

---

**OpenROAD**

**OpenROAD Team**

**Mar 27, 2024**



# CONTENTS

<b>1 Documentation</b>	<b>3</b>
<b>2 Code of conduct</b>	<b>5</b>
<b>3 How to contribute</b>	<b>7</b>
<b>4 How to get in touch</b>	<b>9</b>
<b>5 Site Map</b>	<b>11</b>
5.1 OpenROAD . . . . .	11
5.2 OpenROAD . . . . .	24
5.3 Getting Involved . . . . .	184
5.4 Contributor Covenant Code of Conduct . . . . .	210
5.5 FAQs . . . . .	212



The OpenROAD (“Foundations and Realization of Open, Accessible Design”) project was launched in June 2018 within the DARPA IDEA program. OpenROAD aims to bring down the barriers of cost, expertise and unpredictability that currently block designers’ access to hardware implementation in advanced technologies. The project team (Qualcomm, Arm and multiple universities and partners, led by UC San Diego) is developing a fully autonomous, open-source tool chain for digital SoC layout generation, focusing on the RTL-to-GDSII phase of system-on-chip design. Thus, OpenROAD holistically attacks the multiple facets of today’s design cost crisis: engineering resources, design tool licenses, project schedule, and risk.

The IDEA program targets no-human-in-loop (NHIL) design, with 24-hour turnaround time and zero loss of power-performance-area (PPA) design quality.

The NHIL target requires tools to adapt and auto-tune successfully to flow completion, without (or, with minimal) human intervention. Machine intelligence augments human expertise through efficient modeling and prediction of flow and optimization outcomes throughout the synthesis, placement and routing process. This is complemented by development of metrics and machine learning infrastructure.

The 24-hour runtime target implies that problems must be strategically decomposed throughout the design process, with clustered and partitioned subproblems being solved and recomposed through intelligent distribution and management of computational resources. This ensures that the NHIL design optimization is performed within its available [threads \* hours] “box” of resources. Decomposition that enables parallel and distributed search over cloud resources incurs a quality-of-results loss, but this is subsequently recovered through improved flow predictability and enhanced optimization.

For a technical description of the OpenROAD flow, please refer to our DAC-2019 paper: [Toward an Open-Source Digital Flow: First Learnings from the OpenROAD Project](#). The paper is also available from [ACM Digital Library](#). Other publications and presentations are linked [here](#).



---

**CHAPTER  
ONE**

---

**DOCUMENTATION**

The OpenROAD Project has two releases:

- Application ([github](#)) ([docs](#)): The application is a standalone binary for digital place and route that can be used by any other RTL-GDSII flow controller.
- Flow ([github](#)) ([docs](#)): This is the native OpenROAD flow that consists of a set of integrated scripts for an autonomous RTL-GDSII flow using OpenROAD and other open-source tools.



---

**CHAPTER  
TWO**

---

**CODE OF CONDUCT**

Please read our code of conduct [\*here\*](#).



---

CHAPTER  
**THREE**

---

## HOW TO CONTRIBUTE

If you are willing to **contribute**, see the [\*Getting Involved\*](#) section.

If you are a **developer** with EDA background, learn more about how you can use OpenROAD as the infrastructure for your tools in the [\*Developer Guide\*](#) section.

OpenROAD uses Git for version control and contributions. Get familiarised with a quickstart tutorial to contribution [\*here\*](#).



---

**CHAPTER  
FOUR**

---

## **HOW TO GET IN TOUCH**

We maintain the following channels for communication:

- Project homepage and news: <https://theopenroadproject.org>
- Twitter: [https://twitter.com/OpenROAD\\_EDA](https://twitter.com/OpenROAD_EDA)
- Issues and bugs:
  - OpenROAD: <https://github.com/The-OpenROAD-Project/OpenROAD/issues>
- Discussions:
  - OpenROAD: <https://github.com/The-OpenROAD-Project/OpenROAD/discussions>
- Inquiries: [openroad@ucsd.edu](mailto:openroad@ucsd.edu)


See also our [\*FAQs\*](#).



## 5.1 OpenROAD

### 5.1.1 About OpenROAD

OpenROAD is the leading open-source, foundational application for semiconductor digital design. The OpenROAD flow delivers an Autonomous, No-Human-In-Loop (NHIL) flow, 24 hour turnaround from RTL-GDSII for rapid design exploration and physical design implementation.



### 5.1.2 OpenROAD Mission

OpenROAD eliminates the barriers of cost, schedule risk and uncertainty in hardware design to promote open access to rapid, low-cost IC design software and expertise and system innovation. The OpenROAD application enables flexible flow control through an API with bindings in Tcl and Python.

OpenROAD is used in research and commercial applications such as,

- [OpenROAD-flow-scripts](#) from [OpenROAD](#)
- [OpenLane](#) from Efabless
- [Silicon Compiler](#) from [Zero ASIC](#)
- [Hammer](#) from [UC Berkeley](#)
- [OpenFASoC](#) from [IDEA-FASoC](#) for mixed-signal design flows

OpenROAD fosters a vibrant ecosystem of users through active collaboration and partnership through software development and key alliances. Our growing user community includes hardware designers, software engineers, industry collaborators, VLSI enthusiasts, students and researchers.


OpenROAD strongly advocates and enables IC design-based education and workforce development initiatives through training content and courses across several global universities, the Google-SkyWater [shuttles](#) also includes Global-Foundries shuttles, design contests and IC design workshops. The OpenROAD flow has been successfully used to date in over 600 silicon-ready tapeouts for technologies up to 12nm.

### 5.1.3 Getting Started with OpenROAD-flow-scripts

OpenROAD provides [OpenROAD-flow-scripts](#) as a native, ready-to-use prototyping and tapeout flow. However, it also enables the creation of any custom flow controllers based on the underlying tools, database and analysis engines. Please refer to the flow documentation [here](#).

OpenROAD-flow-scripts (ORFS) is a fully autonomous, RTL-GDSII flow for rapid architecture and design space exploration, early prediction of QoR and detailed physical design implementation. However, ORFS also enables manual intervention for finer user control of individual flow stages through Tcl commands and Python APIs.

Figure below shows the main stages of the OpenROAD-flow-scripts:



Here are the main steps for a physical design implementation using OpenROAD:

- Floorplanning

- Floorplan initialization - define the chip area, utilization
- IO pin placement (for designs without pads)
- Tap cell and well tie insertion
- PDN- power distribution network creation
- **Global Placement**
  - Macro placement (RAMs, embedded macros)
  - Standard cell placement
  - Automatic placement optimization and repair for max slew, max capacitance, and max fanout violations and long wires
- **Detailed Placement**
  - Legalize placement - align to grid, adhere to design rules
  - Incremental timing analysis for early estimates
- **Clock Tree Synthesis**
  - Insert buffers and resize for high fanout nets
- **Optimize setup/hold timing**
- **Global Routing**
  - Antenna repair
  - Create routing guides
- **Detailed Routing**
  - Legalize routes, DRC-correct routing to meet timing, power constraints
- **Chip Finishing**
  - Parasitic extraction using OpenRCX
  - Final timing verification
  - Final physical verification
  - Dummy metal fill for manufacturability
  - Use KLayout or Magic using generated GDS for DRC signoff

## GUI

The OpenROAD GUI is a powerful visualization, analysis, and debugging tool with a customizable Tcl interface. The below figures show GUI views for various flow stages including floorplanning, placement congestion, CTS and post-routed design.

### **Floorplan**

#### **Automatic Hierarchical Macro Placement**

#### **Placement Congestion Visualization**

### **CTS**

### **Routing**

### **PDK Support**

The OpenROAD application is PDK independent. However, it has been tested and validated with specific PDKs in the context of various flow controllers.

OpenLane supports SkyWater 130nm and GlobalFoundries 180nm.

OpenROAD-flow-scripts supports several public and private PDKs including:

#### **Open-Source PDKs**

- GF180 - 180nm
- SKY130 - 130nm
- Nangate45 - 45nm
- ASAP7 - Predictive FinFET 7nm

#### **Proprietary PDKs**

These PDKS are supported in OpenROAD-flow-scripts only. They are used to test and calibrate OpenROAD against commercial platforms and ensure good QoR. The PDKs and platform-specific files for these kits cannot be provided due to NDA restrictions. However, if you are able to access these platforms independently, you can create the necessary platform-specific files yourself.

- GF55 - 55nm
- GF12 - 12nm
- Intel22 - 22nm

- Intel16 - 16nm
- TSMC65 - 65nm

#### 5.1.4 Tapeouts

OpenROAD has been used for full physical implementation in over 600 tapeouts in SKY130 and GF180 through the Google-sponsored, Efabless MPW shuttle and ChipIgnite programs.

#### OpenTitan SoC on GF12LP - Physical design and optimization using OpenROAD

#### Continuous Tapeout Integration into CI

The OpenROAD project actively adds successfully taped out MPW shuttle designs to the [CI regression testing](#). Examples of designs include Open processor cores, RISC-V based SoCs, cryptocurrency miners, robotic app processors, amateur satellite radio transceivers, OpenPower-based Microwatt etc.

#### 5.1.5 Build OpenROAD

To build OpenROAD tools locally in your machine, follow steps from [here](#).

#### 5.1.6 Regression Tests

There are a set of executable regression test scripts in `./test/`.

```
# run tests for all tools
./test/regression

# run all flow tests
./test/regression flow

# run <tool> tests
./test/regression <tool>

# run all <tool>-specific unit tests
cd src/<tool>
./test/regression

# run only <TEST_NAME> for <tool>
cd src/<tool>
./test/regression <TEST_NAME>
```

The flow tests check results such as worst slack against reference values. Use `report_flow_metrics [test]...` to see all of the metrics.

```
% report_flow_metrics gcd_nangate45
          insts    area   util  slack_min  slack_max  tns_max  clk_skew  max_slew
←max_cap max_fanout DPL ANT drv
gcd_nangate45           368      564   8.8       0.112     -0.015     -0.1      0.004      0
←          0        0    0    0
```

To update a failing regression, follow the instructions below:

```
# update log files (i.e. *ok)
save_ok <TEST_NAME>

# update "*.metrics" for tests that use flow test
save_flow_metrics <TEST_NAME>

# update "*.metrics_limits" files
save_flow_metrics_limits <TEST_NAME>
```

### 5.1.7 Run

```
openroad [-help] [-version] [-no_init] [-exit] [-gui]
          [-threads count|max] [-log file_name] cmd_file
  -help            show help and exit
  -version         show version and exit
  -no_init         do not read .openroad init file
  -threads count|max use count threads
  -no_splash       do not show the license splash at startup
  -exit            exit after reading cmd_file
  -gui             start in gui mode
  -python           start with python interpreter [limited to db operations]
  -log <file_name> write a log in <file_name>
  cmd_file         source cmd_file
```

OpenROAD sources the Tcl command file `~/.openroad` unless the command line option `-no_init` is specified.

OpenROAD then sources the command file `cmd_file` if it is specified on the command line. Unless the `-exit` command line flag is specified, it enters an interactive Tcl command interpreter.

A list of the available tools/modules included in the OpenROAD app and their descriptions are available [here](#).

### 5.1.8 Git Quickstart

OpenROAD uses Git for version control and contributions. Get familiarised with a quickstart tutorial to contribution [here](#).

## 5.1.9 Understanding Warning and Error Messages

Seeing OpenROAD warnings or errors you do not understand? We have compiled a table of all messages and you may potentially find your answer [here](#).

## 5.1.10 License

BSD 3-Clause License. See LICENSE file.

## 5.1.11 Installing OpenROAD

### Build

The first step, independent of the build method, is to download the repository:

```
git clone --recursive https://github.com/The-OpenROAD-Project/OpenROAD.git
cd OpenROAD
```

OpenROAD git submodules (cloned by the --recursive flag) are located in `src/`.

The default build type is RELEASE to compile optimized code. The resulting executable is in `build/src/openroad`. Optional CMake variables passed as `-D<var>=<value>` arguments to CMake are show below.

Argument	Value
<code>CMAKE_BUILD_TYPE</code>	DEBUG, RELEASE
<code>CMAKE_CXX_FLAGS</code>	Additional compiler flags
<code>TCL_LIBRARY</code>	Path to Tcl library
<code>TCL_HEADER</code>	Path to <code>tcl.h</code>
<code>ZLIB_ROOT</code>	Path to <code>zlib</code>
<code>CMAKE_INSTALL_PREFIX</code>	Path to install binary

**Note:** There is a `openroad_build.log` file that is generated with every build in the build directory. In case of filing issues, it can be uploaded in the “Relevant log output” section of OpenROAD [issue forms](#).

### Install dependencies

You may follow our helper script to install dependencies as follows:

```
sudo ./etc/DependencyInstaller.sh
```

### WARNING

`etc/DependencyInstaller.sh` defaults to installing system packages and requires sudo access. These packages can affect your environment. We recommend users install dependencies locally using `setup.sh` from OpenROAD-flow-scripts.

### Build Manually

```
mkdir build && cd build  
cmake ..  
make  
make install
```

The default install directory is /usr/local. To install in a different directory with CMake use:

```
cmake .. -DCMAKE_INSTALL_PREFIX=<prefix_path>
```

Alternatively, you can use the DESTDIR variable with make.

```
make DESTDIR=<prefix_path> install
```

### Build using support script

```
./etc/Build.sh  
# To build with debug option enabled and if the Tcl library is not on the default path  
./etc/Build.sh -cmake="-DCMAKE_BUILD_TYPE=DEBUG -DTCL_LIB=/path/to/tcl/lib"
```

The default install directory is /usr/local. To install in a different directory use:

```
./etc/Build.sh -cmake="-DCMAKE_INSTALL_PREFIX=<prefix_path>"
```

### LTO Options

By default, OpenROAD is built with link time optimizations enabled. This adds about 1 minute to compile times and improves the runtime by about 11%. If you would like to disable LTO pass -DLINK\_TIME\_OPTIMIZATION=OFF when generating a build.

### Build with Address Sanitizer

To enable building with Address Sanitizer, use the argument -DASAN=ON. Setting the ASAN variable to ON adds necessary compile and link options for using Address Sanitizer.

**Note:** Address Sanitizer adds instrumentation for detecting memory errors. Enabling this option will cause OpenROAD to run slower and consume more RAM.

### Build with Prebuilt Binaries

Courtesy of [Precision Innovations](#), there are pre-built binaries of OpenROAD with self-contained dependencies released on a regular basis. Refer to this [link](#) here.

## 5.1.12 Tutorials

### OpenROAD Flow Scripts Tutorial

Flow tutorial can be accessed from OpenROAD Flow Scripts documentation [here](#).

## 5.1.13 Git Quickstart

This tutorial serves as a quickstart to Git and contributing to our repository. If you have not already set up OpenROAD, please follow the instructions [here](#).

---

**Tip:** This basic tutorial gives instruction for basic password Git authentication. If you would like to setup SSH authentication, please follow this [guide](#).

---

### Forking

You will need your own fork to work on the code. Go to the OpenROAD project [page](#) and hit the Fork button. You will want to clone your fork to your machine:

```
git clone https://github.com/your-user-name/OpenROAD.git
cd OpenROAD
git remote add upstream https://github.com/The-OpenROAD-Project/OpenROAD.git
git fetch upstream
```

This creates the directory OpenROAD and connects your repository to the upstream (master project) *OpenROAD* repository.

### Creating a branch

You want your master branch to reflect only production-ready code, so create a feature branch for making your changes. For example:

```
git checkout master && git branch shiny-new-feature
git checkout shiny-new-feature
# Or equivalently,
git checkout master && checkout -b shiny-new-feature
```

This changes your working directory to the shiny-new-feature branch. Keep any changes in this branch specific to one bug or feature so it is clear what the branch brings to OpenROAD. You can have many shiny-new-features and switch in between them using the git checkout command.

When creating this branch, make sure your master branch is up to date with the latest upstream master version. To update your local master branch, you can do:

```
git checkout master
git pull upstream master
```

When you want to update the feature branch with changes in master after you created the branch, check the section on [updating a PR](#).

### Committing your code

Keep style fixes to a separate commit to make your pull request more readable. Once you've made changes, you can see them by typing:

```
git status
```

If you have created a new file, it is not being tracked by git. Add it by typing:

```
git add path/to/file-to-be-added.py
```

Doing `git status` again should give something like:

```
# On branch shiny-new-feature
#
#       modified:   /relative/path/to/file-you-added.py
#
```

Finally, commit your changes to your local repository with an explanatory commit message. Do note the `-s` option is needed for developer signoff.

```
git commit -s -m "your commit message goes here"
```

### Pushing your changes

When you want your changes to appear publicly on your GitHub page, push your forked feature branch's commits:

```
git push origin shiny-new-feature
```

Here `origin` is the default name given to your remote repository on GitHub. You can see the remote repositories:

```
git remote -v
```

If you added the upstream repository as described above you will see something like:

```
origin  https://github.com/your-user-name/OpenROAD.git (fetch)
origin  https://github.com/your-user-name/OpenROAD.git (push)
upstream    https://github.com/The-OpenROAD-Project/OpenROAD.git (fetch)
upstream    https://github.com/The-OpenROAD-Project/OpenROAD.git (push)
```

Now your code is on GitHub, but it is not yet a part of the OpenROAD project. For that to happen, a pull request needs to be submitted on GitHub.

### Review your code

When you're ready to ask for a code review, file a pull request. Before you do, once again make sure that you have followed all the guidelines outlined in the [Developer's Guide](#) regarding code style, tests, performance tests, and documentation. You should also double check your branch changes against the branch it was based on:

1. Navigate to your repository on GitHub – <https://github.com/your-user-name/OpenROAD>
2. Click on Branches
3. Click on the Compare button for your feature branch

4. Select the base and compare branches, if necessary. This will be master and shiny-new-feature, respectively.

## Submitting the pull request

If everything looks good, you are ready to make a pull request. A pull request is how code from a local repository becomes available to the GitHub community and can be looked at and eventually merged into the master version. This pull request and its associated changes will eventually be committed to the master branch and available in the next release. To submit a pull request:

1. Navigate to your repository on GitHub
2. Click on the `Compare & pull request` button
3. You can then click on `Commits and Files Changed` to make sure everything looks okay one last time
4. Write a description of your changes in the `Preview Discussion` tab
5. Click `Send Pull Request`.

This request then goes to the repository maintainers, and they will review the code.

## Updating your pull request

Based on the review you get on your pull request, you will probably need to make some changes to the code. In that case, you can make them in your branch, add a new commit to that branch, push it to GitHub, and the pull request will be automatically updated. Pushing them to GitHub again is done by:

```
git push origin shiny-new-feature
```

This will automatically update your pull request with the latest code and restart the *Continuous Integration* tests.

Another reason you might need to update your pull request is to solve conflicts with changes that have been merged into the master branch since you opened your pull request.

To do this, you need to `merge upstream master` in your branch:

```
git checkout shiny-new-feature
git fetch upstream
git merge upstream/master
```

If there are no conflicts (or they could be fixed automatically), a file with a default commit message will open, and you can simply save and quit this file.

If there are merge conflicts, you need to solve those conflicts. See this [article](#) for an explanation on how to do this. Once the conflicts are merged and the files where the conflicts were solved are added, you can run `git commit` to save those fixes.

If you have uncommitted changes at the moment you want to update the branch with master, you will need to `stash` them prior to updating.

### See also:

See the [stash docs](#).

This will effectively store your changes and they can be reapplied after updating.

After the feature branch has been updated locally, you can now update your pull request by pushing to the branch on GitHub:

```
git push origin shiny-new-feature
```

### Tips for a successful pull request

If you have made it to the `Review your code` phase, one of the core contributors may take a look. Please note however that a handful of people are responsible for reviewing all of the contributions, which can often lead to bottlenecks.

To improve the chances of your pull request being reviewed, you should:

- **Reference an open issue** for non-trivial changes to clarify the PR's purpose
- **Ensure you have appropriate tests.** These should be the first part of any PR
- **Keep your pull requests as simple as possible.** Larger PRs take longer to review
- **Ensure that CI is in a green state.** Reviewers may not even look otherwise
- **Keep updating your pull request**, either by request or every few days

### Acknowledgements

This page has been adapted from [pandas Developer Guide](#).

## 5.2 OpenROAD

OpenROAD is run using Tcl scripts. The following commands are used to read and write design data.

```
read_lef [-tech] [-library] filename  
read_def filename  
write_def [-version 5.8|5.7|5.6|5.5|5.4|5.3] filename  
read_verilog filename  
write_verilog filename  
read_db filename  
write_db filename  
write_abstract_lef filename
```

Use the `Tcl source` command to read commands from a file.

```
source [-echo] file
```

If an error is encountered in a command while reading the command file, then the error is printed and no more commands are read from the file. If `file_continue_on_error` is 1 then OpenROAD will continue reading commands after the error.

If `exit_on_error` is 1 then OpenROAD will exit when it encounters an error.

OpenROAD can be used to make a OpenDB database from LEF/DEF, or Verilog (flat or hierarchical). Once the database is made it can be saved as a file with the `write_db` command. OpenROAD can then read the database with the `read_db` command without reading LEF/DEF or Verilog.

The `read_lef` and `read_def` commands can be used to build an OpenDB database as shown below. The `read_lef -tech` flag reads the technology portion of a LEF file. The `read_lef -library` flag reads the MACROs in the LEF file. If neither of the `-tech` and `-library` flags are specified they default to `-tech -library` if no technology has been read and `-library` if a technology exists in the database.

```
read_lef liberty1.lef
read_def reg1.def
# Write the db for future runs.
write_db reg1.db
```

The `read_verilog` command is used to build an OpenDB database as shown below. Multiple Verilog files for a hierarchical design can be read. The `link_design` command is used to flatten the design and make a database.

```
read_lef liberty1.lef
read_verilog reg1.v
link_design top
# Write the db for future runs.
write_db reg1.db
```

## 5.2.1 Example scripts

Example scripts demonstrating how to run OpenROAD on sample designs can be found in `/test`. Flow tests taking sample designs from synthesizable RTL Verilog to detail-routed final layout in the open-source technologies Nangate45 and Sky130HD are shown below.

```
gcd_nangate45.tcl
aes_nangate45.tcl
tinyRocket_nangate45.tcl
gcd_sky130hd.tcl
aes_sky130hd.tcl
ibex_sky130hd.tcl
```

Each of these designs use the common script `flow.tcl`.

## 5.2.2 Abstract LEF Support

OpenROAD contains an abstract LEF writer that can take your current design and emit an abstract LEF representing the external pins of your design and metal obstructions.

```
write_abstract_lef (-bloat_factor bloat_factor|-bloat_occupied_layers) \
filename
```

### Options

Switch Name	Description
<code>-bloat_factor</code>	Specifies the bloat factor used when bloating then merging shapes into LEF obstructions. The factor is measured in # of default metal pitches for the respective layer. A factor of 0 will result in detailed LEF obstructions
<code>-bloat_occupied_layers</code>	Creates LEF obstructions (obstructions over the entire layer) for each layer where shapes are present

## Examples

```
read reg1.db

# Bloat metal shapes by 3 pitches (respectively for every layer) and then merge
write_abstract_lef -bloat_factor 3 reg1_abstract.lef

# Produce cover obstructions for each layer with shapes present
write_abstract_lef -bloat_occupied_layers reg1_abstract.lef
```

## Global Connections

### Add global connections

The `add_global_connection` command is used to specify how to connect power and ground pins on design instances to the appropriate supplies.

```
add_global_connection -net net_name \
                      [-inst_pattern inst_regular_expression] \
                      -pin_pattern pin_regular_expression \
                      (-power|-ground) \
                      [-region region_name]
```

## Options

Switch Name	Description
<code>-net</code>	Specifies the name of the net in the design to which connections are to be added
<code>-inst_pattern</code>	Optional specifies a regular expression to select a set of instances from the design. (Default: <code>.*</code> )
<code>-pin_pattern</code>	Specifies a regular expression to select pins on the selected instances to connect to the specified net
<code>-power</code>	Specifies that the net it a power net
<code>-ground</code>	Specifies that the net is a ground net
<code>-region</code>	Specifies the name of the region for this rule

## Examples

```
# Stdcell power/ground pins
add_global_connection -net VDD -pin_pattern {^VDD\$} -power
add_global_connection -net VSS -pin_pattern {^VSS\$} -ground

# SRAM power ground pins
add_global_connection -net VDD -pin_pattern {^VDDPE\$}
add_global_connection -net VDD -pin_pattern {^VDDCE\$}
add_global_connection -net VSS -pin_pattern {^VSSE\$}
```

## Perform global connections

The `global_connect` command is used to connect power and ground pins on design instances to the appropriate supplies.

```
global_connect
```

## Clear global connection rules

The `clear_global_connect` command is used remove all defined global connection rules.

```
clear_global_connect
```

## Report global connection rules

The `report_global_connect` command is used print out the currently defined global connection rules.

```
report_global_connect
```

## Report cell type usage

The `report_cell_usage` command is used to print out the usage of cells for each type of cell.

```
report_cell_usage
```

### 5.2.3 TCL functions

Get the die and core areas as a list in microns: `llx lly urx ury`

```
ord::get_die_area  
ord::get_core_area
```

### 5.2.4 FAQs

Check out [GitHub discussion](#) about this tool.

### 5.2.5 License

BSD 3-Clause License.

### 5.2.6 OpenDB

OpenDB is a design database to support tools for physical chip design. It was originally developed by Athena Design Systems. Nefelus, Inc. acquired the rights to the code and open-sourced it with BSD-3 license in 2019 to support the DARPA OpenROAD project.

The structure of OpenDB is based on the text file formats LEF (library) and DEF (design) formats version 5.6. OpenDB supports a binary file format to save and load the design much faster than using LEF and DEF.

OpenDB is written in C++ 98 with standard library style iterators. The classes are designed to be fast enough to base an application on without having to copy them into application-specific structures.

#### Directory structure

```
include/odb/db.h - public header for all database classes  
src/db - private/internal database representations  
src/lefin - LEF reader  
src/lefout - LEF writer  
src/defin - DEF reader  
src/defout - DEF writer
```

#### Database API

We are still working on documenting the APIs. We have over 1,800 objects and functions that we are still documenting (for both TCL and Python). **Contributions are very welcome in this effort.** Find starting points below.

#### TCL

After building successfully, run OpenDB Tcl shell using `../.../build/src/odb/src/swig/tcl/odbtcl`. An example usage:

```
set db [dbDatabase_create]  
set lef_parser [new_lefin $db true]  
set tech [lefin_createTech $lef_parser ./src/odb/test/data/gscl45nm.lef]
```

You can find examples on using the API from Tcl under `test/tcl/` directory.

The full set of the Tcl commands exposed can be found under `./build/src/swig/tcl/opendb_wrapper.cpp`. Search for `SWIG_prefix`.

#### Python

After building successfully, run `openroad -python` to enable the Python interpreter. You can find examples on using the API from Python under `test/python/` directory.

To list the full set of the Python classes exposed run `openroad -python` then:

```
import openroad  
import odb  
print(' ', '.join(dir(openroad)))  
print(' ', '.join(dir(odb)))
```

## C++

All public database classes are defined in `db.h`. These class definitions provide all functions for examining and modifying the database objects. The database is an object itself, so multiple database objects can exist simultaneously (no global state).

`dbTypes.h` defines types returned by database class member functions.

All database objects are in the `odb` namespace.

- `dbChip`
- `dbBlock`
- `dbTech`
- `dbLib`

All database objects have a 32bit object identifier accessed with the `dbObject::getOID` base class member function that returns a `uint`. This identifier is preserved across save/restores of the database so it should be used to reference database object by data structures instead of pointers if the reference lifetime is across database save/restores. OIDs allow the database to have exactly the same layout across save/restores.

The database distance units are **nanometers** and use the type `uint`.

## Example scripts

### Regression tests

There are a set of regression tests in `/test`.

```
./test/regression-tcl.sh  
./test/regression-py.sh
```

## Database Internals

The internal description included here is paraphrased from Lukas van Ginneken by James Cherry.

The database separates the implementation from the interface, and as a result, each class becomes two classes, a public one and a private one. For instance, `dbInst` has the public API functions, while class `_dbInst` has the private data fields.

The objects are allocated in dynamically resizable tables, the implementation of which is in `dbTable.hpp`. Each table consists of a number of pages, each containing 128 objects. The table contains the body of the `struct`, not a set of pointers. This eliminates most of the pointer overhead while iteration is accomplished by stepping through the table. Thus, grouping these objects does not require a doubly-linked list and saves 16 bytes per object (at the cost of some table overhead). Each object has an id, which is the index into the table. The lowest 7 bits are the index in the page, while the higher bits are the page number. Object id's are persistent when saving and reading the data model to disk, even as pointer addresses may change.

Everything in the data model can be stored on disk and restored from disk exactly the way it was. An extensive set of equality tests and diff functions make it possible to check for even the smallest deviation. The capability to save an exact copy of the state of the system makes it possible to create a checkpoint. This is a necessary capability for debugging complex systems.

The code follows the definition of LEF and DEF closely and reflects many of the idiosyncrasies of LEF and DEF. The code defines many types of objects to reflect LEF and DEF constructs although it sometimes uses different terminology, for instance, the object to represent a library cell is called `dbMaster` while the LEF keyword is `MACRO`.

The data model supports the EEQ and LEQ keywords (i.e., electrically equivalent and logically equivalent Masters), which could be useful for sizing. However, it does not support any logic function representation. In general, there is very limited support for synthesis-specific information: no way to represent busses, no way to represent logic function, very limited understanding of signal flow, limited support of timing information, and no support for high level synthesis or test insertion.

The db represents routing as in DEF, representing a trace from point to point with a given width. The layout for a net is stored in a class named `dbWire` and it requires a special `dbWireDecoder` (which works like an iterator) to unpack the data and another `dbWireEncoder` to pack it. The data model does not support a region query and objects that are in the same layer are scattered about the data model and are of different classes.

This means that whatever tool is using the layout information will have to build its own data structures that are suitable to the layout operations of that tool. For instance, the router, the extractor, and the DRC engine would each have to build their unique data structures. This encourages batch mode operation (route the whole chip, extract the whole chip, run DRC on the whole chip).

## Limitations

## FAQs

Check out [GitHub discussion](#) about this tool.

## LICENSE

BSD 3-Clause License. See LICENSE file.

## Automatic Code Generator

This is an automatic code generation tool for OpenDB objects and Iterators. To test the tool you can use the following command

```
python3 gen.py --json schema.json --src_dir ../db --include_dir ../../include/odb --  
--templates templates
```

Where schema.json is the json file that includes the requirements, src is the source files directory, include is the include directory, and templates is the directory including the jinja templates for the classes.

Empty sections are removed by default from the output. If you need to add something to a section that is currently empty, you can run the generator with `--keep_empty` to preserve them. Once the section is filled in, the flag can be dropped and the code regenerated to remove the remaining empty sections.

## Python Unit Tests

### Running tests

For running the python unit tests you will need to install first `testtools` and `unittest-parallel` which enables concurrent unit testing

```
pip3 install testtools  
pip3 install unittest-parallel
```

Then, you can run the unit tests in sequence by running

```
../unitTests.sh
```

or in parallel by running

```
../unitTests.sh parallel
```

**Note:** The test cases within each Unit Test run in parallel in both situations

---

## Tests Structure

The directory unitTestsPython includes unit tests for OpenDB Python APIs. Any test file starts with ‘Test’ followed by the test target.

### odbUnitTest.py:

This includes TestCase class which inherits from unittest.TestCase with additional functionalities:

- `changeAndTest(self,obj,SetterName,GetterName,expectedVal,*args)` which is a function for changing a value and testing for the effect of that change where:
  - `obj` is the object to be tested
  - `SetterName` is the name of the function to be called for changing a value
  - `GetterName` is the name of the function to be called for testing the effect
  - `expectedVal` is the expected value for the testing
  - `*args` are the arguments passed to the `SetterName` function

So, in the end, the expected behavior is:

```
obj.SetterName(*args)  
  
assert(obj.GetterName()==expectedVal)
```

- `check(self,obj,GetterName,expectedVal,*args)` which tests against expected value
- `change(self,obj,SetterName,*args)` which changes a value in the object
- `main()` runs the TestCase in sequential order
- `mainParallel(Test)` runs the passed Test class in parallel

### helper.py:

A set of functions for creating simple db instances to be used for testing. You can find the description of each function in the comments

### TestNet.py:

Unit test class for testing dbNet. It inherits from `odbUnitTest.TestCase`. it consists of

- `setUp(self)` function to be called before each test case. Here, we create the database with the desired chip, block, masters, instances and nets.
- `tearDown(self)` function to be called after each test case. Here, we destroy our db.
- `test_*(self)` the test cases functions. Their names should start with `test` for the unittest suite to recognize.

### TestDestroy.py:

Integration test class for testing the `destroy(*args)` function on OpenDB.

- `test_destroy_net` destroying net and testing for the effect on the *block,inst, iterms and bterms*
- `test_destroy_inst` destroying instance and testing for the effect on *block, iterms, net, bterms*
- `test_destroy_bterm` destroying bterm and testing for the effect on *block and net*
- `test_destroy_block` destroying block and testing for the effect on *block(parent and child relation), and chip*
- `test_destroy_bpin` destroying bpin and testing for the effect on *bterm*
- `test_create_destroy_wire` destroying wire and test for the effect on *net*
- `test_destroy_capnode` destroying capnode and test for the effect on *net(node and connected ccsegs)*
- `test_destroy_ccseg` destroying ccseg and test for the effect on *node,block and net*
- `test_destroy_lib` destroying lib and test for the effect on *db*
- `test_destroy_obstruction` destroying obstruction and test for the effect on *block*
- `test_create_regions` creating regions and test for the effect on *block and region(parent and child relation)*
- `test_destroy_region_child` destroying *\_* and test for the effect on *block and region(parent)*
- `test_destroy_region_parent` destroying *\_* and test for the effect on *block*

### TestBlock.py:

Unit Test for dbBlock

- `test_find` testing the find function with *BTerm, Child, Inst, Net, ITerm, ExtCornerBlock, nonDefaultRule, Region*
- Testing the `ComputeBBox()` function through the first call of `getBBox`:
  - `test_bbox0` testing empty block box
  - `test_bbox1` testing block box with Inst placed
  - `test_bbox2` testing block box with Inst and BPin placed
  - `test_bbox3` testing block box with Inst, BPin and Obstruction placed
  - `test_bbox4` testing block box with Inst, BPin, Obstruction and SWire placed

### TestBTerm.py:

Unit Test for dbBTerm

- `test_idle` testing for idle disconnected BTerm behavior
- `test_connect` testing connect function of BTerm on BTerm and Net
- `test_disconnect` testing disconnect function of BTerm on BTerm and Net

### TestInst.py:

Unit Test for dbInst

- `test_swap_master` testing swap master function

### TestITerm.py:

Unit Test for dbITerm

- `test_idle` testing for disconnected ITerm without a net
- `test_connection_from_iterm` testing the connect(ITerm,...) and disconnect functions of ITerm and their effect on ITerm and Net
- `test_connection_from_inst` testing the connect(Inst,...) and disconnect functions of ITerm and their effect on ITerm and Net
- Testing for getAvgXY() function
  - `test_avgxy_R0` testing with default orientation R0
  - `test_avgxy_R90` testing with different orientation R90 for transformation

---

## Problems Found In Testing

- multiple core dumps that leads to aborting the process:
  - `dbNet.get1st*()` (when nothing on top of the list)
  - `childRegion.getParent()` (after destroying the parent region)
- Implementation of ComputeBBox() is flawed and needs to be reconsidered

## Adding new fields in DB Object

For example `add_pitchDiag` in object `DbTechLayer`.

	Action	File	Source Code
1	Add Fields at the .h file	dbTechLayer.h	
2	Define a keyword for db rev number	dbDatabase.h	#define ADS_DB_DF58 52
3	Set the current rev number same as	dbDatabase.h	#define ADS_DB_SCHEMA_MINOR 52
4	Stream in new fields Conditionally upon Schema number	dbTechLayer.cpp	if ( stream.getDatabase()->isSchema(ADS_DB_DF58) ) { stream >> layer._pitchDiag;
5	Stream out new fields Conditionally upon Schema number	dbTechLayer.cpp	if ( stream.getDatabase()->isSchema(ADS_DB_DF58) ) { stream << layer._pitchDiag;
6	Conditionally Diff new fields	dbTechLayer.cpp	if ( stream.getDatabase()->isSchema(ADS_DB_DF58) ) { DIFF_FIELD(_pitchDiag);
7	Conditionally Diff Out new fields	dbTechLayer.cpp	if ( stream.getDatabase()->isSchema(ADS_DB_DF58) ) { DIFF_OUT_FIELD(_pitchDiag);
8	Created access APIs to the fields	dbTechLayer.h	"dbTechLayer::getPitchDiag(), dbTechLayer::setPitchDiag( int pitch )"
9	Add new APIs in include/db.h	db.h	class dbTechLayer

## 5.2.7 Graphical User Interface

The graphical user interface can be accessed by launching OpenROAD with `-gui` or by opening it from the command-line with `gui::show`.

### Commands

#### Add buttons to the toolbar

```
create_toolbar_button [-name name]
                      -text button_text
                      -script tcl_script
                      [-echo]
```

Returns: name of the new button, either `name` or `buttonX`.

Options description:

- `button_text`: The text to put on the button.
- `tcl_script`: The tcl script to evaluate when the button is pressed.
- `name`: (optional) name of the button, used when deleting the button.
- `echo`: (optional) indicate that the commands in the `tcl_script` should be echoed in the log.

To remove the button:

```
gui::remove_toolbar_button name
```

## Add items to the menubar

```
create_menu_item [-name name]
                  [-path menu_path]
                  -text item_text
                  -script tcl_script
                  [-shortcut key_shortcut]
                  [-echo]
```

Returns: name of the new item, either name or actionX.

Options description:

- **item\_text**: The text to put on the item.
- **tcl\_script**: The tcl script to evaluate when the button is pressed.
- **name**: (optional) name of the item, used when deleting the item.
- **menu\_path**: (optional) Menu path to place the new item in (hierarchy is separated by /), defaults to “Custom Scripts”, but this can also be “Tools” or “New menu/New submenu”.
- **key\_shortcut**: (optional) key shortcut to trigger this item.
- **echo**: (optional) indicate that the commands in the **tcl\_script** should be echoed in the log.

To remove the item:

```
gui::remove_menu_item name
```

## Save screenshot of layout

This command can be both be used when the GUI is active and not active.

```
save_image [-resolution microns_per_pixel]
           [-area {x0 y0 x1 y1}]
           [-width width]
           [-display_option {option value}]
           filename
```

Options description:

- **filename** path to save the image to.
- **x0**, **y0** first corner of the layout area (in microns) to be saved, default is to save what is visible on the screen unless called when gui is not active and then it selected the whole block.
- **x1**, **y1** second corner of the layout area (in microns) to be saved, default is to save what is visible on the screen unless called when gui is not active and then it selected the whole block.
- **microns\_per\_pixel** resolution in microns per pixel to use when saving the image, default will match what the GUI has selected.
- **width** width of the output image in pixels, default will be computed from the resolution. Cannot be used with **-resolution**.
- option specific setting for a display option to show or hide specific elements. For example, to hide metal1 -display\_option {Layers/metal1 false}, to show routing tracks -display\_option {Tracks/Pref true}, or to show everthing -display\_option {\*} true}.

### Save screenshot of clock trees

```
save_clocktree_image filename
    -clock clock_name
    [-width width]
    [-height height]
    [-corner corner]
```

Options description:

- **filename** path to save the image to.
- **-clock** name of the clock to save the clocktree for.
- **-corner** name of the timing corner to save the clocktree for, default to the first corner defined.
- **-height** height of the image in pixels, defaults to the height of the GUI widget.
- **-width** width of the image in pixels, defaults to the width of the GUI widget.

### Selecting objects

```
select -type object_type
    [-name glob_pattern]
    [-filter attribute=value]
    [-case_insensitive]
    [-highlight group]
```

Returns: number of objects selected.

Options description:

- **object\_type**: name of the object type. For example, `Inst` for instances, `Net` for nets, and `DRC` for DRC violations.
- **glob\_pattern**: (optional) filter selection by the specified name. For example, to only select clk nets `*clk*`. Use `-case_insensitive` to filter based on case insensitive instead of case sensitive.
- **attribute=value**: (optional) filter selection based on the objects' properties. `attribute` represents the property's name and `value` the property's value. In case the property holds a collection (e. g. BTerms in a Net) or a table (e. g. Layers in a Generate Via Rule) `value` can be any element within those. A special case exists for checking whether a collection is empty or not by using the value `CONNECTED`. This can be useful to select a specific group of elements (e. g. `BTerms=CONNECTED` will select only Nets connected to Input/Output Pins).
- **group**: (optional) add the selection to the specific highlighting group. Values can be 0 to 7.

### Displaying timing cones

```
display_timing_cone pin
    [-fanin]
    [-fanout]
    [-off]
```

Options description:

- **pin**: name of the instance or block pin.

- **fanin**: (optional) display the fanin timing cone.
- **fanout**: (optional) display the fanout timing cone.
- **off**: (optional) remove the timing cone.

## Limit drawing to specific nets

```
focus_net net
    [-remove]
    [-clear]
```

Options description:

- **pin**: name of the net.
- **remove**: (optional) removes the net from from the focus.
- **clear**: (optional) clears all nets from focus.

## TCL functions

### Support

Determine is the GUI is active:

```
gui::enabled
```

Announce to the GUI that a design was loaded (note: this is only needed when the design was loaded through the odb API and not via `read_def` or `read_db`):

```
gui::design_created
```

To load the results of a DRC report:

```
gui::load_drc filename
```

### Opening and closing

To open the GUI from the command-line (this command does not return until the GUI is closed):

```
gui::show
gui::show script
gui::show script interactive
```

Options description:

- **script** TCL script to evaluate in the GUI.
- **interactive** indicates if true the GUI should open in an interactive session (default), or if false that the GUI would execute the script and return to the terminal.

To close the GUI and return to the command-line:

```
gui::hide
```

### Layout navigation

To fit the whole layout in the window:

```
gui::fit
```

To zoom in or out to a specific region:

```
gui::zoom_to x0 y0 x1 y1
```

Options description:

- $x0, y0$  first corner of the layout area in microns.
- $x1, y1$  second corner of the layout area in microns.

To zoom in the layout:

```
gui::zoom_in  
gui::zoom_in x y
```

Options description:

- $x, y$  new center of layout.

To zoom out the layout:

```
gui::zoom_out  
gui::zoom_out x y
```

Options description:

- $x, y$  new center of layout.

To move the layout to new area:

```
gui::center_at x y
```

Options description:

- $x, y$  new center of layout.

To change the resolution to a specific value:

```
gui::set_resolution resolution
```

Options description:

- $resolution$  database units per pixel.

## Selections

To add a single net to the selected items:

```
gui::selection_add_net name
```

Options description:

- **name** name of the net to add.

To add several nets to the selected items:

```
gui::selection_add_nets name_regex
```

Options description:

- **name\_regex** regular expression of the net names to add.

To add a single instance to the selected items:

```
gui::selection_add_inst name
```

Options description:

- **name** name of the instance to add.

To add several instances to the selected items:

```
gui::selection_add_insts name_regex
```

Options description:

- **name\_regex** regular expression of the instance names to add.

To add items at a specific point or in an area:

```
gui::select_at x y
gui::select_at x y append
gui::select_at x0 y0 x1 y1
gui::select_at x0 y0 x1 y1 append
```

Options description:

- **x, y** point in the layout area in microns.
- **x0, y0** first corner of the layout area in microns.
- **x1, y1** second corner of the layout area in microns.
- **append** if **true** (the default value) append the new selections to the current selection list, else replace the selection list with the new selections.

To navigate through multiple selected items:

```
gui::select_next
gui::select_previous
```

Returns: current index of the selected item.

To clear the current set of selected items:

```
gui::clear_selections
```

To get the properties for the current selection in the Inspector:

```
gui::get_selection_property name
```

Options description:

- **name** name of the property. For example, `Type` for object type or `bbox` for the bounding box of the object.

To animate the current selection in the Inspector:

```
gui::selection_animate  
gui::selection_animate repeat
```

Options description:

- **repeat**: indicate how many times the animation should repeat, default value is 0 repeats. If the value is 0, the animation will repeat indefinitely.

## Highlighting

To highlight a net:

```
gui::highlight_net name  
gui::highlight_net name highlight_group
```

Options description:

- **name** name of the net to highlight.
- **highlight\_group** group to add the highlighted net to, defaults to 0, valid groups are 0 - 7.

To highlight an instance:

```
gui::highlight_inst name  
gui::highlight_inst name highlight_group
```

Options description:

- **name** name of the instance to highlight.
- **highlight\_group** group to add the highlighted instance to, defaults to 0, valid groups are 0 - 7.

To clear the highlight groups:

```
gui::clear_highlights  
gui::clear_highlights highlight_group
```

Options description:

- **highlight\_group** group to clear, defaults to 0, valid groups are -1 - 7. Use -1 to clear all groups.

## Rulers

To add a ruler to the layout:

1. either press **k** and use the mouse to place it visually. To disable snapping for the ruler when adding, hold the **Ctrl** key, and to allow non-horizontal or vertical snapping when completing the ruler hold the **Shift** key.
2. or use the command:

```
gui::add_ruler x0 y0 x1 y1
gui::add_ruler x0 y0 x1 y1 label
gui::add_ruler x0 y0 x1 y1 label name
gui::add_ruler x0 y0 x1 y1 label name euclidian
```

Returns: name of the newly created ruler.

Options description:

- **x0**, **y0** first end point of the ruler in microns.
- **x1**, **y1** second end point of the ruler in microns.
- **label** text label for the ruler.
- **name** name of the ruler.
- **euclidian** 1 for euclidian ruler, and 0 for regular ruler.

To remove a single ruler:

```
gui::delete_ruler name
```

Options description:

- **name** name of the ruler.

To remove all the rulers:

```
gui::clear_rulers
```

## Heat Maps

The currently available heat maps are:

- Power
- Routing
- Placement
- IRDrop
- RUDY<sup>1</sup>

To control the settings in the heat maps:

```
gui::set_heatmap name option
gui::set_heatmap name option value
```

<sup>1</sup> RUDY means Rectangular Uniform wire DensitY, which can predict the routing density very rough and quickly. You can see this notion in [this paper](#)

Options description:

- **name** is the name of the heatmap.
- **option** is the name of the option to modify. If option is **rebuild** the map will be destroyed and rebuilt.
- **value** is the new value for the specified option. This is not used when rebuilding map.

These options can also be modified in the GUI by double-clicking the underlined display control for the heat map.

To save the raw data from the heat maps in a comma separated value (CSV) format:

```
gui::dump_heatmap name filename
```

Options description:

- **name** is the name of the heatmap.
- **filename** path to the file to write the data to.

## GUI Display Controls

Control the visible and selected elements in the layout:

```
gui::set_display_controls name display_type value
```

Options description:

- **name** is the name of the control. For example, for the power nets option this would be **Signals/Power** or could be **Layers/\*** to set the option for all the layers.
- **display\_type** is either **visible** or **selectable**
- **value** is either **true** or **false**

To check the visibility or selectability of elements in the layout:

```
gui::check_display_controls name display_type
```

Options description:

- **name** is the name of the control. For example, for the power nets option this would be **Signals/Power** or could be **Layers/\*** to set the option for all the layers.
- **display\_type** is either **visible** or **selectable**

When performing a batch operation changing the display controls settings, the following commands can be used to save the current state of the display controls and restore them at the end.

```
gui::save_display_controls  
gui::restore_display_controls
```

## GUI Controls

To request user input via the GUI:

```
gui::input_dialog title question
```

Returns: a string with the input, or empty string if canceled.

Options description:

- **title** is the title of the input message box.
- **question** is the text for the message box.

Pause the execution of the script:

```
gui::pause  
gui::pause timeout
```

Options description:

- **timeout** is specified in milliseconds, if it is not provided the pause will last until the user presses the Continue button.

To open or close a specific layout widget:

```
gui::show_widget name  
gui::hide_widget name
```

Options description:

- **name** of the widget. For example, the display controls would be “Display Control”.

## License

BSD 3-Clause License. See LICENSE file.

---

## 5.2.8 Partition Manager

The partitioning module (**par**) is based on TritonPart, an open-source constraints-driven partitioner. **par** can be used to partition a hypergraph or a gate-level netlist.

## Highlights

- Start of the art multiple-constraints driven partitioning “multi-tool”
- Optimizes cost function based on user requirement
- Permissive open-source license
- Solves multi-way partitioning with following features:
  - Multidimensional real-value weights on vertices and hyperedges
  - Multilevel coarsening and refinement framework
  - Fixed vertices constraint

- Timing-driven partitioning framework
- Group constraint: Groups of vertices need to be in same block
- Embedding-aware partitioning

### Dependency

We use Google OR-Tools as our ILP solver.

Our recommendation is to follow the OpenROAD *DependencyInstaller* for installation of this requirement.

Alternatively, you may also install Google OR-Tools following these [instructions](#).

**Warning:** Due to a build issue, TritonPart is not supported for macOS. Stay tuned to this page for updates!

### Main Algorithm

An overview of the TritonPart algorithm is shown below. It takes as inputs

- Hypergraph  $H(V, E)$  in .hgr format.
- Vertex weight  $w_v \in \mathcal{R}_+^m$
- Hyperedge weight  $w_e \in \mathcal{R}_+^n$
- Number of blocks  $K$ .
- Imbalance factor  $\epsilon$ .
- User-specified cost function  $\phi$ .

There are five main steps in the main algorithm, mainly 1) constraints-driven coarsening, 2) initial partitioning, 3) refinement, 4) cut-overlay clustering and partitioning (COCP), and 5) V-cycle refinement. The steps for the timing-aware algorithm may be found in the next [section](#).

#### 1. Constraints-Driven Coarsening

The first step involves multilevel coarsening. Specifically, at each level, clusters of vertices are identified, and the merged and represented as a single vertex in the resulting coarser hypergraph. In this algorithm, the First-Choice scheme is used, which traverses the vertices in the hypergraph according to a given ordering and merges pairs of vertices with high connectivity. The connectivity between a pair of vertices  $(u, v)$  is measured as follows:

$$r(u, v) = \sum_{e \in \{I(v) \cap I(u)\}} \frac{\langle \alpha, w_e \rangle}{|e| - 1}$$

To efficiently manage multiple constraints, the following enhancements are made to the coarsening scheme above:

- **Fixed Vertex Constraint:** Fixed vertices that belong to the same partitioning block are merged into a single vertex.
- **Grouping Constraint:** Vertices that belong to the same group are merged into a single vertex.
- **Embedding Constraint:** The embedding information is incorporated into the heavy-edge rating function. The new connectivity is updated as follows:

$$\hat{r}(u, v) = r(u, v) + \rho \frac{1}{\|X_u - X_v\|_2}$$

where  $\rho$  is a normalization factor set to the average distance between two vertex embeddings. When vertices  $v_1, \dots, v_t$  are merged into a single vertex  $v_{coarse}$ , the corresponding vertex embedding  $X_{v_{coarse}}$  is defined as the *center of gravity* of  $t$  vertices:

$$X_{v_{coarse}} = \sum_{j=1}^t \frac{\|w_{v_j}\|}{M} X_{v_j}, \text{ where } M = \sum_{j=1}^t \|w_{v_j}\|$$

- **Community Guidance:** Only vertices within the same community are considered for merging.
- **Tie-breaking mechanism:** If multiple neighbor pairs have the same rating score, combine the lexicographically first unmatched vertex to break ties.

## 2. Initial Partitioning

After completing the coarsening process, an initial partitioning solution for the coarsest hypergraph  $H_c$  is derived. Two sub-steps are involved in this: the best partitioning solution from random and VILE partitioning is chosen from  $\eta = 50$  runs as a warm-start to the ILP-based partitioner. The optimization is based on only the cut size rather than the cost function  $\phi$  to keep the runtime reasonable.

## 3. Refinement

After a feasible solution  $H_{c_\xi}$  is obtained by initial partitioning, uncoarsening and move-based refinement is performed to improve the partitioning solution. Three refinement heuristics are applied in sequence:

- **K-way pairwise FM (PM):** This addresses multi-way partitioning as concurrent bi-partitioning problems in a restricted version of K-way Fiduccia–Mattheyses (FM) algorithm. First,  $\lfloor K/2 \rfloor$  pairs of blocks are obtained, with refinement-specific vertex movements restricted to associated paired blocks. Next, two-way FM is concurrently performed on all the block pairs. Finally, a new configuration of block pairs is computed at the end of the PM.
- **Direct K-way FM:** Using  $K$  priority queues, for each block  $V_i$ , establish a priority queue that stores the vertices that can be potentially moved from the current block to block  $V_i$ . This queue is ordered according to the gain of the vertices. Gain is defined as the reduction in cost function from the movement of the vertex from the current block to  $V_i$ . Next, after a vertex move, each priority queue is updated independently, thus enabling parallel updates via multi-threading. Next, early-stop is implemented by limiting the maximum number of vertices moved to 100 per pass. Finally, the *corking effect* is mitigated by traversing the priority queue belonging to the vertex with the highest gain and identifying a feasible vertex move.
- **Greedy Hyperedge Refinement (HER):** First, randomly visit all hyperedges. For each hyperedge  $e$  that crosses the partition boundary, determine whether a subset of vertices in  $e$  can be moved without violating the multi-dimensional balance constraints. The objective is to make  $e$  entirely constrained in a block.

## 4. Cut-Overlay Clustering and Partitioning (COCP)

Cut-overlay Clustering and Partitioning (COCP) is a mechanism to combine multiple good-quality partitioning solutions to generate an improved solution. To begin, the sets of hyperedges cut in the  $\theta$  candidate solutions are denoted as  $E_1, \dots, E_\theta \subset E$ . First,  $\cup_{i=1}^\theta E_i$  is removed from the hypergraph  $H(V, E)$ , resulting in a number of connected components. Next, all vertices within each connected component are merged to form a coarser hypergraph  $H_{overlay}$ . If the number of vertices in  $H_{overlay}$  is less than  $thr_{ilp}$ , ILP-based partitioning is performed. If not, a single round of constraints-driven coarsening is conducted to further reduce the size of  $H_{overlay}$  and generate a coarser hypergraph  $H'_{overlay}$ . Finally, multilevel refinement is performed to further improve the partitioning solution at each level of the hierarchy and return the improved solution  $S'$ .

## 5. V-Cycle Refinement

Cut-overlay clustering and partitioning produces a high-quality partitioning solution  $S'$ . To improve it, there are three phases similar to *hMETIS*, namely multilevel coarsening, ILP-based partitioning, and refinement. Firstly, in multilevel partitioning,  $S'$  is used as a community guidance for the constraints-driven coarsening. Only vertices within the same block are permitted to be merged to ensure that the current solution  $S'$  is preserved in the coarsest hypergraph  $H_{c_\xi}$ . In the ILP-based partitioning phase, if the number of vertices in  $H_{c_\xi}$  does not exceed  $thr_{ilp}$ , run ILP-based partitioning to

improve  $S'$ . Otherwise, continue with  $S'$  in successive iterations of these two steps (default set to 2). The refinement phase is conducted as per step 3.

TritonPart algorithm at a glance

## Timing Aware Algorithm

par can also be used as a timing-aware partitioning framework. A slack propagation methodology is used that optimizes cuts for both timing-critical and timing-noncritical paths.

### 1. Extraction of Timing Paths and Slack Information

First, the top  $P$  timing-critical paths and the slack information of each hyperedge using the wireload model (WLM) is obtained from *OpenSTA*. The timing cost of each path is then calculated:

$$t_p = \left(1 - \frac{\text{slack}_p - \Delta}{\text{clock\_period}}\right)^\mu$$

where a fixed extra delay  $\Delta$  is introduced for timing guardband, and  $\mu$  (default 2) is the exponent.

The snaking factor of a path  $SF(p)$  is defined as the maximum number of block reentries along the path  $p$ . The timing cost of a hyperedge is computed using the timing weight corresponding to hyperedge slack  $\text{slack}_e$  and the accumulated timing cost of all paths traversing the hyperedge.

$$t_e = \left(1 - \frac{\text{slack}_e - \Delta}{\text{clock\_period}}\right)^\mu + \sum_{\{p|e \in p\}} t_p$$

### 2. Timing-aware Coarsening

The timing-aware feature is achieved by adding a timing cost of hyperedge  $t_e$  to the connectivity score earlier mentioned. If vertices  $(u, v)$  are associated with multiple critical paths, then they are more likely to be merged. This is reflected in the update score function:

$$r_t(u, v) = \hat{r}(u, v) + \sum_{e \in \{I(v) \cap I(u)\}} \frac{\beta t_e}{|e| - 1}$$

### 3. Timing-aware Refinement

Timing-aware refinement is based on a similar cost function as the main algorithm. Instead, an additional slack propagation step is performed at the end of each PM/FM/HER pass.

## Commands

---

### Note:

- Parameters in square brackets [-param param] are optional.
  - Parameters without square brackets -param2 param2 are required.
-

## Partition Netlist

```

triton_part_hypergraph
  -hypergraph_file hypergraph_file
  -num_parts num_parts
  -balance_constraint balance_constraint
  [-base_balance base_balance]
  [-seed seed]
  [-vertex_dimension vertex_dimension]
  [-hyperedge_dimension hyperedge_dimension]
  [-placement_dimension placement_dimension]
  [-fixed_file fixed_file]
  [-community_file community_file]
  [-group_file group_file]
  [-placement_file placement_file]
  [-e_wt_factors e_wt_factors]
  [-v_wt_factors <v_wt_factors>]
  [-placement_wt_factors <placement_wt_factors>]
  [-thr_coarsen_hyperedge_size_skip thr_coarsen_hyperedge_size_skip]
  [-thr_coarsen_vertices thr_coarsen_vertices]
  [-thr_coarsen_hyperedges thr_coarsen_hyperedges]
  [-coarsening_ratio coarsening_ratio]
  [-max_coarsen_iters max_coarsen_iters]
  [-adj_diff_ratio adj_diff_ratio]
  [-min_num_vertices_each_part min_num_vertices_each_part]
  [-num_initial_solutions num_initial_solutions]
  [-num_best_initial_solutions num_best_initial_solutions]
  [-refiner_iters refiner_iters]
  [-max_moves max_moves]
  [-early_stop_ratio early_stop_ratio]
  [-total_corking_passes total_corking_passes]
  [-v_cycle_flag v_cycle_flag]
  [-max_num_vcycle max_num_vcycle]
  [-num_coarsen_solutions num_coarsen_solutions]
  [-num_vertices_threshold_ilp num_vertices_threshold_ilp]
  [-global_net_threshold global_net_threshold]

```

## Options

Switch Name	Description
-num_parts	Number of partitions. The default value is 2, and the allowed values are integers [0, MAX_NUM_PARTS].
-balance_constraint	Allowed imbalance between blocks. The default value is 1.0, and the allowed values are floating-point numbers.
-base_balance	Tcl list of baseline imbalance between partitions. The default value is {1.0}, and the allowed values are lists of floating-point numbers.
-seed	Random seed. The default value is 0, and the allowed values are integers [-MAX_INT, MAX_INT].
-vertex_dimension	Number of vertices in the hypergraph. The default value is 1, and the allowed values are integers.
-hyperedge_dimension	Number of hyperedges in hypergraph. The default value is 1, and the allowed values are integers.
-placement_dimension	Number of dimensions for canvas if placement information is provided. The default value is 1.
-hypergraph_file	Path to hypergraph file.
-fixed_file	Path to fixed vertices constraint file.
-community_file	Path to community attributes file to guide the partitioning process.

Table 1 – continued from

Switch Name	Description
-group_file	Path to stay together attributes file.
-placement_file	Placement information file, each line corresponds to a group fixed vertices, community, a
-e_wt_factors	Hyperedge weight factor.
-v_wt_factors	Vertex weight factors.
-placement_wt_factors	Placement weight factors.
-thr_coarsen_hyperedge_size_skip	Threshold for ignoring large hyperedge (default 200, integer).
-thr_coarsen_vertices	Number of vertices of coarsest hypergraph (default 10, integer).
-thr_coarsen_hyperedges	Number of vertices of coarsest hypergraph (default 50, integer).
-coarsening_ratio	Coarsening ratio of two adjacent hypergraphs (default 1.6, float).
-max_coarsen_iters	Number of iterations (default 30, integer).
-adj_diff_ratio	Minimum difference of two adjacent hypergraphs (default 0.0001, float).
-min_num_vertices_each_part	Minimum number of vertices in each partition (default 4, integer).
-num_initial_solutions	Number of initial solutions (default 50, integer).
-num_best_initial_solutions	Number of top initial solutions to filter out (default 10, integer).
-refiner_iters	Refinement iterations (default 10, integer).
-max_moves	The allowed moves for each Fiduccia-Mattheyses (FM) algorithm pass or greedy refinement.
-early_stop_ratio	Describes the ratio $e$ where if the $n_{movedvertices} > n_{vertices} * e$ , the tool exits the current pass.
-total_corking_passes	Maximum level of traversing the buckets to solve the “corking effect” (default 25, integer).
-v_cycle_flag	Disables v-cycle is used to refine partitions (default true, bool).
-max_num_vcycle	Maximum number of vcycles (default 1, integer).
-num_coarsen_solutions	Number of coarsening solutions with different randoms seed (default 3, integer).
-num_vertices_threshold_ilp	Describes threshold $t$ , the number of vertices used for integer linear programming (ILP) partitioning.
-global_net_threshold	If the net is larger than this, it will be ignored by TritonPart (default 1000, integer).

## Evaluate Hypergraph Partition

```
evaluate_hypergraph_solution
  -num_parts num_parts
  -balance_constraint balance_constraint
  -hypergraph_file hypergraph_file
  -solution_file solution_file
  [-base_balance base_balance]
  [-vertex_dimension vertex_dimension]
  [-hyperedge_dimension hyperedge_dimension]
  [-fixed_file fixed_file]
  [-group_file group_file]
  [-e_wt_factors e_wt_factors]
  [-v_wt_factors v_wt_factors]
```

## Options

Switch Name	Description
-num_parts	Number of partitions. The default value is 2, and the allowed values are integers [0, MAX_INT].
-balance_constraint	Allowed imbalance between blocks. The default value is 1.0, and the allowed values are floats.
-vertex_dimension	Number of vertices in the hypergraph. The default value is 1, and the allowed values are integers [0, MAX_INT].
-hyperedge_dimension	Number of hyperedges in hypergraph. The default value is 1, and the allowed values are integers [0, MAX_INT].
-hypergraph_file	Path to hypergraph file.
-solution_file	Path to solution file.
-base_balance	Tcl list of baseline imbalance between partitions. The default value is {1.0}, and the allowed values are floats that sum up to 1.0.
-fixed_file	Path to fixed vertices constraint file.
-group_file	Path to stay together attributes file.
-e_wt_factors	Hyperedge weight factor.
-v_wt_factors	Vertex weight factor.

## Partition Netlist

```
triton_part_design
  [-num_parts num_parts]
  [-balance_constraint balance_constraint]
  [-base_balance base_balance]
  [-seed seed]
  [-timing_aware_flag timing_aware_flag]
  [-top_n top_n]
  [-placement_flag placement_flag]
  [-fence_flag fence_flag]
  [-fence_lx fence_lx]
  [-fence_ly fence_ly]
  [-fence_ux fence_ux]
  [-fence_uy fence_uy]
  [-fixed_file fixed_file]
  [-community_file community_file]
  [-group_file group_file]
  [-solution_file solution_file]
  [-net_timing_factor net_timing_factor]
  [-path_timing_factor path_timing_factor]
  [-path_snaking_factor path_snaking_factor]
  [-timing_exp_factor timing_exp_factor]
  [-extra_delay extra_delay]
  [-guardband_flag guardband_flag]
  [-e_wt_factors e_wt_factors]
  [-v_wt_factors v_wt_factors]
  [-placement_wt_factors placement_wt_factors]
  [-thr_coarsen_hyperedge_size_skip thr_coarsen_hyperedge_size_skip]
  [-thr_coarsen_vertices thr_coarsen_vertices]
```

(continues on next page)

(continued from previous page)

```

[-thr_coarsen_hyperedges thr_coarsen_hyperedges]
[-coarsening_ratio coarsening_ratio]
[-max_coarsen_iters max_coarsen_iters]
[-adj_diff_ratio adj_diff_ratio]
[-min_num_vertices_each_part min_num_vertices_each_part]
[-num_initial_solutions num_initial_solutions]
[-num_best_initial_solutions num_best_initial_solutions]
[-refiner_iters refiner_iters]
[-max_moves max_moves]
[-early_stop_ratio early_stop_ratio]
[-total_corking_passes total_corking_passes]
[-v_cycle_flag v_cycle_flag ]
[-max_num_vcycle max_num_vcycle]
[-num_coarsen_solutions num_coarsen_solutions]
[-num_vertices_threshold_ilp num_vertices_threshold_ilp]
[-global_net_threshold global_net_threshold]

```

## Options

Switch Name	Description
-num_parts	Number of partitions. The default value is 2, and the allowed values are integers [0, MAX_PARTS].
-balance_constraint	Allowed imbalance between blocks. The default value is 1.0, and the allowed values are floats.
-base_balance	Tcl list of baseline imbalance between partitions. The default value is {1.0}, and the allowed values are lists.
-seed	Random seed. The default value is 1, and the allowed values are integers [-MAX_INT, MAX_INT].
-timing_aware_flag	Enable timing-driven mode. The default value is true, and the allowed values are booleans.
-top_n	Extract the top n critical timing paths. The default value is 1000, and the allowed values are integers.
-placement_flag	Enable placement driven partitioning. The default value is false, and the allowed values are booleans.
-fence_flag	Consider fences in the partitioning. The default value is false, and the allowed values are booleans.
-fence_lx	Fence lower left x in microns. The default value is 0.0, and the allowed values are floats.
-fence_ly	Fence lower left y in microns. The default value is 0.0, and the allowed values are floats.
-fence_ux	Fence upper right x in microns. The default value is 0.0, and the allowed values are floats.
-fence_uy	Fence upper right y in microns. The default value is 0.0, and the allowed values are floats.
-fixed_file	Path to fixed vertices constraint file.
-community_file	Path to community attributes file to guide the partitioning process.
-group_file	Path to stay together attributes file.
-solution_file	Path to solution file.
-net_timing_factor	Hyperedge timing weight factor (default 1.0, float).
-path_timing_factor	Cutting critical timing path weight factor (default 1.0, float).
-path_snaking_factor	Snaking a critical path weight factor (default 1.0, float).
-timing_exp_factor	Timing exponential factor for normalized slack (default 1.0, float).
-extra_delay	Extra delay introduced by a cut (default 1e-9, float).
-guardband_flag	Enable timing guardband option (default false, bool).
-e_wt_factors	Hyperedge weight factor.
-v_wt_factors	Vertex weight factor.
-placement_wt_factors	Placement weight factor.
-thr_coarsen_hyperedge_size_skip	Threshold for ignoring large hyperedge. The default value is 1000, and the allowed values are integers.
-thr_coarsen_vertices	Number of vertices of coarsest hypergraph. The default value is 10, and the allowed values are integers.
-thr_coarsen_hyperedges	Number of vertices of the coarsest hypergraph. The default value is 50, and the allowed values are integers.

Table 2

Switch Name	Description
-coarsening_ratio	Coarsening ratio of two adjacent hypergraphs. The default value is 1.5, and the allowed values are integers [0, M].
-max_coarsen_iters	Number of iterations. The default value is 30, and the allowed values are integers [0, M].
-adj_diff_ratio	Minimum ratio difference of two adjacent hypergraphs. The default value is 0.0001, and the allowed values are floats [0.0001, 1.0].
-min_num_vertices_each_part	Minimum number of vertices in each partition. The default value is 4, and the allowed values are integers [1, M].
-num_initial_solutions	Number of initial solutions. The default value is 100, and the allowed values are integers [1, M].
-num_best_initial_solutions	Number of top initial solutions to filter out. The default value is 10, and the allowed values are integers [1, M].
-refiner_iters	Refinement iterations. The default value is 10, and the allowed values are integers [0, M].
-max_moves	The allowed moves for each Fiduccia-Mattheyses (FM) algorithm pass or greedy refinement.
-early_stop_ratio	Describes the ratio $e$ where if the $n_{movedvertices} > n_{vertices} * e$ , the tool exists the current pass.
-total_corking_passes	Maximum level of traversing the buckets to solve the “corking effect”. The default value is 100, and the allowed values are integers [1, M].
-v_cycle_flag	Disables v-cycle is used to refine partitions. The default value is true, and the allowed values are boolean [true, false].
-max_num_vcycle	Maximum number of vcycles. The default value is 1, and the allowed values are integers [1, M].
-num_coarsen_solutions	Number of coarsening solutions with different randoms seed. The default value is 4, and the allowed values are integers [1, M].
-num_vertices_threshold_ilp	Describes threshold $t$ , the number of vertices used for integer linear programming (ILP) problem.
-global_net_threshold	If the net is larger than this, it will be ignored by TritonPart. The default value is 1000, and the allowed values are integers [1, M].

## Evaluation Netlist Partition

```

evaluate_part_design_solution
  [-num_parts num_parts]
  [-balance_constraint balance_constraint]
  [-base_balance base_balance]
  [-timing_aware_flag timing_aware_flag]
  [-top_n top_n]
  [-fence_flag fence_flag]
  [-fence_lx fence_lx]
  [-fence_ly fence_ly]
  [-fence_ux fence_ux]
  [-fence_uy fence_uy]
  [-fixed_file fixed_file]
  [-community_file community_file]
  [-group_file group_file]
  [-hypergraph_file hypergraph_file]
  [-hypergraph_int_weight_file hypergraph_int_weight_file]
  [-solution_file solution_file]
  [-net_timing_factor net_timing_factor]
  [-path_timing_factor path_timing_factor]
  [-path_snaking_factor path_snaking_factor]
  [-timing_exp_factor timing_exp_factor]
  [-extra_delay extra_delay]
  [-guardband_flag guardband_flag]
  [-e_wt_factors e_wt_factors]
  [-v_wt_factors v_wt_factors]

```

## Options

Switch Name	Description
<code>-num_parts</code>	Number of partitions. The default value is 2, and the allowed values are integers [0, MAX_INT].
<code>-balance_constraint</code>	Allowed imbalance between blocks. The default value is 1.0, and the allowed values are floats.
<code>-base_balance</code>	Tcl list of baseline imbalance between partitions. The default value is {1.0}, and the allowed values are floats that sum up to 1.0.
<code>-timing_aware_flag</code>	Enable timing-driven mode. The default value is true, and the allowed values are booleans.
<code>-top_n</code>	Extract the top n critical timing paths. The default value is 1000, and the allowed values are integers [0, MAX_INT].
<code>-fence_flag</code>	Consider fences in the partitioning. The default value is false, and the allowed values are booleans.
<code>-fence_lx</code>	Fence lower left x in microns. The default value is 0.0, and the allowed values are floats.
<code>-fence_ly</code>	Fence lower left y in microns. The default value is 0.0, and the allowed values are floats.
<code>-fence_ux</code>	Fence upper right x in microns. The default value is 0.0, and the allowed values are floats.
<code>-fence_uy</code>	Fence upper right y in microns. The default value is 0.0, and the allowed values are floats.
<code>-fixed_file</code>	Path to fixed vertices constraint file.
<code>-community_file</code>	Path to community attributes file to guide the partitioning process.
<code>-group_file</code>	Path to stay together attributes file.
<code>-hypergraph_file</code>	Path to hypergraph file.
<code>-hypergraph_int_weight</code>	Path to METIS format integer weight file.
<code>-solution_file</code>	Path to solution file.
<code>-net_timing_factor</code>	Hyperedge timing weight factor. The default value is 1.0, and the allowed values are floats.
<code>-path_timing_factor</code>	Cutting critical timing path weight factor. The default value is 1.0, and the allowed values are floats.
<code>-path_snaking_factor</code>	Snaking a critical path weight factor. The default value is 1.0, and the allowed values are floats.
<code>-timing_exp_factor</code>	Timing exponential factor for normalized slack. The default value is 1.0, and the allowed values are floats.
<code>-extra_delay</code>	Extra delay introduced by a cut. The default value is 1e-9, and the allowed values are floats.
<code>-guardband_flag</code>	Enable timing guardband option. The default value is false, and the allowed values are booleans.
<code>-e_wt_factors</code>	Hyperedge weight factors.
<code>-v_wt_factors</code>	Vertex weight factors.

## Write Partition to Verilog

```
write_partition_verilog
  [-port_prefix prefix]
  [-module_suffix suffix]
  [file]
```

### Options

Switch Name	Description
-port_prefix	Port name prefix.
-module_suffix	Module name suffix.
file	Filename to write partition verilog to.

## Read the Partition file

```
read_partitioning
  -read_file name
  [-instance_map_file file_path]

## Example Scripts

### How to partition a hypergraph in the way you would using hMETIS (min-cut
partitioning)

```tcl
triton_part_hypergraph -hypergraph_file des90.hgr -num_parts 5 -balance_constraint 2 -
seed 2
```

You can also check the provided example here.

## How to perform the embedding-aware partitioning

```
set num_parts 2
set balance_constraint 2
set seed 0
set design sparcT1_chip2
set hypergraph_file "${design}.hgr"
set placement_file "${design}.hgr.ubfactor.2.numparts.2.embedding.dat"
set solution_file "${design}.hgr.part.${num_parts}"

triton_part_hypergraph -hypergraph_file $hypergraph_file -num_parts $num_parts \
  -balance_constraint $balance_constraint \
  -seed $seed \
  -placement_file ${placement_file} -placement_wt_factors { 0.
  00005 0.00005 } \
```

(continues on next page)

(continued from previous page)

```
-placement_dimension 2
```

You can find the provided example here.

## How to partition a netlist

```
# set technology information
set ALL_LEFS "list_of_lefs"
set ALL_LIBS "list_of_libs"
# set design information
set design "design_name"
set top_design "top_design"
set netlist "netlist.v"
set sdc "timing.sdc"
foreach lef_file ${ALL_LEFS} {
    read_lef $lef_file
}
foreach lib_file ${ALL_LIBS} {
    read_lib $lib_file
}
read_verilog $netlist
link_design $top_design
read_sdc $sdc

set num_parts 5
set balance_constraint 2
set seed 0
set top_n 100000
# set the extra_delay_cut to 20% of the clock period
# the extra_delay_cut is introduced for each cut hyperedge
set extra_delay_cut 9.2e-10
set timing_aware_flag true
set timing_guardband true
set part_design_solution_file "${design}_part_design.hgr.part.${num_parts}"

#####
## TritonPart with slack propagation
#####
puts "Start TritonPart with slack propagation"
# call triton_part to partition the netlist
triton_part_design -num_parts $num_parts -balance_constraint $balance_constraint \
    -seed $seed -top_n $top_n \
    -timing_aware_flag $timing_aware_flag -extra_delay $extra_delay_cut \
    -guardband_flag $timing_guardband \
    -solution_file $part_design_solution_file
```

You can find the provided example here.

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## References

1. Bustany, I., Kahng, A. B., Koutis, I., Pramanik, B., & Wang, Z. (2023). K-SpecPart: A Supervised Spectral Framework for Multi-Way Hypergraph Partitioning Solution Improvement. arXiv preprint arXiv:2305.06167. ([.pdf](#))
2. Bustany, I., Gasparian, G., Kahng, A. B., Koutis, I., Pramanik, B., & Wang, Z. (2023). “An Open-Source Constraints-Driven General Partitioning Multi-Tool for VLSI Physical Design”, Proc. ACM/IEEE International Conference of Computer-Aided Design 2023, ([.pdf](#)).

## License

BSD 3-Clause License. See LICENSE file.

### 5.2.9 Restructure

The restructure module in OpenROAD (`rmp`) is based on an interface to ABC for local resynthesis. The package allows logic restructuring that targets area or timing. It extracts a cloud of logic using the OpenSTA timing engine, and passes it to ABC through `blif` interface. Multiple recipes for area or timing are run to obtain multiple structures from ABC; the most desirable among these is used to improve the netlist. The ABC output is read back by a `blif` reader which is integrated to OpenDB. `blif` writer and reader also support constants from and to OpenDB. Reading back of constants requires insertion of tie cells which should be provided by the user as per the interface described below.

## Commands

---

### Note:

- Parameters in square brackets `[-param param]` are optional.
  - Parameters without square brackets `-param2 param2` are required.
- 

Restructuring can be done in two modes: area or delay.

**Area Mode**

```
restructure
  -liberty_file liberty_file
  -target area
  -tielo_pin  tielo_pin_name
  -tiehi_pin  tiehi_pin_name
  -work_dir   workdir_name
```

**Timing Mode**

```
restructure
  -liberty_file liberty_file
  -target timing
  -slack_threshold slack_val
  -depth_threshold depth_threshold
  -tielo_pin  tielo_pin_name
  -tiehi_pin  tiehi_pin_name
  -work_dir   workdir_name
```

**Options**

Switch Name	Description
-liberty_file	Liberty file with description of cells used in design. This is passed to ABC.
-target	Either area or delay. In area mode, the focus is area reduction, and timing may degrade. In delay mode, delay is likely reduced, but the area may increase. The default value is area.
-slack_threshold	Specifies a (setup) timing slack value below which timing paths need to be analyzed for restructuring. The default value is 0, and the allowed values are floats [0, MAX_FLOAT].
-depth_threshold	Specifies the path depth above which a timing path would be considered for restructuring. The default value is 16, and the allowed values are [0, MAX_INT].
-tielo_pin	Tie cell pin that can drive constant zero. The format is <cell>/<port>.
-tiehi_pin	Tie cell pin that can drive constant one. The format is <cell>/<port>.
-work_dir	Name of the working directory for temporary files. If not provided, run directory would be used.

**Example scripts**

Example scripts on running rmp for a sample design of gcd as follows:

```
./test/gcd_restructure.tcl
```

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

## FAQs

Check out [GitHub discussion](#) about this tool.

## Authors

- Sanjiv Mathur
- Ahmad El Rouby

## License

BSD 3-Clause License. See *LICENSE* file.

### 5.2.10 Initialize Floorplan

This tool initializes floorplan constraints, die/core area, and makes tracks.

#### Commands

---

##### Note:

- Parameters in square brackets `[-param param]` are optional.
  - Parameters without square brackets `-param2 param2` are required.
- 

#### Initialize Floorplan

Do note that there are two ways of setting the floorplan dimensions. The user can either specify manually die/core area, or specify the utilization/aspect ratio.

**Method 1: Automatic die size calculation**

```
initialize_floorplan
[-utilization util]
[-aspect_ratio ratio]
[-core_space space | {bottom top left right}]
[-sites site_name]
```

**Options**

Switch Name	Description
-utilization	Percentage utilization. Allowed values are double >0, more than 100% utilization can be useful with mock abstracts.
-aspect_ratio	$\frac{height}{width}$ . The default value is 1.0 and the allowed values are floats [0, 1.0].
-core_space	Space around the core, default 0.0 microns. Allowed values are either one value for all margins or a set of four values, one for each margin. The order of the four values are: {bottom top left right}.
-sites	Tcl list of sites to make rows for (e.g. {SITEXX, SITEYY})

**Method 2: Set die/core area**

```
initialize_floorplan
[-die_area {llx lly urx ury}]
[-core_area {llx lly urx ury}]
[-additional_sites site_names]
-site site_name
```

**Options**

Switch Name	Description
-die_area	Die area coordinates in microns (lower left x/y and upper right x/y coordinates).
-core_area	Core area coordinates in microns (lower left x/y and upper right x/y coordinates).
-site	The LEF site to make rows for.
-additional_sites	Any additional LEF site to make rows.

The die area and core area used to write ROWs can be specified explicitly with the -die\_area and -core\_area arguments. Alternatively, the die and core areas can be computed from the design size and utilization as shown below:

The -site argument determines the basic single-height rows to make. For a hybrid row design the site should have a row pattern. Any sites referenced by an instance in the netlist will also have rows constructed for them.

Additional sites are specified if you wish to have rows for a site that is not used in the netlist but may be needed later. For example, you might not have any double height cells in the incoming netlist but you expect some to be generated by flop clustering later in the flow.

Example computation:

```

core_area = design_area / (utilization / 100)
core_width = sqrt(core_area / aspect_ratio)
core_height = core_width * aspect_ratio
core = ( core_space_left, core_space_bottom )
    ( core_space_left + core_width, core_space_bottom + core_height )
die = ( 0, 0 )
( core_width + core_space_left + core_space_right,
  core_height + core_space_bottom + core_space_top )

```

## Make Tracks

The `initialize_floorplan` command removes existing tracks.

Use the `make_tracks` command to add routing tracks to a floorplan.

```

make_tracks
[layer]
[-x_pitch x_pitch]
[-y_pitch y_pitch]
[-x_offset x_offset]
[-y_offset y_offset]

```

## Options

Switch Name	Description
<code>layer</code>	Select layer name to make tracks for. Defaults to all layers.
<code>-x_pitch, -y_pitch</code>	If set, overrides the LEF technology x-/y- pitch. Use the same unit as in the LEF file.
<code>-x_offset, -y_offset</code>	If set, overrides the LEF technology x-/y- offset. Use the same unit as in the LEF file.

## Inserting tieoff cells

To insert tiecells:

```

insert_tiecells
tie_pin
[-prefix inst_prefix]

```

## Options

Switch Name	Description
<code>tie_pin</code>	Indicates the master and port to use to tie off nets. For example, LOGIC0_X1/Z for the Nangate45 library, where LOGIC0_X1 is the master and Z is the output port on the master.
<code>-prefix</code>	Used to control the prefix of the new tiecell names. This will default to TIEOFF_.

## Useful developer functions

If you are a developer, you might find these useful. More details can be found in the source file or the *swig file*.

Command Name	Description
<code>microns_to_mfg_grid</code>	Convert microns to manufacturing grid DBU.

## Example scripts

Example scripts on running `ifp` for a sample design of `mpd_top` are as follows:

```
./test/upf_test.tcl
```

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

## FAQs

Check out [GitHub discussion](#) about this tool.

## License

BSD 3-Clause License. See *LICENSE* file.

### 5.2.11 Pin Placer

Place pins on the boundary of the die on the track grid to minimize net wirelengths. Pin placement also creates a metal shape for each pin using min-area rules.

For designs with unplaced cells, the net wirelength is computed considering the center of the die area as the unplaced cells position.

## Commands

---

### Note:

- Parameters in square brackets `[-param param]` are optional.
  - Parameters without square brackets `-param2 param2` are required.
-

## Define Pin Shape Pattern

The `define_pin_shape_pattern` command defines a pin placement grid on the specified layer. This grid has positions inside the die area, not only at the edges of the die boundary.

```
define_pin_shape_pattern
  [-layer layer]
  [-x_step x_step]
  [-y_step y_step]
  [-region {llx lly urx ury} | *]
  [-size {width height}]
  [-pin_keepout dist]
```

### Options

Switch Name	Description
<code>-layer</code>	The single top-most routing layer of the placement grid.
<code>-x_step</code> , <code>-y_step</code>	The distance (in microns) between each valid position on the grid in the x- and y-directions, respectively.
<code>-region</code>	The <code>{llx, lly, urx, ury}</code> region of the placement grid (in microns). If the <code>*</code> is specified, the region will be the entire die area.
<code>-size</code>	The width and height (in microns) of the pins assigned to this grid. The centers of the pins are placed on the grid positions. Pins may have half of their shapes outside the defined region.
<code>-pin_keepout</code>	The boundary (in microns) around existing routing obstructions that the pins should avoid; this defaults to the <code>layer</code> minimum spacing.

## Face-to-Face direct-bonding IOs

The `define_pin_shape_pattern` command can be used to place pins in any metal layer with the minimum allowed spacing to facilitate 3DIC integration of chips using face-to-face packaging technologies. These technologies include micro bumps and [hybrid bonding](#) for high density face-to-face interconnect.

### Set IO Pin Constraint

The `set_io_pin_constraint` command sets region constraints for pins according to the pin direction or the pin name. This command can be called multiple times with different constraints.

You can use the `set_io_pin_constraint` command to restrict pins to the pin placement grid created with the `define_pin_shape_pattern` command.

It is possible to use the `-region`, `-group` and `-order` arguments together per `set_io_pin_constraint` call, but the `-mirrored_pins` argument should be called alone.

```
set_io_pin_constraint
  [-direction direction]
  [-pin_names names]
  [-region edge:interval]
  [-mirrored_pins names]
```

(continues on next page)

(continued from previous page)

<code>[-group]</code>
<code>[-order]</code>

## Options

Switch Name	Description
<code>-direction</code>	<code>Pin direction (input, output, inout, or feedthrough).</code>
<code>-pin_names</code>	<code>Names of names.</code> Only one of ( <code>-direction</code> , <code>-pin_names</code> ) should be used in a single call for the <code>set_io_pin_constraint</code> command.
<code>-region</code>	Syntax is <code>-region edge:interval</code> . The edge values are ( <code>top bottom left right</code> ). The interval can be the whole edge with the wildcard <code>*</code> value or a range of values.
<code>-mirrored_pins</code>	<code>Set pins that sets pairs of pins that will be symmetrically placed in the vertical or the horizontal edges.</code> The number of pins in this list <b>must be even</b> . For example, in <code>set_io_pin_constraint -mirrored_pins {pin1 pin2 pin3 pin4 pin5 pin6}</code> , the pins pin1 and pin2 will be placed symmetrically to each other. Same for pin3 and pin4, and for pin5 and pin6.
<code>-group</code>	Flag places together on the die boundary the pin list defined in <code>-pin_names</code> , similar to the <code>-group_pins</code> option on the <code>place_pins</code> command.
<code>-order</code>	Flag places the pins ordered in ascending x/y position and must be used only when <code>-group</code> is also used.

The edge values are (up, top, bottom, left, right), where up is the grid created by `define_pin_shape_pattern`. To restrict pins to the pin placement grid defined with `define_pin_shape_pattern` use:

- `-region up:{llx lly urx ury}` to restrict the pins into a specific region in the grid. The region is defined in microns.
- `-region up:*` to restrict the pins into the entire region of the grid.

The up option is only available when the pin placement grid is created with the `define_pin_shape_pattern` command.

## Clear IO Pin Constraints

The `clear_io_pin_constraints` command clears all the previously-defined constraints and pin shape patterns created with `set_io_pin_constraint` or `define_pin_shape_pattern`.

<code>clear_io_pin_constraints</code>
---------------------------------------

## Set Pin Length

The `set_pin_length` command defines the length of all vertical and horizontal pins.

<code>set_pin_length</code>
<code>  [-hor_length h_length]</code>
<code>  [-ver_length v_length]</code>

## Options

Switch Name	Description
-hor_length	The length (in microns) of the horizontal pins.
-ver_length	The length (in microns) of the vertical pins.

## Set Pin Extension

The `set_pin_length_extension` command defines the an extension of the length of all vertical and horizontal pins. Note that this command may generate pins partially outside the die area.

```
set_pin_length_extension
  [-hor_extension h_extension]
  [-ver_extension v_extension]
```

## Options

Switch Name	Description
-hor_extension	The length (in microns) for the horizontal pins.
-ver_extension	The length (in microns) for the vertical pins.

## Set Pin Thick Multiplier

The `set_pin_thick_multiplier` command defines a multiplier for the thickness of all vertical and horizontal pins.

```
set_pin_thick_multiplier
  [-hor_multiplier h_mult]
  [-ver_multiplier v_mult]
```

## Options

Switch Name	Description
-hor_multiplier	The thickness multiplier for the horizontal pins.
-ver_multiplier	The thickness multiplier for the vertical pins.

## Set Simulated Annealing Parameters

The `set_simulated_annealing` command defines the parameters for simulated annealing pin placement.

```
set_simulated_annealing
  [-temperature temperature]
  [-max_iterations iter]
  [-perturb_per_iter perturbs]
  [-alpha alpha]
```

## Options

Switch Name	Description
-temperature	Temperature parameter. The default value is <code>1.0</code> , and the allowed values are floats [ <code>0</code> , <code>MAX_FLOAT</code> ].
-max_iterations	The maximum number of iterations. The default value is <code>2000</code> , and the allowed values are integers [ <code>0</code> , <code>MAX_INT</code> ].
-perturb_per_ite	The number of perturbations per iteration. The default value is <code>0</code> , and the allowed values are integers [ <code>0</code> , <code>MAX_INT</code> ].
-alpha	The temperature decay factor. The default value is <code>0.985</code> , and the allowed values are floats ( <code>0</code> , <code>1</code> ).

## Place Individual Pin

The `place_pin` command places a specific pin in the specified location with the specified size. It is recommended that individual pins be placed before the `place_pins` command, as the routing tracks occupied by these individual pins will be blocked, preventing overlaps.

To place an individual pin:

```
place_pin
  -pin_name pin_name
  -layer layer
  -location {x y}
  [-pin_size {width height}]
  [-force_to_die_boundary]
```

## Options

Switch Name	Description
-pin_name	The name of a pin of the design.
-layer	The routing layer where the pin is placed.
-location	The center of the pin (in microns).
-pin_size	The width and height of the pin (in microns).
-force_to_die_boundary	When this flag is enabled, the pin will be snapped to the nearest routing track, next to the die boundary.

## Place All Pins

Use the following command to perform pin placement:

```
place_pins
  -hor_layers h_layers
  -ver_layers v_layers
  [-random_seed seed]
  [-random]
  [-corner_avoidance length]
  [-min_distance distance]
```

(continues on next page)

(continued from previous page)

<code>[-min_distance_in_tracks]</code>
<code>[-exclude region]</code>
<code>[-group_pins pin_list]</code>
<code>[-annealing]</code>
<code>[-write_pin_placement file_name]</code>

## Options

Switch Name	Description
<code>-hor_layers</code>	The layers to create the metal shapes of pins placed in horizontal tracks. It can be a single layer or a list of layer names.
<code>-ver_layers</code>	The layers to create the metal shapes of pins placed in vertical tracks. It can be a single layer or a list of layer names.
<code>-corner_avoidance</code>	The distance (in microns) from each corner within which pin placement should be avoided.
<code>-min_distance</code>	The minimum distance between pins on the die boundary. This distance can be in microns (default) or in number of tracks between each pin.
<code>-min_distance_in_tracks</code>	Flag that allows setting the min distance in number of tracks instead of microns.
<code>-exclude</code>	A region where pins cannot be placed. Either `top`
<code>-group_pins</code>	A list of pins to be placed together on the die boundary.
<code>-annealing</code>	Flag to enable simulated annealing pin placement.
<code>-write_pin_placement</code>	file with the pin placement generated in the format of multiple calls for the <code>place_pin</code> command.

The `exclude` option syntax is `-exclude edge:interval`. The `edge` values are (top|bottom|left|right). The `interval` can be the whole edge, with the `*` value, or a range of values. For example, in `place_pins -hor_layers metal2 -ver_layers metal3 -exclude top:*` `-exclude right:15-60.5` `-exclude left:*(-50` three intervals are excluded: the whole top edge, the right edge from 15 microns to 60.5 microns, and the left edge from its beginning to 50 microns.

## Developer Arguments

Switch Name	Description
<code>-random_seed</code>	Specify the seed for random operations.
<code>-random</code>	When this flag is enabled, the pin placement is random.

## Write Pin Placement

Use the following command to write a file with the pin placement in the format of multiple calls for the `place_pin` command:

<code>write_pin_placement file_name</code>
--------------------------------------------

## Options

Switch Name	Description
file_name	The name of the file with the pin placement.

## Useful Developer Commands

If you are a developer, you might find these useful. More details can be found in the source file or the swig file.

Command Name	Description
parse_edge	Parse edge (top/bottom/left/right).
parse_direction	Parse direction.
parse_excludes_arg	Parse excluded arguments.
parse_group_pins_arg	Parse group pins arguments.
parse_layer_name	Parse layer name.
parse_pin_names	Parse pin names.
get_edge_extreme	Get extremes of edge.
exclude_intervals	Set exclude interval.
add_pins_to_constraint	Add pins to constrained region.
add_pins_to_top_layer	Add pins to top layer.

## Example scripts

Example scripts of ppl running on a sample design of gcd as follows:

```
./test/gcd.tcl
```

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

## References

- This code depends on Munkres.

## FAQs

Check out [GitHub discussion](#) about this tool.

## License

BSD 3-Clause License. See LICENSE file.

### 5.2.12 Chip-level Connections

The chip-level connections module in OpenROAD (pad) is based on the open-source tool ICeWall. In this utility, either place an IO ring around the boundary of the chip and connect with either wirebond pads or a bump array.

## Commands

---

### Note:

- Parameters in square brackets [-param param] are optional.
  - Parameters without square brackets -param2 param2 are required.
- 

### Placing Terminals

In the case where the bond pads are integrated into the padcell, the IO terminals need to be placed. To place a terminals on the padring

```
place_io_terminals
  -allow_non_top_layer
    inst_pins
```

### Options

Switch Name	Description
-allow_non_top_layer	Allow the terminal to be placed below the top layer.
inst_pins	Instance pins to place the terminals on.

### Examples

```
place_io_terminals u_*/PAD
place_io_terminals u_*/VDD
```

## Defining a Bump Array

To define a bump array.

```
make_io_bump_array
  -bump master
  -origin {x y}
  -rows rows
  -columns columns
  -pitch {x y}
  [-prefix prefix]
```

### Options

Switch Name	Description
-bump	Name of the bump master.
-origin	Origin of the array.
-rows	Number of rows to create.
-columns	Number of columns to create.
-pitch	Pitch of the array.
-prefix	Name prefix for the bump array. The default value is BUMP_.
Example usage:	

```
make_io_bump_array -bump BUMP -origin "200 200" -rows 14 -columns 14 -pitch "200 200"
```

## Removing Entire Bump Array

To remove a bump array.

```
remove_io_bump_array -bump master
```

### Options

Switch Name	Description
-bump	Name of the bump master.

Example usage:

```
remove_io_bump_array -bump BUMP
```

## Removing a Single Bump Instance

To remove a single bump instance.

```
remove_io_bump instance_name
```

### Options

Switch Name	Description
instance_name	Name of the bump.

## Assigning a Net to a Bump

To assign a net to a bump.

```
assign_io_bump
  -net net
  [-terminal item]
  [-dont_route]
  instance
```

### Options

Switch Name	Description
-net	Net to connect to.
-terminal	Instance terminal to route to.
-dont_route	Flag to indicate that this bump should not be routed, only perform assignment.
instance	Name of the bump.

Example usage:

```
assign_io_bump -net p_ddr_addr_9_o BUMP_6_0
assign_io_bump -net p_ddr_addr_8_o BUMP_6_2
assign_io_bump -net DVSS BUMP_6_4
assign_io_bump -net DVDD BUMP_7_3
assign_io_bump -net DVDD -terminal u_dvdd/DVDD BUMP_8_3
assign_io_bump -net p_ddr_addr_7_o BUMP_7_1
assign_io_bump -net p_ddr_addr_6_o BUMP_7_0
```

## Define IO Rows

Define an IO site for the pads to be placed into.

```
make_io_sites
  -horizontal_site site
  -vertical_site site
  -corner_site site
  -offset offset
  [-rotation_horizontal rotation]
  [-rotation_vertical rotation]
  [-rotation_corner rotation]
  [-ring_index index]
```

## Options

Switch Name	Description
-horizontal_site	Name of the site for the horizontal pads (east and west).
-vertical_site	Name of the site for the vertical pads (north and south).
-corner_site	Name of the site for the corner cells.
-offset	Offset from the die edge to place the rows.
-rotation_horizontal	Rotation to apply to the horizontal sites to ensure pads are placed correctly. The default value is R0.
-rotation_vertical	Rotation to apply to the vertical sites to ensure pads are placed correctly. The default value is R0.
-rotation_corner	Rotation to apply to the corner sites to ensure pads are placed correctly. The default value is R0.
-ring_index	Used to specify the index of the ring in case of multiple rings.

Example usage:

```
make_io_sites -horizontal_site IOSITE_H -vertical_site IOSITE_V -corner_site IOSITE_C -
  -offset 35
make_io_sites -horizontal_site IOSITE_H -vertical_site IOSITE_V -corner_site IOSITE_C -
  -offset 35 -rotation_horizontal R180
```

## Remove IO Rows

When the padding is complete, the following command can remove the IO rows to avoid causing confusion with the other tools.

```
remove_io_rows
```

## Placing Corners

To place the corner cells

```
place_corners
  master
  [-ring_index index]
```

### Options

Switch Name	Description
<code>master</code>	Name of the master for the corners.
<code>-ring_index</code>	Used to specify the index of the ring in case of multiple rings.

Example usage:

```
place_corners sky130_fd_io_corner_bus_overlay
```

## Placing Pads

To place a pad into the pad ring.

```
place_pad
  -row row_name
  -location offset
  -mirror
  [-master master]
  name
```

### Options

Switch Name	Description
<code>-row</code>	Name of the row to place the pad into, examples include: IO_NORTH, IO_SOUTH, IO_WEST, IO_EAST, IO_NORTH_0, IO_NORTH_1.
<code>-location</code>	Offset from the bottom left chip edge to place the pad at.
<code>-mirror</code>	Specifies if the pad should be mirrored.
<code>-master</code>	Name of the instance master if the instance needs to be created.
<code>name</code>	Name of the instance.

Example usage:

```
place_pad -row IO_SOUTH -location 280.0 {u_clk.u_in}
place_pad -row IO_SOUTH -location 360.0 -mirror {u_reset.u_in}
place_pad -master sky130_fd_io_top_ground_hvc_wpad -row IO_SOUTH -location 439.5 {u_vzz_
↪0}
place_pad -master sky130_fd_io_top_power_hvc_wpad -row IO_SOUTH -location 517.5 {u_v18_
↪0}
```

## Placing IO Filler Cells

To place the IO filler cells.

```
place_io_fill
  -row row_name
  [-permit_overlaps masters]
    masters
```

### Options

Switch Name	Description
-row	Name of the row to place the pad into, examples include: IO_NORTH, IO_SOUTH, IO_WEST, IO_EAST, IO_NORTH_0, IO_NORTH_1.
-permit_overlaps	Names of the masters for the IO filler cells that allow for overlapping.
masters	Names of the masters for the IO filler cells.

Example usage:

```
place_io_fill -row IO_NORTH s8iom0s8_com_bus_slice_10um s8iom0s8_com_bus_slice_5um_
  ↵s8iom0s8_com_bus_slice_1um
place_io_fill -row IO_SOUTH s8iom0s8_com_bus_slice_10um s8iom0s8_com_bus_slice_5um_
  ↵s8iom0s8_com_bus_slice_1um
place_io_fill -row IO_WEST s8iom0s8_com_bus_slice_10um s8iom0s8_com_bus_slice_5um_
  ↵s8iom0s8_com_bus_slice_1um
place_io_fill -row IO_EAST s8iom0s8_com_bus_slice_10um s8iom0s8_com_bus_slice_5um_
  ↵s8iom0s8_com_bus_slice_1um
```

## Connecting Ring Signals

Once the ring is complete, use the following command to connect the ring signals.

```
connect_by_abutment
```

## Placing Wirebond Pads

To place the wirebond pads over the IO cells.

```
place_bondpad
  -bond master
  [-offset {x y}]
  [-rotation rotation]
  io_instances
```

## Options

Switch Name	Description
-bond	Name of the bondpad master.
-offset	Offset to place the bondpad at with respect to the io instance.
-rotation	Rotation of the bondpad.
io_instances	Names of the instances to add bond pads to.

Example usage:

```
place_bondpad -bond PAD IO_*
```

## Creating False IO Sites

If the library does not contain sites for the IO cells, the following command can be used to add them. This should not be used unless the sites are not in the library.

```
make_fake_io_site
  -name name
  -width width
  -height height
```

## Options

Switch Name	Description
-name	Name of the site.
-width	Width of the site (in microns).
-height	Height of the site (in microns).

Example usage:

```
make_fake_io_site -name IO_HSITE -width 1 -height 204
make_fake_io_site -name IO_VSITE -width 1 -height 200
make_fake_io_site -name IO_CSITE -width 200 -height 204
```

## Redistribution Layer Routing

To route the RDL for the bump arrays.

```
rdl_route
  -layer layer
  [-bump_via access_via]
  [-pad_via access_via]
  [-width width]
  [-spacing spacing]
  [-turn_penalty penalty]
  [-allow45]
  nets
```

## Options

Switch Name	Description
-layer	Layer to route on.
-bump_via	Via to use to connect the bump to the routing layer.
-pad_via	Via to use to connect the pad cell to the routing layer.
-width	Width of the routing. Defaults to minimum width for each respective layer.
-spacing	Spacing of the routing. Defaults to minimum spacing for each respective layer.
-turn_penalty	Scaling factor to apply to discourage turning to allow for straighter routes. The default value is 2.0, and the allowed values are floats.
-allow45	Specifies that 45 degree routing is permitted.
nets	Nets to route.

## Useful Developer Commands

If you are a developer, you might find these useful. More details can be found in the source file or the swig file.

Command Name	Description
find_site	Find site given site name.
find_master	Find master given master name.
find_instance	Find instance given instance name.
find_net	Find net given net name.
assert_required	Assert argument that is required for cmd
connect_itorm	Connect instance terminals. Required inputs are: inst_name, i term_name, net_name.
convert_tcl	These functions read from \$ICeWall::library parameters to generate a standalone Tcl script.

## Example Scripts

Example scripts for running ICeWall functions can be found in `./test`.

```
./test/assign_bumps.tcl
./test/bump_array_make.tcl
./test/bump_array_remove.tcl
./test/bump_array_remove_single.tcl
./test/connect_by_abutment.tcl
./test/make_io_sites.tcl
./test/place_bondpad.tcl
./test/place_bondpad_stagger.tcl
./test/place_pad.tcl
./test/rdl_route.tcl
./test/rdl_route_45.tcl
./test/rdl_route_assignments.tcl
```

## Regression Tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

### FAQs

Check out [GitHub discussion](#) about this tool.

### License

BSD 3-Clause License. See LICENSE file.

## 5.2.13 Macro Placement

The macro placement module in OpenROAD (`mpl`) is based on TritonMacroPlacer, an open-source ParquetFP-based macro cell placer. The macro placer places macros/blocks honoring halos, channels and cell row “snapping”. Run `global_placement` before macro placement.

Approximately  $\lceil \frac{\text{num Macros}}{3} \rceil^{1.5}$  quadrisections of the initial placed mixed-size layout are explored and packed using ParquetFP-based annealing. The best resulting floorplan according to a heuristic evaluation function is kept.

## Commands

### Note:

- Parameters in square brackets `[-param param]` are optional.
- Parameters without square brackets `-param2 param2` are required.

## Macro Placement

```
macro_placement
  [-halo {halo_x halo_y}]
  [-channel {channel_x channel_y}]
  [-fence_region {lx ly ux uy}]
  [-snap_layer snap_layer_number]
  [-style corner_wax_wl|corner_min_wl]
```

## Options

Switch Name	Description
-halo	Horizontal and vertical halo around macros (microns).
-channel	Horizontal and vertical channel width between macros (microns).
-fence_region	Restrict macro placements to a region (microns). Defaults to the core area.
-snap_layer	Snap macro origins to this routing layer track.
-style	Placement style, to choose either corner_max_wl or corner_min_wl. The default value is corner_max_wl.

For placement style, `corner_max_wl` means that choosing the partitions that maximise the wirelength of connections between the macros to force them to the corners. Vice versa for `corner_min_wl`.

Macros will be placed with  $\max(\text{halo} * 2, \text{channel})$  spacing between macros, and between macros and the fence/die boundary. If no solutions are found, try reducing the channel/halo.

## Useful developer functions

If you are a developer, you might find these useful. More details can be found in the source file or the swig file.

Command Name	Description
macro_placement_debug	Macro placement debugging. Note that GUI must be present for this command, otherwise a segfault will occur.

## Example scripts

Example scripts demonstrating how to run TritonMacroPlace on a sample design of `east_west` as follows:

```
./test/east_west.tcl  
./test/east_west1.tcl  
./test/east_west2.tcl
```

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

### FAQs

Check out [GitHub discussion](#) about this tool.

### License

BSD 3-Clause License. See LICENSE file.

## 5.2.14 Hierarchical Macro Placement

A hierarchical automatic macro placer for large-scale complex IP blocks, “Hier-RTLMP”. This tool builds on the existing RTLMP (`mp1`) framework, adopting a multilevel physical planning approach that exploits the hierarchy and data flow inherent in the design RTL.

### Commands

#### Note:

- Parameters in square brackets `[-param param]` are optional.
- Parameters without square brackets `-param2 param2` are required.

### Hier-RTLMP algorithm

```
rtl_macro_placer
  [-max_num_macro max_num_macro]
  [-min_num_macro min_num_macro]
  [-max_num_inst max_num_inst]
  [-min_num_inst min_num_inst]
  [-tolerance tolerance]
  [-max_num_level max_num_level]
  [-coarsening_ratio coarsening_ratio]
  [-num_bundled_ios num_bundled_ios]
  [-large_net_threshold large_net_threshold]
  [-signature_net_threshold signature_net_threshold]
  [-halo_width halo_width]
  [-fence_lx fence_lx]
  [-fence_ly fence_ly]
  [-fence_ux fence_ux]
  [-fence_uy fence_uy]
  [-area_weight area_weight]
  [-outline_weight outline_weight]
  [-wirelength_weight wirelength_weight]
  [-guidance_weight guidance_weight]
  [-fence_weight fence_weight]
  [-boundary_weight boundary_weight]
```

(continues on next page)

(continued from previous page)

```
[-notch_weight notch_weight]
[-macro_blockage_weight macro_blockage_weight]
[-pin_access_th pin_access_th]
[-target_util target_util]
[-target_dead_space target_dead_space]
[-min_ar min_ar]
[-snap_layer snap_layer]
[-bus_planning]
[-report_directory report_directory]
[-write_macro_placement file_name]
```

## Generic Parameters

Switch Name	Description
-max_num_macro, -min_num_macro	Maximum/minimum number of macros in a cluster. The default value is 0 for both, and the allowed values are integers [0, MAX_INT].
-max_num_inst, -min_num_inst	Maximum/minimum number of standard cells in a cluster. The default value is 0 for both, and the allowed values are integers [0, MAX_INT].
-tolerance	Add a margin to the minimum and maximum number of macros/std cells in a cluster. For min, we multiply by (1 - tol), and for the max (1 + tol). This is to improve the robustness of hierarchical clustering. The allowed values are floats [0, 1], and the default value is 0.1.
-max_num_level	Maximum depth of physical hierarchical tree. The default value is 2, and the allowed values are integers [0, MAX_INT].
-coarsening_ratio	The larger the coarsening_ratio, the faster the convergence process. The allowed values are floats, and the default value is 10.0.
-num_bundled_ios	Specifies the number of bundled pins for the left, right, top, and bottom boundaries. The default value is 3, and the allowed values are integers [0, MAX_INT].
-large_net_threshold	Identifies nets with many connections during clustering, such as global nets. The default value is 50, and the allowed values are integers [0, MAX_INT].
-signature_net_threshold	Threshold number of connections between two clusters to be identified as connected. The default value is 50, and the allowed values are integers [0, MAX_INT].
-halo_width	Horizontal/vertical halo around macros (microns). The allowed values are floats, and the default value is 0.0.
-fence_lx, -fence_ly, -fence_ux, -fence_uy	Defines the global fence bounding box coordinates. The default values are the core area coordinates).
-pin_access_th	Specifies the pin access threshold value of macros. The default value is 0.0, and the allowed values are floats [0,1].
-target_util	Specifies the target utilization of MixedCluster and has higher priority than target_dead_space. The allowed values are floats, and the default value is 0.25.
-target_dead_space	Specifies the target dead space percentage, which influences the utilization of StandardCellCluster. The allowed values are floats, and the default value is 0.05.
-min_ar	Specifies the minimum aspect ratio $a$ , or the ratio of its width to height of a StandardCellCluster from $[a, \frac{1}{a}]$ . The allowed values are floats, and the default value is 0.33.
-snap_layer	Snap macro origins to this routing layer track. The default value is 4, and the allowed values are integers [1, MAX_LAYER]).
-bus_planning	Flag to enable bus planning. We recommend to enable bus planning for technologies with very limited routing layers such as SKY130 and GF180. As for technologies such as NanGate45 and ASAP7, we recommend to keep it disabled.
-report_directory	Save reports to this directory.
-write_macro_placement	Generates a file with the placement of the macros placed by HierRTLMP flow in the format of multiple calls for the place_macro command.

## Simulated Annealing Weight parameters

Do note that while action probabilities are normalized to 1.0, the weights are not necessarily normalized.

Switch Name	Description
-area_weight	Weight for the area of current floorplan. The allowed values are floats, and the default value is <code>0.1</code> .
-outline_weight	Weight for violating the fixed outline constraint, meaning that all clusters should be placed within the shape of their parent cluster. The allowed values are floats, and the default value is <code>100.0</code> .
-wirelength_weight	Weight for half-perimeter wirelength. The allowed values are floats, and the default value is <code>100.0</code> .
-guidance_weight	Weight for guidance cost or clusters being placed near specified regions if users provide such constraints. The allowed values are floats, and the default value is <code>10.0</code> .
-fence_weight	Weight for fence cost, or how far the macro is from zero fence violation. The allowed values are floats, and the default value is <code>10.0</code> .
-boundary_weight	Weight for the boundary, or how far the hard macro clusters are from boundaries. Note that mixed macro clusters are not pushed, thus not considered in this cost. The allowed values are floats, and the default value is <code>50.0</code> .
-notch_weight	Weight for the notch, or the existence of dead space that cannot be used for placement & routing. Note that this cost applies only to hard macro clusters. The allowed values are floats, and the default value is <code>10.0</code> .
-macro_blockage_weight	Weight for macro blockage, or the overlapping instances of the macro. The allowed values are floats, and the default value is <code>10.0</code> .

## Write Macro Placement

Command to generate a file with the placement of the macros in the design using multiple calls for the `place_macro` command:

```
write_macro_placement file_name
```

## Place Macro

Command for placement of one specific macro.

```
place_macro
  -macro_name macro_name
  -location {x y}
  [-orientation orientation]
```

## Options

Switch Name	Description
-macro_name	The name of a macro of the design.
-location	The lower left corner of the macro in microns.
-orientation	The orientation according to odb. If nothing is specified, defaults to R0. We only allow R0, MY, MX and R180.

## Example scripts

Example of a script demonstrating how to run `mp12` on a sample design of `bp_fe_top` as follows:

```
./test/bp_fe_top.tcl
```

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

## References

1. A. B. Kahng, R. Varadarajan and Z. Wang, “RTL-MP: Toward Practical, Human-Quality Chip Planning and Macro Placement”, ([.pdf](#)), Proc. ACM/IEEE Intl. Symp. on Physical Design, 2022, pp. 3-11.
2. A. B. Kahng, R. Varadarajan and Z. Wang, “Hier-RTLMP: A hierarchical automatic macro placer for large-scale complex IP blocks.”, ([.pdf](#)), arXiv preprint arXiv:2304.11761, 2023.

## FAQs

Check out [GitHub discussion](#) about this tool.

## License

BSD 3-Clause License. See LICENSE file.

### 5.2.15 Tapcell

Tapcell and endcap insertion.

## Commands

---

### Note:

- Parameters in square brackets `[-param param]` are optional.
  - Parameters without square brackets `-param2 param2` are required.
-

## Add Tapcell/Endcap

```
tapcell
  [-tapcell_master tapcell_master]
  [-endcap_master endcap_master]
  [-distance dist]
  [-halo_width_x halo_x]
  [-halo_width_y halo_y]
  [-tap_nwin2_master tap_nwin2_master]
  [-tap_nwin3_master tap_nwin3_master]
  [-tap_nwout2_master tap_nwout2_master]
  [-tap_nwout3_master tap_nwout3_master]
  [-tap_nwintie_master tap_nwintie_master]
  [-tap_nwouttie_master tap_nwouttie_master]
  [-cnrcap_nwin_master cnrcap_nwin_master]
  [-cnrcap_nwout_master cnrcap_nwout_master]
  [-incnrcap_nwin_master incnrcap_nwin_master]
  [-incnrcap_nwout_master incnrcap_nwout_master]
  [-tap_prefix tap_prefix]
  [-endcap_prefix endcap_prefix]
  [-tbtie_cpp tbtie_cpp]
  [-no_cell_at_top_bottom]
```

## Options

Switch Name	Description
-tapcell_master	Master used as a tapcell.
-endcap_master	Master used as an endcap.
-distance	Distance (in microns) between each tapcell in the checkerboard.
-halo_width_x	Horizontal halo size (in microns) around macros during cut rows.
-halo_width_y	Vertical halo size (in microns) around macros during cut rows.
-tap_nwintie_master	Master cell placed at the top and bottom of
-tap_nwin2_master	Master cell placed at the top and bottom of macros and the core area according the row orientation. This master should be smaller than tap_nwintie_master
-tap_nwin3_master	Master cell placed at the top and bottom of macros and the core area according the row orientation. This master should be smaller than tap_nwin2_master.
-tap_nwouttie_master	Master cell placed at the top and bottom of macros and the core area according the row orientation.
-tap_nwout2_master	Master cell placed at the top and bottom of macros and the core area according the row orientation. This master should be smaller than tap_nwouttie_master.
-tap_nwout3_master	Master cell placed at the top and bottom of macros and the core area according the row orientation
-incnrcap_nwin	Master cell placed at the corners of macros, according the row orientation.
-incnrcap_nwout	Master cell placed at the corners of macros, according the row orientation.
-cnrcap_nwin_master	Macro cell placed at the corners the core area according the row orientation.
-cnrcap_nwout_master	Macro cell placed at the corners the core area according the row orientation.
-tap_prefix	Prefix for the tapcell instances. The default value is TAP_.
-endcap_prefix	Prefix for the endcaps instances. The default value is PHY_.
-tbtie_cpp	Option is deprecated.
-no_cell_at_top_bottom	Options deprecated.

The figures below show two examples of tapcell insertion. When only the `-tapcell_master` and `-endcap_master` masters are given, the tapcell placement is similar to Figure 1. When the remaining masters are give, the tapcell placement is similar to Figure 2.

Figure 1: Tapcell insertion representation	Figure 2: Tapcell insertion around macro representation
--------------------------------------------	---------------------------------------------------------

## Only cutting rows

```
cut_rows
[-endcap_master endcap_master]
[-halo_width_x halo_x]
[-halo_width_y halo_y]
```

## Options

Switch Name	Description
<code>-endcap_master</code>	Master used as an endcap.
<code>-halo_width_x</code>	Horizontal halo size (in microns) around macros during cut rows.
<code>-halo_width_y</code>	Vertical halo size (in microns) around macros during cut rows.

## Only adding boundary/endcap cells

Place endcaps into the design, the naming for the arguments to `place_endcaps` is based on the LEF58 CLASS specification for endcaps.

```
place_endcaps
[-corner master]
[-edge_corner master]
[-endcap masters]
[-endcap_horizontal masters]
[-endcap_vertical master]
[-prefix prefix]
[-left_top_corner master]
[-right_top_corner master]
[-left_bottom_corner master]
[-right_bottom_corner master]
[-left_top_edge master]
[-right_top_edge master]
[-left_bottom_edge master]
[-right_bottom_edge master]
[-left_edge master]
[-right_edge master]
[-top_edge masters]
[-bottom_edge masters]
```

**Options**

Switch Name	Description
-prefix	Prefix to use for the boundary cells. Defaults to "PHY_".
-corner	Master for the corner cells on the outer corners.
-edge_corner	Master for the corner cells on the inner corners.
-endcap	Master used as an endcap.
-endcap_horizontal	List of masters for the top and bottom row endcaps. (overrides -endcap).
-endcap_vertical	Master for the left and right row endcaps. (overrides -endcap).
-left_top_corner	Master for the corner cells on the outer top left corner. (overrides -corner).
-right_top_corner	Master for the corner cells on the outer top right corner. (overrides -corner).
-left_bottom_corner	Master for the corner cells on the outer bottom left corner. (overrides -corner).
-right_bottom_corner	Master for the corner cells on the outer bottom right corner. (overrides -corner).
-left_top_edge	Master for the corner cells on the inner top left corner. (overrides -edge_corner).
-right_top_edge	Master for the corner cells on the inner top right corner. (overrides -edge_corner).
-left_bottom_edge	Master for the corner cells on the inner bottom left corner. (overrides -edge_corner).
-right_bottom_edge	Master for the corner cells on the inner bottom right corner. (overrides -edge_corner).
-left_edge	Master for the left row endcaps. (overrides -endcap_vertical).
-right_edge	Master for the right row endcaps. (overrides -endcap_vertical).
-top_edge	List of masters for the top row endcaps. (overrides -endcap_horizontal).
-bottom_edge	List of masters for the bottom row endcaps. (overrides -endcap_horizontal).

**Only adding tapcells cells**

```
place_tapcells
  -master tapcell_master
  -distance dist
```

**Options**

Switch Name	Description
-master	Master to use for the tapcells.
-distance	Distance between tapcells.

**Remove Tapcells/Endcaps**

```
tapcell_riput
  -tap_prefix tap_prefix
  -endcap_prefix endcap_prefix
```

## Options

Switch Name	Description
-tap_prefix	Remove tapcells with said prefix.
-endcap_prefix	Remove endcaps with said prefix.

## Example scripts

You can find script examples for both 45nm and 14nm in `./etc/scripts`

```
./etc/scripts/example_14nm.tcl  
./etc/scripts/example_45nm.tcl
```

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

### FAQs

Check out [GitHub discussion](#) about this tool.

### License

BSD 3-Clause License. See `LICENSE` file.

## 5.2.16 Power Distribution Network Generator

The power distribution network (PDN) generator module in OpenROAD (pdn) is based on the PDNGEN tool. This utility aims to simplify the process of adding a power grid into a floorplan. The aim is to specify a small set of power grid policies to be applied to the design, such as layers to use, stripe width and spacing, then have the utility generate the actual metal straps. Grid policies can be defined over the stdcell area, and over areas occupied by macros.

### See also:

To work with UPF files, refer to [Read UPF Utility](#).

## Commands

---

**Note:**

- Parameters in square brackets [-param param] are optional.
  - Parameters without square brackets -param2 param2 are required.
- 

### Build Power Grid

Build a power grid in accordance with the information specified.

```
pdngen
  [-skip_trim]
  [-dont_add_pins]
  [-reset]
  [-riput]
  [-report_only]
  [-failed_via_report file]
```

#### Options

Switch Name	Description
-skip_trim	Skip the metal trim step, which attempts to remove metal stubs.
-dont_add_pins	Prevent the creation of block pins.
-reset	Reset the grid and domain specifications.
-riput	Ripup the existing power grid, as specified by the voltage domains.
-report_only	Print the current specifications.
-failed_via_report	Generate a report file that can be viewed in the DRC viewer for all the failed vias (i.e., those that did not get built or were removed).

### Define Voltage Domains

Defines a named voltage domain with the names of the power and ground nets for a region.

This region must already exist in the floorplan before referencing it with the set\_voltage\_domain command. If the -region argument is not supplied, then the region is the entire core area of the design.

```
set_voltage_domain
  -name domain_name
  -power power_net_name
  -ground ground_net_name
  [-region region_name]
  [-secondary_power secondary_power_net]
  [-switched_power switched_power_net]
```

## Options

Switch Name	Description
-name	Defines the name of the voltage domain. The default is “Core” or region name if provided.
-power	Specifies the name of the power net for this voltage domain.
-ground	Specifies the name of the ground net for this voltage domain.
-region	Specifies a region of the design occupied by this voltage domain.
-secondary_power	Specifies the name of the secondary power net for this voltage domain.
-switched_power	Specifies the name of the switched power net for switched power domains.

Example usage:

```
set_voltage_domain -power VDD -ground VSS
set_voltage_domain -name TEMP_ANALOG -region TEMP_ANALOG -power VIN -ground VSS
set_voltage_domain -region test_domain -power VDD -ground VSS -secondary_power VREG
```

## Define Power Grid (General)

Define the rules to describe a power grid pattern to be placed in the design.

**Warning:** `define_pdn_grid` is overloaded with two different signatures. Take note of the arguments when using this function!

```
define_pdn_grid
  [-name name]
  [-voltage_domain list_of_domain_names]
  [-pins list_of_pin_layers]
  [-starts_with POWER|GROUND]
  [-starts_with POWER|GROUND]
  [-obstructions list_of_layers]
```

## Options

Switch Name	Description
-name	The name to use when referring to this grid definition.
-voltage_domain	This grid’s voltage domain name. Defaults to the last domain created.
-pins	List of layers where the power straps will be promoted to block pins.
-starts_with	Use POWER or GROUND for the first placed strap. Defaults to GROUND.
-obstructions	Layers to add routing blockages to avoid DRC violations.

Example usage:

```
define_pdn_grid -name main_grid -pins {metal7} -voltage_domain {CORE TEMP_ANALOG}
```

## Define Power Grid (Macros)

```
define_pdn_grid
  -macro
  [-name name]
  [-grid_over_pg_pins|-grid_over_boundary]
  [-voltage_domain list_of_domain_names]
  [-orient list_of_valid_orientations]
  [-instances list_of_instances]
  [-cells list_of_cells]
  [-default]
  [-halo list_of_halo_values]
  [-pins list_of_pin_layers]
  [-starts_with POWER|GROUND]
  [-obstructions list_of_layers]
  [-power_switch_cell name]
  [-power_control signal_name]
  [-power_control_network STAR|DAISY]
```

## Options

Switch Name	Description
-macro	The type of grid added as a macro.
-name	The name to use when referring to this grid definition.
-grid_over_boundary	Places the power grid over the power ground pins of the macro (default) or place the power grid over the boundary of the macro.
-voltage_domain	voltage domain name. Defaults to the last domain created.
-orient	For a macro, defines a set of valid orientations. LEF orientations (N, FN, S, FS, E, FE, W and FW) can be used as well as standard geometry orientations (R0, R90, R180, R270, MX, MY, MXR90 and MYR90). Macros with one of the valid orientations will use this grid specification.
-instances	For a macro, defines a set of valid instances. Macros with a matching instance name will use this grid specification.
-cells	For a macro, defines a set of valid cells. Macros, which are instances of one of these cells, will use this grid specification.
-default	For a macro, specifies this is a default grid that can be overwritten.
-halo	Specifies the design's default minimum separation of selected macros from other cells. This is only used if the macro does not define halo values in the LEF description. If one value is specified, it will be used on all four sides; if two values are specified, the first will be applied to left/right sides, and the second will be applied to top/bottom sides; if four values are specified, then they are applied to left, bottom, right and top sides respectively (Default: 0).
-pins	Defines a list of layers where the power straps will be promoted to block pins.
-starts_with	the POWER or GROUND for the first placed strap. Defaults to GROUND.
-obstructions	Specify the layers to add routing blockages in order to avoid DRC violations.
-power_switch	Defines the name of the coarse grain power switch cell to be used wherever the stdcell rail connects to the rest of the power grid. The mesh layers are associated with the unswitched power net of the voltage domain, whereas the stdcell rail is associated with the switched power net of the voltage domain. The placement of a power switch cell connects the unswitched power mesh to the switched power rail through a power switch defined by the define_power_switch_cell command.
-power_control	Defines the name of the power control signal used to control the switching of the inserted power switches.
-power_control_network	Defines the structure of the power control signal network. Choose from STAR or DAISY. If STAR is specified, then the network is wired as a high-fanout net with the power control signal driving the power control pin on every power switch. If DAISY is specified, then the power switches are connected in a daisy-chain configuration - note, this requires that the power switch defined by the define_power_switch_cell command defines an acknowledge pin for the switch.

Example usage:

```
define_pdn_grid -macro -name ram           -orient {R0 R180 MX MY} -grid_over_pg_pins -
  ↵ starts_with POWER -pin_direction vertical
define_pdn_grid -macro -name rotated_rams -orient {E FE W FW}      -grid_over_boundary -
  ↵ starts_with POWER -pin_direction horizontal
```

## Define Power Grid for an Existing Routing Solution

```
define_pdn_grid
    -existing
    [-name name]
    [-obstructions list_of_layers]
```

### Options

Switch Name	Description
-existing	Enable use of existing routing solution.
-name	The name to use when referring to this grid definition. Defaults to <code>existing_grid</code> .
-obstructions	The layers to add routing blockages in order to avoid DRC violations.

Example usage:

```
define_pdn_grid -name main_grid -existing
```

## Define Power Switch Cell

Define a power switch cell that will be inserted into a power grid.

```
define_power_switch_cell
    -name name
    -control control_pin
    -power_switchable power_switchable_pin
    -power unswitched_power_pin
    -ground ground_pin
    [-acknowledge acknowledge_pin_name]
```

### Options

Switch Name	Description
-name	The name of the power switch cell.
-control	The name of the power control port of the power switch cell.
-switched_power	The pin's name that outputs the switched power net.
-power	The pin's name that connects to the unswitched power net.
-ground	The pin's name that connects to the ground net.
-acknowledge	The name of the output control signal of the power control switch if it has one.

Example usage:

```
define_power_switch_cell -name POWER_SWITCH -control SLEEP -switched_power VDD -power_
                           ↵VDDG -ground VSS
```

## Add Stripes

Defines a pattern of power and ground stripes in a single layer to be added to a power grid.

```
add_pdn_stripe
  -layer layer_name
  [-grid grid_name]
  [-width width_value]
  [-followpins]
  [-extend_to_core_ring]
  [-pitch pitch_value]
  [-spacing spacing_value]
  [-offset offset_value]
  [-starts_with POWER|GROUND]
  [-extend_to_boundary]
  [-snap_to_grid]
  [-number_of_straps count]
  [-nets list_of_nets]
```

## Options

Switch Name	Description
-layer	The layer name for these stripes.
-grid	The grid to which this stripe definition will be added. (Default: Last grid defined by define_pdn_grid).
-width	Value for the width of the stripe.
-followpins	Indicates that the stripe forms part of the stdcell rails, pitch and spacing are dictated by the stdcell rows, and the -width is not needed if it can be determined from the cells.
-extend_to_core	Extend the stripes to the core PG ring.
-pitch	Value for the distance between each power/ground pair.
-spacing	Optional specification of the spacing between power/ground pairs within a single pitch defaults to pitch / 2.
-offset	Value for the offset of the stripe from the lower left corner of the design core area.
-starts_with	Use POWER or GROUND for the first placed strap. Defaults to GROUND.
-extend_to_boundary	Extend the stripes to the boundary of the grid.
-snap_to_grid	Snap the stripes to the defined routing grid.
-number_of_straps	Number of power/ground pairs to add.
-nets	Limit straps to just this list of nets.

Example usage:

```
add_pdn_stripe -grid main_grid -layer metal1 -followpins
add_pdn_stripe -grid main_grid -layer metal2 -width 0.17 -followpins
add_pdn_stripe -grid main_grid -layer metal4 -width 0.48 -pitch 56.0 -offset 2 -starts_
  ↵with GROUND
```

## Add Rings

The `add_pdn_ring` command defines power/ground rings around a grid region. The ring structure is built using two layers that are orthogonal to each other. A power/ground pair will be added above and below the grid using the horizontal layer, with another power/ground pair to the left and right using the vertical layer. These four pairs of power/ground stripes form a ring around the specified grid. Power straps on these layers that are inside the enclosed region are extended to connect to the ring.

```
add_pdn_ring
  -layers layer_name
  -widths width_value|list_of_2_values
  -spacings spacing_value|list_of_2_values
  [-grid grid_name]
  [-core_offsets offset_value]
  [-pad_offsets offset_value]
  [-add_connect]
  [-extend_to_boundary]
  [-connect_to_pads]
  [-connect_to_pad_layers layers]
  [-starts_with POWER|GROUND]
  [-nets list_of_nets]
```

## Options

Switch Name	Description
<code>-layers</code>	Specifies the name of the layer for these stripes.
<code>-widths</code>	Value for the width of the stdcell rail.
<code>-spacings</code>	Optional specification of the spacing between power/ground pairs within a single pitch. (Default: pitch / 2).
<code>-grid</code>	Specifies the name of the grid to which this ring defintion will be added. (Default: Last grid created by <code>define_pdn_grid</code> ).
<code>-core_offsets</code>	Value for the offset of the ring from the grid region.
<code>-pad_offsets</code>	When defining a power grid for the top level of an SoC, can be used to define the offset of ring from the pad cells.
<code>-add_connect</code>	Automatically add a connection between the two layers.
<code>-extend_to_boundary</code>	Extend the rings to the grid boundary.
<code>-connect_to_pads</code>	The core side of the pad pins will be connected to the ring.
<code>-connect_to_pad_layers</code>	Restrict the pad pins layers to this list.
<code>-starts_with</code>	Use POWER or GROUND for the first placed strap. Defaults to GROUND.
<code>-nets</code>	Limit straps to just this list of nets.

Example usage:

```
add_pdn_ring -grid main_grid -layer {metal6 metal7} -widths 5.0 -spacings 3.0 -core_
  ↵offset 5
```

## Add Connections

The `add_pdn_connect` command is used to define which layers in the power grid are to be connected together. During power grid generation, vias will be added for overlapping power nets and overlapping ground nets. The use of fixed vias from the technology file can be specified or else via stacks will be constructed using VIARULEs. If VIARULEs are not available in the technology, then fixed vias must be used.

```
add_pdn_connect
-layers list_of_two_layers
[-grid grid_name]
[-cut_pitch pitch_value]
[-fixed_vias list_of_fixed_vias]
[-dont_use_vias list_of_vias]
[-max_rows rows]
[-max_columns columns]
[-ongrid ongrid_layers]
[-split_cuts split_cuts_mapping]
```

## Options

Switch Name	Description
-layers	Layers to be connected where there are overlapping power or overlapping ground nets.
-grid	Specifies the name of the grid definition to which this connection will be added (Default: Last grid created by <code>define_pdn_grid</code> ).
-cut_pitch	When the two layers are parallel, e.g., overlapping stdcell rails, specify the distance between via cuts.
-fixed_vias	List of fixed vias to be used to form the via stack.
-dont_use_vias	List or pattern of vias to not use to form the via stack.
-max_rows	Maximum number of rows when adding arrays of vias.
-max_columns	Maximum number of columns when adding arrays of vias.
-ongrid	List of intermediate layers in a via stack to snap onto a routing grid.
-split_cuts	Specifies layers to use split cuts on with an associated pitch, for example <code>{metal3 0.380 metal5 0.500}</code> .

Example usage:

```
add_pdn_connect -grid main_grid -layers {metal1 metal2} -cut_pitch 0.16
add_pdn_connect -grid main_grid -layers {metal2 metal4}
add_pdn_connect -grid main_grid -layers {metal4 metal7}

add_pdn_connect -grid ram -layers {metal4 metal5}
add_pdn_connect -grid ram -layers {metal5 metal6}
add_pdn_connect -grid ram -layers {metal6 metal7}

add_pdn_connect -grid rotated_rams -layers {metal4 metal6}
add_pdn_connect -grid rotated_rams -layers {metal6 metal7}
```

## Repairing Power Grid vias after Detailed Routing

To remove vias which generate DRC violations after detailed placement and routing use `repair_pdn_vias`.

```
repair_pdn_vias
  [-all]
  [-net net_name]
```

### Options

Switch Name	Description
<code>-all</code>	Repair vias on all supply nets.
<code>-net</code>	Repair only vias on the specified net.

## Useful Developer Commands

If you are a developer, you might find these useful. More details can be found in the *source file* or the *swig file*.

Command Name	Description
<code>name_cmp</code>	Compare 2 input strings <code>obj1</code> and <code>obj2</code> if they are equal.
<code>check_design</code>	Check if the design is loaded.
<code>get_layer</code>	Get the layer reference of the layer name.
<code>get_voltage_domains</code>	Tcl list of power domains in design.
<code>match_orientations</code>	Checks if a given orientation <code>orient</code> is within a list of orientations <code>orients</code> .
<code>get_insts</code>	Get the Tcl list of instances.
<code>get_masters</code>	Get the Tcl list of masters.
<code>get_one_to_two</code>	If a Tcl list has one element <code>{x}</code> , Tcl list <code>{x x}</code> is returned. If a Tcl list of two elements <code>{y y}</code> , list as is returned. Otherwise, for any other list lengths, an error is triggered.
<code>get_one_to_four</code>	Similar logic for the above function, except the logic only works for lists of length one, two, and four, respectively. All other list lengths trigger errors.
<code>get_obstructed_layers</code>	Gets the Tcl list of layers.
<code>get_starts_with</code>	If value starts with POWER, return 1; else if value starts with GROUND return 0; else return error.
<code>get_mterm</code>	Find master terminal.
<code>get_orientations</code>	Gets the list of valid orientations.

## Example scripts

### Defining a SoC power grid with pads

```
add_global_connection -net VDD -pin_pattern {"^VDD$"} -power
add_global_connection -net VDD -pin_pattern {"^VDDPE$"}
add_global_connection -net VDD -pin_pattern {"^VDDCE$"}
add_global_connection -net VSS -pin_pattern {"^VSS$"} -ground
add_global_connection -net VSS -pin_pattern {"^VSSE$"}

set_voltage_domain -power VDD -ground VSS
```

(continues on next page)

(continued from previous page)

```

define_pdn_grid -name "Core"
add_pdn_ring -grid "Core" -layers {metal8 metal9} -widths 5.0 -spacings 2.0 -core_
- offsets 4.5 -connect_to_pads

add_pdn_stripe -followpins -layer metal1 -extend_to_core_ring

add_pdn_stripe -layer metal4 -width 0.48 -pitch 56.0 -offset 2.0 -extend_to_core_ring
add_pdn_stripe -layer metal7 -width 1.40 -pitch 40.0 -offset 2.0 -extend_to_core_ring
add_pdn_stripe -layer metal8 -width 1.40 -pitch 40.0 -offset 2.0 -extend_to_core_ring
add_pdn_stripe -layer metal9 -width 1.40 -pitch 40.0 -offset 2.0 -extend_to_core_ring

add_pdn_connect -layers {metal1 metal4}
add_pdn_connect -layers {metal4 metal7}
add_pdn_connect -layers {metal7 metal8}
add_pdn_connect -layers {metal8 metal9}
add_pdn_connect -layers {metal9 metal10}

pdngen

```

## Sroute

The `add_sroute_connect` command is employed for connecting pins located outside of a specific power domain to the power ring, especially in cases where multiple power domains are present. During `sroute`, multi-cut vias will be added for new connections. The use of fixed vias from the technology file should be specified for the connection using the `add_sroute_connect` command. The use of `max_rows` and `max_columns` defines the row and column limit for the via stack.

```

add_sroute_connect
  -layers list_of_2_layers
  -cut_pitch pitch_value
  [-net net]
  [-outerNet outerNet]
  [-fixed_vias list_of_vias]
  [-max_rows rows]
  [-max_columns columns]
  [-metalwidths metalwidths]
  [-metalspaces metalspaces]
  [-ongrid ongrid_layers]
  [-insts inst]

```

## Options

Switch Name	Description
-net	The inner net where the power ring exists.
-outerNet	The outer net where instances/pins that need to get connected exist.
-layers	The metal layers for vertical stripes within inner power ring.
-cut_pitch	Distance between via cuts when the two layers are parallel, e.g., overlapping stdcell rails. (Default:200 200)
-fixed_vias	List of fixed vias to be used to form the via stack.
-max_rows	Maximum number of rows when adding arrays of vias. (Default:10)
-max_columns	Maximum number of columns when adding arrays of vias. (Default:10)
-metalwidths	Width for each metal layer.
-metalspaces	Spacing of each metal layer.
-ongrid	List of intermediate layers in a via stack to snap onto a routing grid.
-insts	List of all the instances that contain the pin that needs to get connected with power ring. (Default:nothing)

## Examples

```
add_sroute_connect -net "VIN" -outerNet "VDD" -layers {met1 met4} -cut_pitch {200 200} -  
fixed_vias {M3M4_PR_M} -metalwidths {1000 1000} -metalspaces {800} -ongrid {met3 met4} -  
-insts "temp_analog_1.a_header_0"
```

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

Currently the following assumptions are made:

1. The design is rectangular
2. The input floorplan includes the stdcell rows, placement of all macro blocks and IO pins.
3. The stdcells rows will be cut around macro placements

## FAQs

Check out [GitHub discussion](#) about this tool.

## License

BSD 3-Clause License. See LICENSE file.

## Read UPF Utility

This module contains functionality to read, and modify information from Unified Power Format (UPF) files.

### Commands

---

#### Note:

- Parameters in square brackets [-param param] are optional.
  - Parameters without square brackets -param2 param2 are required.
- 

## Read UPF

Sources the UPF file.

```
read_upf  
  -file file
```

### Options

Switch Name	Description
-file	Path to .upf file.

## Create Power Domain

```
create_power_domain  
  [-elements elements]  
  name
```

**Options**

Switch Name	Description
-elements	List of module paths that belong to this domain OR * for top domain.
name	Domain name.

**Create Logic Port**

```
create_logic_port
  [-direction direction]
  port_name
```

**Options**

Switch Name	Description
-direction	Direction of the port (in, out, inout).
port_name	Port name.

**Create Power Switch**

```
create_power_switch
  [-domain domain]
  [-output_supply_port output_supply_port]
  [-input_supply_port input_supply_port]
  [-control_port control_port]
  [-on_state on_state]
  name
```

**Options**

Switch Name	Description
-domain	Power domain name.
-output_supply_port	Output supply port of the switch.
-input_supply_port	Input supply port of the switch.
-control_port	Control port on the switch.
-on_state	One of {state_name, input_supply_port, boolean_expression}.
name	Power switch name.

## Create or Update Isolation Strategy

```
set_isolation
  [-domain domain]
  [-applies_to applies_to]
  [-clamp_value clamp_value]
  [-isolation_signal isolation_signal]
  [-isolation_sense isolation_sense]
  [-location location]
  [-update]
  name
```

### Options

Switch Name	Description
-domain	Power domain
-applies_to	Restricts the strategy to apply one of these (inputs, outputs, both).
-clamp_value	Value the isolation can drive (0, 1).
-isolation_signal	The control signal for this strategy.
-isolation_sense	The active level of isolation control signal.
-location	Domain in which isolation cells are placed (parent, self, fanout).
-update	Only available if using existing strategy, will error if the strategy doesn't exist.
name	Isolation strategy name.

## Set Interface cell

```
use_interface_cell
  [-domain domain]
  [-strategy strategy]
  [-lib_cells lib_cells]
```

**Options**

Switch Name	Description
-domain	Power domain name.
-strategy	Isolation strategy name.
-lib_cells	List of lib cells that could be used.

**Set Domain Area**

```
set_domain_area  
  domain_name  
  -area {llx lly urx ury}
```

**Options**

Switch Name	Description
domain_name	Power domain name.
-area	x-/y- coordinates in microns for the lower left and upper right corners of the power domain area.

**Map existing power switch**

```
map_power_switch  
  [-switch_name_list switch_name_list]  
  [-lib_cells lib_cells]  
  [-port_map port_map]
```

**Options**

Switch Name	Description
-switch_name_list	A list of switches (as defined by create_power_switch) to map.
-lib_cells	A list of library cells that could be mapped to the power switch
-port_map	A map that associates model ports defined by create_power_switch to logical ports

**Example scripts**

Example script demonstrating how to run upf related commands can be found here:

```
./test/upf_test.tcl
```

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

## FAQs

Check out [GitHub discussion](#) about this tool.

## License


BSD 3-Clause License. See *LICENSE* file.

## IR Drop Analysis

The IR Drop Analysis module in OpenROAD (`psm`) is based on PDNSim, an open-source static IR analyzer.

Features:

- Report worst IR drop.
- Report worst current density over all nodes and wire segments in the power distribution network, given a placed and PDN-synthesized design.
- Check for floating PDN stripes on the power and ground nets.
- Spice netlist writer for power distribution network wire segments.



## Commands

---

**Note:**

- Parameters in square brackets [-param param] are optional.
  - Parameters without square brackets -param2 param2 are required.
- 

### Analyze Power Grid

```
analyze_power_grid
[-vsrc vsrc_file]
[-outfile outfile]
[-error_file err_file]
[-enable_em]
[-em_outfile em_outfile]
[-net net_name]
[-dx bump_pitch_x]
[-dy bump_pitch_y]
[-node_density val_node_density]
[-node_density_factor val_node_density_factor]
[-corner corner]
```

### Options

Switch Name	Description
-vsrc	File to set the location of the power C4 bumps/IO pins. Vsrc_aes.loc file for an example with a description specified <a href="#">here</a> .
-dx, -dy	These arguments set the bump pitch to decide the voltage source location in the absence of a vsrc file. Default bump pitch of 140um used in absence of these arguments and vsrc.
-net	Name of the net to analyze, power or ground net name.
-enable_em	Report current per power grid segment.
-outfile	Write per-instance voltage into the file.
-em_outfile	Write the per-segment current values into a file. This option is only available if used in combination with -enable_em.
-voltage	Sets the voltage on a specific net. If this option is not set, the Liberty file's voltage value is obtained from operating conditions.
-node_density	Node density (in microns) on the standard cell rails. It cannot be used together with -node_density_factor.
-node_density_factor	Factor which is multiplied by standard cell height to determine the node density on the std cell rails. It cannot be used together with -node_density. The default value is 5, and the allowed values are integers [0, MAX_INT].
-corner	Corner to use for analysis.

## Check Power Grid

```
check_power_grid -net net_name
```

### Options

Switch Name	Description
-net	Name of the net to analyze. Must be a power or ground net name.

## Write Spice Power Grid

```
write_pg_spice
  [-vsrc vsrc_file]
  [-outfile outfile]
  [-net net_name]
  [-dx bump_pitch_x]
  [-dy bump_pitch_y]
  [-corner corner]
```

### Options

Switch Name	Description
-vsrc	File to set the location of the power C4 bumps/IO pins. See Vsrc_aes.loc file for an example and its <a href="#">description</a> .
-dx,-dy	Set the bump pitch to decide the voltage source location in the absence of a vsrc file. The default bump pitch is 140um if neither these arguments nor a vsrc file are given.
-net	Name of the net to analyze. Must be a power or ground net name.
-outfile	Write per-instance voltage written into the file.
-corner	Corner to use for analysis.

## Set PDNSim Net voltage

```
set_pdnsim_net_voltage
  [-net net_name]
  [-voltage volt]
```

## Options

Switch Name	Description
-net	Name of the net to analyze. It must be a power or ground net name.
-voltage	Sets the voltage on a specific net. If this option is not given, the Liberty file's voltage value is obtained from operating conditions.

## Useful Developer Commands

If you are a developer, you might find these useful. More details can be found in the source file or the swig file.

Command Name	Description
find_net	Get a reference to net name.

## Example scripts

Example scripts demonstrating how to run PDNSim on a sample design on aes as follows:

```
./test/aes_test_vdd.tcl  
./test/aes_test_vss.tcl
```

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

## FAQs

Check out [GitHub discussion](#) about this tool.

## References

1. PDNSIM documentation
2. Chhabria, V.A. and Sapatnekar, S.S. (no date) The-openroad-project/pdnsim: Power Grid Analysis, GitHub. Available at: <https://github.com/The-OpenROAD-Project/PDNSim> (Accessed: 24 July 2023). ([link](#))

## License

BSD 3-Clause License. See LICENSE file.

### Voltage source location file description

This file specifies the description of the C4 bump configurations file. The file is a csv as described below:

```
<x_coordinate>, <y_coordinate>, <octagonal_c4_bump_edge_length>, <voltage_value>
```

The x and y coordinate specify the center location of the voltage C4 bumps in micro meter.

The octagonal c4\_edge\_length specifies the edge length of the C4 to determine the pitch of the RDL layer in micron

Voltage\_value specifies the value of voltage source at the C4 bump. In case there is a need to specify voltage drop in micron

### Example file

```
250,250,20,1.1
130,170,20,1.1
370,410,10,1.1
410,450,10,1.1
```

## 5.2.17 Global Placement

The global placement module in OpenROAD (gp1) is based on the open-source RePLACE tool, from the paper “Advancing Solution Quality and Routability Validation in Global Placement”.

Features:

- Analytic and nonlinear placement algorithm. Solves electrostatic force equations using Nesterov’s method. ([link](#))
- Verified with various commercial technologies and research enablements using OpenDB (7/14/16/28/45/55/65nm).
- Verified deterministic solution generation with various compilers and OS.
- Supports Mixed-size placement mode.

	Visualized examples from ISPD 2006 contest; adaptec2.inf	Real-world Design: Coyote (TSMC16 7.5T)
--	----------------------------------------------------------	-----------------------------------------

## Commands

---

### Note:

- Parameters in square brackets [-param param] are optional.
  - Parameters without square brackets -param2 param2 are required.
- 

## Global Placement

When using the `-timing_driven` flag, gpl does a virtual `repair_design` to find slacks and weight nets with low slack. It adjusts the worst slacks (modified with `-timing_driven_nets_percentage`) using a multiplier (modified with `-timing_driven_net_weight_max`). The multiplier is scaled from the full value for the worst slack, to 1.0 at the `timing_driven_nets_percentage` point. Use the `set_wire_rc` command to set resistance and capacitance of estimated wires used for timing.

```
global_placement
  [-timing_driven]
  [-routability_driven]
  [-skip_initial_place]
  [-incremental]
  [-bin_grid_count grid_count]
  [-density target_density]
  [-init_density_penalty init_density_penalty]
  [-init_wirelength_coef init_wirelength_coef]
  [-min_phi_coef min_phi_conef]
  [-max_phi_coef max_phi_coef]
  [-overflow overflow]
  [-initial_place_max_iter initial_place_max_iter]
  [-initial_place_max_fanout initial_place_max_fanout]
  [-pad_left pad_left]
  [-pad_right pad_right]
  [-verbose_level level]
  [-force_cpu]
  [-skip_io]
  [-routability_check_overflow routability_check_overflow]
  [-routability_max_density routability_max_density]
  [-routability_max_bloat_iter routability_max_bloat_iter]
  [-routability_max_inflation_iter routability_max_inflation_iter]
  [-routability_target_rc_metric routability_target_rc_metric]
  [-routability_inflation_ratio_coef routability_inflation_ratio_coef]
  [-routability_pitch_scale routability_pitch_scale]
  [-routability_max_inflation_ratio routability_max_inflation_ratio]
  [-routability_rc_coefficients routability_rc_coefficients]
  [-timing_driven_net_reweight_overflow]
  [-timing_driven_net_weight_max]
  [-timing_driven_nets_percentage]
```

## General Arguments

Switch Name	Description
-timing_driven	Enable timing-driven mode. See <a href="#">link</a> for timing-specific arguments.
-routability_driven	Routability-driven mode. See <a href="#">link</a> for routability-specific arguments.
-skip_initial	Skip the initial placement (Biconjugate gradient stabilized, or BiCGSTAB solving) before Nesterov placement. Initial placement improves HPWL by ~5% on large designs. Equivalent to -initial_place_max_iter 0.
-incremental	Enable the incremental global placement. Users would need to tune other parameters (e.g., <code>init_density_penalty</code> ) with pre-placed solutions.
-bin_grid_count	Set bin grid's counts. The internal heuristic defines the default value. Allowed values are integers [64, 128, 256, 512, ...].
-density	Set target density. The default value is 0.7 (i.e., 70%). Allowed values are floats [0, 1].
-init_density	Set initial density penalty. The default value is 8e-5. Allowed values are floats [1e-6, 1e6].
-init_wirelength	Set initial wirelength coefficient. The default value is 0.25. Allowed values are floats.
-min_phi_coef	Set pcof_min ( $\mu_k$ Lower Bound). The default value is 0.95. Allowed values are floats [0.95, 1.05].
-max_phi_coef	Set pcof_max ( $\mu_k$ Upper Bound). Default value is 1.05. Allowed values are [1.00-1.20, float].
-overflow	Set target overflow for termination condition. The default value is 0.1. Allowed values are floats [0, 1].
-initial_place_max_iter	Set maximum iterations in the initial place. The default value is 20. Allowed values are integers [0, MAX_INT].
-initial_place_max_fanout	Set fanout condition in initial place when $fanout \geq initial\_place\_max\_fanout$ . The default value is 200. Allowed values are integers [1, MAX_INT].
-pad_left	Set left padding in terms of number of sites. The default value is 0, and the allowed values are integers [1, MAX_INT]
-pad_right	Set right padding in terms of number of sites. The default value is 0, and the allowed values are integers [1, MAX_INT]
-verbose_level	Set verbose level for gpl. The default value is 1. Allowed values are integers [0, 5].
-force_cpu	Force to use the CPU solver even if the GPU is available.
-skip_io	Flag to ignore the IO ports when computing wirelength during placement. The default value is False, allowed values are boolean.

## Routability-Driven Arguments

Switch Name	Description
-routability_check	Set overflow threshold for routability mode. The default value is 0.2, and the allowed values are floats [0, 1].
-routability_max_density	Density threshold for routability mode. The default value is 0.99, and the allowed values are floats [0, 1].
-routability_max_knob_loops	Knob iteration threshold for routability mode. The default value is 1, and the allowed values are integers [1, MAX_INT].
-routability_max_lsf_inflation_iteration	Lsf inflation iteration threshold for routability mode. The default value is 4, and the allowed values are integers [1, MAX_INT].
-routability_target_rc	Set target RC metric for routability mode. The default value is 1.25, and the allowed values are floats.
-routability_inflation_ratio	Set inflation ratio efficient for routability mode. The default value is 2.5, and the allowed values are floats.
-routability_max_lsf_inflation_ratio	Lsf inflation ratio threshold for routability mode. The default value is 2.5, and the allowed values are floats.
-routability_rc_coefficients	RC coefficients. It comes in the form of a Tcl List {k1, k2, k3, k4}. The default value for each coefficient is {1.0, 1.0, 0.0, 0.0} respectively, and the allowed values are floats.

## Timing-Driven Arguments

Switch Name	Description
-timing_driven_net_reweight	Set overflow threshold for timing-driven net reweighting. Allowed value is a Tcl list of integers where each number is [0, 100].
-timing_driven_net_weight	Smash multiplier for the most timing-critical nets. The default value is 1.9, and the allowed values are floats.
-timing_driven_nets_percent	State reweighted percentage of nets in timing-driven mode. The default value is 10. Allowed values are floats [0, 100].

## Useful developer functions

If you are a developer, you might find these useful. More details can be found in the source file or the swig file.

```
# debugging global placement
global_placement_debug -pause -update -inst -draw_bins -initial

# adds padding and gets global placement uniform target density
get_global_placement_uniform_density -pad_left -pad_right
```

## Cluster Flops

Cluster single bit flops into multi-bit flops.

```
cluster_flops
  [-tray_weight tray_weight]
  [-timing_weight timing_weight]
  [-max_split_size max_split_size]
  [-num_paths num_paths]
```

## General Arguments

Switch Name	Description
-tray_weight	Set the weighting factor for tray cost (recommended to be [20.0, float]).
-timing_weight	Set the weighting factor for timing-critical paths in (recommended to be [1.0, float]).
-max_split_size	The maximum size of a single pointset after running the pointset decomposition algorithm for runtime improvement (default = 250).
num_paths	Number of timing-critical paths to consider (default = 0).

## Example Scripts

Example scripts demonstrating how to run gpl on a sample design on core01 as follows:

```
./test/core01.tcl
```

## Regression tests

There are a set of regression tests in ./test. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

### Using the Python interface to gpl

This API tries to stay close to the API defined in C++ class Replace that is located here.

When initializing a design, a sequence of Python commands might look like the following:

```
from openroad import Design, Tech
tech = Tech()
tech.readLef(...)
design = Design(tech)
design.readDef(...)
gpl = design.getReplace()
```

Here is an example of some options / configurations to the global placer. (See Replace.h for a complete list)

```
gpl.setInitialPlaceMaxIter(itter)
gpl.setSkipIoMode(skip_io)
gpl.setTimingDrivenMode(timing_driven)
gpl.setTimingNetWeightMax(weight)
```

There are some useful Python functions located in the file *grt\_aux.py* but these are not considered a part of the *final* API and they may change.

### FAQs

Check out [GitHub discussion](#) about this tool.

### References

- C.-K. Cheng, A. B. Kahng, I. Kang and L. Wang, “RePlAce: Advancing Solution Quality and Routability Validation in Global Placement”, IEEE Transactions on Computer-Aided Design of Integrated Circuits and Systems, 38(9) (2019), pp. 1717-1730. ([.pdf](#))
- J. Lu, P. Chen, C.-C. Chang, L. Sha, D. J.-H. Huang, C.-C. Teng and C.-K. Cheng, “ePlace: Electrostatics based Placement using Fast Fourier Transform and Nesterov’s Method”, ACM TODAES 20(2) (2015), article 17. ([.pdf](#))
- J. Lu, H. Zhuang, P. Chen, H. Chang, C.-C. Chang, Y.-C. Wong, L. Sha, D. J.-H. Huang, Y. Luo, C.-C. Teng and C.-K. Cheng, “ePlace-MS: Electrostatics based Placement for Mixed-Size Circuits”, IEEE TCAD 34(5) (2015), pp. 685-698. ([.pdf](#))
- A. B. Kahng, J. Li and L. Wang,  
“Improved Flop Tray-Based Design Implementation for Power Reduction”,  
IEEE/ACM ICCAD, 2016, pp. 20:1-20:8.
- The timing-driven mode has been implemented by Mingyu Woo (only available in [legacy](#) repo in standalone branch.)
- The routability-driven mode has been implemented by Mingyu Woo.
- Timing-driven mode re-implementation is ongoing with the current clean-code structure.

### Authors

- Authors/maintainer since Jan 2020: Mingyu Woo (Ph.D. Advisor: Andrew. B. Kahng)
- Original open-sourcing of RePlAce: August 2018, by Ilgweon Kang (Ph.D. Advisor: Chung-Kuan Cheng), Lutong Wang (Ph.D. Advisor: Andrew B. Kahng), and Mingyu Woo (Ph.D. Advisor: Andrew B. Kahng).
- Also thanks to Dr. Jingwei Lu for open-sourcing the previous ePlace-MS/ePlace project code.

## License

BSD 3-Clause License. See LICENSE file.

### 5.2.18 Gate Resizer

Gate Resizer commands are described below. The resizer commands stop when the design area is `-max_utilization` util percent of the core area. `util` is between 0 and 100. The resizer stops and reports an error if the max utilization is exceeded.

## Commands

### Note:

- Parameters in square brackets `[-param param]` are optional.
- Parameters without square brackets `-param2 param2` are required.

## Set Wire RC

The `set_wire_rc` command sets the resistance and capacitance used to estimate delay of routing wires. Separate values can be specified for clock and data nets with the `-signal` and `-clock` flags. Without either `-signal` or `-clock` the resistance and capacitance for clocks and data nets are set.

```
set_wire_rc
  [-clock]
  [-signal]
  [-layer layer_name]

or

set_wire_rc
  [-resistance res]
  [-capacitance cap]
```

## Options

Switch Name	Description
<code>-clock</code>	Enable setting of RC for clock nets.
<code>-signal</code>	Enable setting of RC for signal nets.
<code>-layer</code>	Use the LEF technology resistance and area/edge capacitance values for the layer. This is used for a default width wire on the layer.
<code>-resistance</code>	Resistance per unit length, units are from the first Liberty file read, usually in the form of $\frac{resistanceUnit}{distanceUnit}$ . Usually k/ $\mu$ m.
<code>-capacitance</code>	Capacitance per unit length, units are from the first Liberty file read, usually in the form of $\frac{capacitanceUnit}{distanceUnit}$ . Usually pF/ $\mu$ m.

## Set Layer RC

The `set_layer_rc` command can be used to set the resistance and capacitance for a layer or via. This is useful if these values are missing from the LEF file, or to override the values in the LEF.

```
set_layer_rc
[-layer layer]
[-via via_layer]
[-resistance res]
[-capacitance cap]
[-corner corner]
```

### Options

Switch Name	Description
<code>-layer</code>	Set layer name to modify. Note that the layer must be a routing layer.
<code>-via</code>	Select via layer name. Note that via resistance is per cut/via, not area-based.
<code>-resistance</code>	Resistance per unit length, same convention as <code>set_wire_rc</code> .
<code>-capacitance</code>	Capacitance per unit length, same convention as <code>set_wire_rc</code> .
<code>-corner</code>	Process corner to use.

## Estimate Parasitics

Estimate RC parasitics based on placed component pin locations. If there are no component locations, then no parasitics are added. The resistance and capacitance values are per distance unit of a routing wire. Use the `set_units` command to check units or `set_cmd_units` to change units. The goal is to represent “average” routing layer resistance and capacitance. If the `set_wire_rc` command is not called before resizing, then the `default_wireload` model specified in the first Liberty file read or with the SDC `set_wire_load` command is used to make parasitics.

After the `global_route` command has been called, the global routing topology and layers can be used to estimate parasitics with the `-global_routing` flag.

```
estimate_parasitics
-placement | -global_routing
```

### Options

Switch Name	Description
<code>-placement</code> or <code>-global_routing</code>	Either of these flags must be set. Parasitics are estimated based after placement stage versus after global routing stage.

## Set Don't Use

The `set_dont_use` command removes library cells from consideration by the resizer engine and the CTS engine. `lib_cells` is a list of cells returned by `get_lib_cells` or a list of cell names (wildcards allowed). For example, `DLY*` says do not use cells with names that begin with DLY in all libraries.

```
set_dont_use lib_cells
unset_dont_use lib_cells
```

## Set Don't Touch

The `set_dont_touch` command prevents the resizer commands from modifying instances or nets.

```
set_dont_touch instances_nets
unset_dont_touch instances_nets
```

## Buffer Ports

The `buffer_ports -inputs` command adds a buffer between the input and its loads. The `buffer_ports -outputs` adds a buffer between the port driver and the output port. Inserting buffers on input and output ports makes the block input capacitances and output drives independent of the block internals.

```
buffer_ports
  [-inputs]
  [-outputs]
  [-max_utilization util]
```

## Options

Switch Name	Description
<code>-inputs</code> , <code>-outputs</code>	Insert a buffer between the input and load, output and load respectively. The default behavior is <code>-inputs</code> and <code>-outputs</code> set if neither is specified.
<code>-max_utilization</code>	Defines the percentage of core area used.

## Remove Buffers

Use the `remove_buffers` command to remove buffers inserted by synthesis. This step is recommended before using `repair_design` so that there is more flexibility in buffering nets.

```
remove_buffers
```

## Repair Design

The `repair_design` command inserts buffers on nets to repair max slew, max capacitance and max fanout violations, and on long wires to reduce RC delay in the wire. It also resizes gates to normalize slews. Use `estimate_parasitics -placement` before `repair_design` to estimate parasitics considered during repair. Placement-based parasitics cannot accurately predict routed parasitics, so a margin can be used to “over-repair” the design to compensate.

```
repair_design
[-max_wire_length max_length]
[-slew_margin slew_margin]
[-cap_margin cap_margin]
[-max_utilization util]
[-verbose]
```

## Options

Switch Name	Description
<code>-max_wire_length</code>	Maximum length of wires (in microns), defaults to a value that minimizes the wire delay for the wire RC values specified by <code>set_wire_rc</code> .
<code>-slew_margin</code>	Add a slew margin. The default value is 0, the allowed values are integers [0, 100].
<code>-cap_margin</code>	Add a capacitance margin. The default value is 0, the allowed values are integers [0, 100].
<code>-max_utilization</code>	Defines the percentage of core area used.
<code>-verbose</code>	Enable verbose logging on progress of the repair.

## Repair Tie Fanout

The `repair_tie_fanout` command connects each tie high/low load to a copy of the tie high/low cell.

```
repair_tie_fanout
[-separation dist]
[-verbose]
lib_port
```

## Options

Switch Name	Description
<code>-separation</code>	Tie high/low insts are separated from the load by this value (Liberty units, usually microns).
<code>-verbose</code>	Enable verbose logging of repair progress.
<code>lib_port</code>	Tie high/low port, which can be a library/cell/port name or object returned by <code>get_lib_pins</code> .

## Repair Timing

The `repair_timing` command repairs setup and hold violations. It should be run after clock tree synthesis with propagated clocks. Setup repair is done before hold repair so that hold repair does not cause setup checks to fail.

The worst setup path is always repaired. Next, violating paths to endpoints are repaired to reduced the total negative slack.

```
repair_timing
  [-setup]
  [-hold]
  [-recover_power percent_of_paths_with_slack]
  [-setup_margin setup_margin]
  [-hold_margin hold_margin]
  [-allow_setup_violations]
  [-skip_pin_swap]
  [-skip_gate_cloning]
  [-repair_tns tns_end_percent]
  [-max_utilization util]
  [-max_buffer_percent buffer_percent]
  [-verbose]
```

## Options

Switch Name	Description
<code>-setup</code>	Repair setup timing.
<code>-hold</code>	Repair hold timing.
<code>-recover_power</code>	Set the percentage of paths to recover power for. The default value is 0, and the allowed values are floats [0, 100].
<code>-setup_margin</code>	Add additional setup slack margin.
<code>-hold_margin</code>	Add additional hold slack margin.
<code>-allow_setup</code>	Whille repairing hold violations, buffers are not inserted that will cause setup violations unless <code>-allow_setup_violations</code> is specified.
<code>-skip_pin_swap</code>	Flag to skip pin swap. The default value is False, and the allowed values are bools.
<code>-skip_gate_cloning</code>	Flag to skip gate cloning. The default value is False, and the allowed values are bools.
<code>-repair_tns</code>	Percentage of violating endpoints to repair (0-100). When <code>tns_end_percent</code> is zero (the default), only the worst endpoint is repaired. When <code>tns_end_percent</code> is 100, all violating endpoints are repaired.
<code>-max_utilization</code>	Defines the percentage of core area used.
<code>-max_buffer_percent</code>	Specify a maximum number of buffers to insert to repair hold violations as a percentage of the number of instances in the design. The default value is 20, and the allowed values are integers [0, 100].
<code>-verbose</code>	Enable verbose logging of the repair progress.

Use `-recover_power` to specify the percent of paths with positive slack which will be considered for gate resizing to save power. It is recommended that this option be used with global routing based parasitics.

## Repair Clock Nets

The `clock_tree_synthesis` command inserts a clock tree in the design but may leave a long wire from the clock input pin to the clock tree root buffer. The `repair_clock_nets` command inserts buffers in the wire from the clock input pin to the clock root buffer.

```
repair_clock_nets  
[-max_wire_length max_wire_length]
```

### Options

Switch Name	Description
<code>-max_wire_length</code>	Maximum length of wires (in microns), defaults to a value that minimizes the wire delay for the wire RC values specified by <code>set_wire_rc</code> .

## Repair Clock Inverters

The `repair_clock_inverters` command replaces an inverter in the clock tree with multiple fanouts with one inverter per fanout. This prevents the inverter from splitting up the clock tree seen by CTS. It should be run before `clock_tree_synthesis`.

```
repair_clock_inverters
```

## Report Design Area

The `report_design_area` command reports the area of the design's components and the utilization.

```
report_design_area
```

## Report Floating Nets

The `report_floating_nets` command reports nets with only one pin connection.

```
report_floating_nets  
[-verbose]
```

### Options

Switch Name	Description
<code>-verbose</code>	Print the net names.

## Useful Developer Commands

If you are a developer, you might find these useful. More details can be found in the source file or the swig file.

Command Name	Description
repair_setup_pin	Repair setup pin violation.
check_parasitics	Check if the estimate_parasitics command has been called.
parse_time_margin_arg	Get the raw value for timing margin (e.g. slack_margin, setup_margin, hold_margin)
parse_percent_margin_arg	Get the above margin in percentage format.
parse_margin_arg	Same as parse_percent_margin_arg.
parse_max_util	Check maximum utilization.
parse_max_wire_length	Get maximum wirelength.
check_corner_wire_caps	Check wire capacitance for corner.
check_max_wire_length	Check if wirelength is allowed by rsz for minimum delay.
dblayer_wire_rc	Get layer RC values.
set dblayer_wire_rc	Set layer RC values.

## Example scripts

A typical resizer command file (after a design and Liberty libraries have been read) is shown below.

```
read_sdc gcd.sdc

set_wire_rc -layer metal2

set_dont_use {CLKBUF_* AOI211_X1 OAI211_X1}

buffer_ports
repair_design -max_wire_length 100
repair.tie_fanout LOGIC0_X1/Z
repair.tie_fanout LOGIC1_X1/Z
# clock tree synthesis...
repair_timing
```

Note that OpenSTA commands can be used to report timing metrics before or after resizing the design.

```
set_wire_rc -layer metal2
report_checks
report_tns
report_wns
report_checks

repair_design

report_checks
report_tns
report_wns
```

### Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

### Limitations

### FAQs

Check out [GitHub discussion](#) about this tool.

### License

BSD 3-Clause License. See *LICENSE* file.

## 5.2.19 Detailed Placement

The detailed placement module in OpenROAD (dp1) is based on OpenDP, or Open-Source Detailed Placement Engine. Its key features are:

- Fence region.
- Fragmented ROWs.

### Commands

#### Detailed Placement

The `detailed_placement` command performs detailed placement of instances to legal locations after global placement.

```
detailed_placement
  [-max_displacement disp|{disp_x disp_y}]
  [-disallow_one_site_gaps]
  [-report_file_name filename]
```

### Options

Switch Name	Description
<code>-max_displacement</code>	Max distance that an instance can be moved (in microns) when finding a site where it can be placed. Either set one value for both directions or set <code>{disp_x disp_y}</code> for individual directions. The default values are <code>{0, 0}</code> , and the allowed values within are integers <code>[0, MAX_INT]</code> .
<code>-disallow_one_site_gaps</code>	Disable long gaps gap during placement check.
<code>-report_file_name</code>	File name for saving the report to (e.g. <code>report.json</code> ).

## Set Placement Padding

The `set_placement_padding` command sets left and right padding in multiples of the row site width. Use the `set_placement_padding` command before legalizing placement to leave room for routing. Use the `-global` flag for padding that applies to all instances. Use `-instances` for instance-specific padding. The instances `insts` can be a list of instance names, or an instance object returned by the SDC `get_cells` command. To specify padding for all instances of a common master, use the `-filter "ref_name == "` option to `get_cells`.

```
set_placement_padding
  -global|-masters masters|-instances insts
  [-right site_count]
  [-left site_count]
```

## Options

**Warning:** Either one of these flags must be set: `-global` | `-masters` | `-instances`. The order of preference is `global > masters > instances`

Switch Name	Description
<code>-global</code>	Set padding globally using <code>left</code> and <code>right</code> values.
<code>-masters</code>	Set padding only for these masters using <code>left</code> and <code>right</code> values.
<code>-instances</code>	For <code>-instances</code> , you will set padding only for these <code>insts</code> using <code>left</code> and <code>right</code> values.
<code>-left</code>	Left padding (in site count).
<code>-right</code>	Right padding (in site count).
<code>instances</code>	Set padding for these list of instances. Not to be confused with the <code>-instances</code> switch above.

## Filler Placement

The `filler_placement` command fills gaps between detail-placed instances to connect the power and ground rails in the rows. `filler_masters` is a list of master/macro names to use for filling the gaps. Wildcard matching is supported, so `FILL*` will match, e.g., `FILLCELL_X1 FILLCELL_X16 FILLCELL_X2 FILLCELL_X32 FILLCELL_X4 FILLCELL_X8`. To specify a different naming prefix from `FILLER_` use `-prefix <new prefix>`.

```
filler_placement
  [-prefix prefix]
  filler_masters
```

## Options

Switch Name	Description
<code>-prefix</code>	Prefix to name the filler cells. The default value is <code>FILLER_</code> .
<code>filler_masters</code>	Filler master cells.

## Remove Fillers

This command removes all filler cells.

```
remove_fillers
```

No arguments are needed for this function.

## Check Placement

The `check_placement` command checks the placement legality. It returns `0` if the placement is legal.

```
check_placement
  [-verbose]
  [-disallow_one_site_gaps]
  [-report_filename filename]
```

## Options

Switch Name	Description
<code>-verbose</code>	Enable verbose logging.
<code>-disallow_one_site_gaps</code>	Disable one site gap during placement check.
<code>-report_file_name</code>	File name for saving the report to (e.g. <code>report.json</code> ).

## Optimize Mirroring

The `optimize_mirroring` command mirrors instances about the Y axis in a weak attempt to reduce the total half-perimeter wirelength (HPWL).

```
optimize_mirroring
```

No arguments are needed for this function.

## Useful Developer Commands

If you are a developer, you might find these useful. More details can be found in the source file or the swig file.

Command Name	Description
<code>detailed_placement_debug</code>	Debug detailed placement.
<code>get_masters_arg</code>	Get masters from a design.
<code>get_inst_bbox</code>	Get bounding box of an instance.
<code>get_inst_grid_bbox</code>	Get grid bounding box of an instance.
<code>format_grid</code>	Format grid (takes in length <code>x</code> and site width <code>w</code> as inputs).
<code>get_row_site</code>	Get row site name.

## Example scripts

Examples scripts demonstrating how to run dpl on a sample design of aes as follows:

```
./test/aes.tcl
```

## Regression tests

There are a set of regression tests in ./test. Refer to this [section](#) for more information.

Simply run the following script:

```
./test/regression
```

## Limitations

## FAQs

Check out [GitHub discussion](#) about this tool.

## Authors

- SangGi Do and Mingyu Woo (respective Ph. D. advisors: Seokhyeong Kang, Andrew B. Kahng).
- Rewrite and port to OpenDB/OpenROAD by James Cherry, Parallax Software

## References

1. Do, S., Woo, M., & Kang, S. (2019, May). Fence-region-aware mixed-height standard cell legalization. In Proceedings of the 2019 on Great Lakes Symposium on VLSI (pp. 259-262). ([.pdf](#))

## License

BSD 3-Clause License. See LICENSE file.

## 5.2.20 Clock Tree Synthesis

The clock tree synthesis module in OpenROAD (cts) is based on TritonCTS 2.0. It is available from the `clock_tree_synthesis` command. TritonCTS 2.0 performs on-the-fly characterization. Thus, there is no need to generate characterization data. The on-the-fly characterization feature can be optionally controlled by parameters specified by the `configure_cts_characterization` command. Use `set_wire_rc` command to set the clock routing layer.

## Commands

### Note:

- Parameters in square brackets [-param param] are optional.
- Parameters without square brackets -param2 param2 are required.

## Configure CTS Characterization

```
configure_cts_characterization
  [-max_slew max_slew]
  [-max_cap max_cap]
  [-slew_steps slew_steps]
  [-cap_steps cap_steps]
```

## Options

Switch Name	Description
-max_slew	Max slew value (in the current time unit) that the characterization will test. If this parameter is omitted, the code would use max slew value for specified buffer in buf_list from liberty file.
-max_cap	Max capacitance value (in the current capacitance unit) that the characterization will test. If this parameter is omitted, the code would use max cap value for specified buffer in buf_list from liberty file.
-slew_steps	Number of steps that max_slew will be divided into for characterization. The default value is 12, and the allowed values are integers [0, MAX_INT].
-cap_steps	Number of steps that max_cap will be divided into for characterization. The default value is 34, and the allowed values are integers [0, MAX_INT].

## Clock Tree Synthesis

```
clock_tree_synthesis
  -buf_list <list_of_buffers>
  [-root_buf root_buf]
  [-wire_unit wire_unit]
  [-clk_nets <list_of_clk_nets>]
  [-distance_between_buffers]
  [-branching_point_buffers_distance]
  [-clustering_exponent]
  [-clustering_unbalance_ratio]
  [-sink_clustering_enable]
  [-sink_clustering_size cluster_size]
  [-sink_clustering_max_diameter max_diameter]
  [-balance_levels]
  [-num_static_layers]
  [-sink_clustering_buffer]
  [-use_dummy_load]
```

(continues on next page)

(continued from previous page)

```
[-insertion_delay]
[-sink_buffer_max_cap_derate derate_value]
[-delay_buffer_derate derate_value]
```

## Options

Switch Name	Description
-buf_list	Tcl list of master cells (buffers) that will be considered when making the wire segments (e.g. {BUFXX, BUFYY}).
-root_buffer	The master cell of the buffer that serves as root for the clock tree. If this parameter is omitted, the first master cell from -buf_list is taken.
-wire_unit	Minimum unit distance between buffers for a specific wire. If this parameter is omitted, the code gets the value from ten times the height of -root_buffer.
-clk_nets	String containing the names of the clock roots. If this parameter is omitted, cts automatically looks for the clock roots automatically.
-distance_between_buffers	Distance (in microns) between buffers that cts should use when creating the tree. When using this parameter, the clock tree algorithm is simplified and only uses a fraction of the segments from the LUT.
-branching_point	Distance (in microns) that a branch has to have in order for a buffer to be inserted on a branch endpoint. This requires the -distance_between_buffers value to be set.
-clustering_exponeat	Exponent that determines the power used on the difference between sink and means on the CKMeans clustering algorithm. The default value is 4, and the allowed values are integers [0, MAX_INT].
-clustering_weight_interpolate	Weight of intermediate cluster's maximum capacity during CKMeans. A value of 0.5 (i.e., 50%) means that each cluster will have exactly half of all sinks for a specific region (half for each branch). The default value is 0.6, and the allowed values are floats [0, 1.0].
-sink_cluster	Implementation of clustering of sinks to create one level of sub-tree before building H-tree. Each cluster is driven by buffer which becomes end point of H-tree structure.
-sink_clustersize	Sink size, i.e. the maximum number of sinks per cluster. The default value is 20, and the allowed values are integers [0, MAX_INT].
-sink_clusterdiameter	Sink size and diameter (in microns) of sink cluster. The default value is 50, and the allowed values are integers [0, MAX_INT].
-balance_levels	Attempt to keep a similar number of levels in the clock tree across non-register cells (e.g., clock-gate or inverter). The default value is False, and the allowed values are bool.
-clk_nets	String containing the names of the clock roots. If this parameter is omitted, cts looks for the clock roots automatically.
-num_static_layers	Specifies the number of static layers. The default value is 0, and the allowed values are integers [0, MAX_INT].
-sink_clustersize	Sink size of clustered buffer(s) to be used.
-obstruction_avoidance	Enables obstruction-aware buffering such that clock buffers are not placed on top of blockages or hard macros. This option may reduce legalizer displacement, leading to better latency, skew or timing QoR. The default value is False, and the allowed values are bool.
-apply_ndr	Applies 2X spacing non-default rule to all clock nets except leaf-level nets. The default value is False.
-no_insertion_delay	Doesn't consider insertion delays in macro timing models in balancing latencies between macro cells and registers. This option prevents construction of separate clock trees for macro cells and registers. The default value is False.
-use_dummy_load	Applies dummy buffer or inverter cells at clock tree leaves to balance loads. The default values is False.
-sink_buffer_max_derate	Max derate to control automatic buffer selection. To favor strong(weak) drive strength buffers use a small(large) value. The default value is 0.01, meaning that buffers are selected by derating max cap limit by 0.01. The value of 1.0 means no derating of max cap limit.
-delay_buffer	This option is used with -insertion_delay option that balances latencies between macro cells and registers by inserting delay buffers. The default values is 1.0, meaning all needed delay buffers are inserted. Value of 0.5 means only half of necessary delay buffers are inserted. Value of 0.0 means no insertion of delay buffers.

## Report CTS

Another command available from `cts` is `report_cts`. It is used to extract metrics after a successful `clock_tree_synthesis` run. These are:

- Number of Clock Roots
- Number of Buffers Inserted
- Number of Clock Subnets
- Number of Sinks.

```
report_cts
    [-out_file file]
```

## Options

Switch Name	Description
<code>-out_file</code>	The file to save <code>cts</code> reports. If this parameter is omitted, the report is streamed to <code>stdout</code> and not saved.

## Useful Developer Commands

If you are a developer, you might find these useful. More details can be found in the source file or the swig file.

Command Name	Description
<code>clock_tree_synthesis_debug</code>	Option to plot the CTS to GUI.

## Example scripts

```
clock_tree_synthesis -root_buf "BUF_X4" \
                     -buf_list "BUF_X4" \
                     -wire_unit 20
report_cts "file.txt"
```

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

### Limitations

### FAQs

Check out [GitHub discussion](#) about this tool.

### References

1. LEMON - Library for Efficient Modeling and Optimization in Networks
2. Kahng, A. B., Li, J., & Wang, L. (2016, November). Improved flop tray-based design implementation for power reduction. In 2016 IEEE/ACM International Conference on Computer-Aided Design (ICCAD) (pp. 1-8). IEEE. ([.pdf](#))

### Authors

TritonCTS 2.0 is written by Mateus Fogaça, PhD student in the Graduate Program on Microelectronics from the Federal University of Rio Grande do Sul (UFRGS), Brazil. Mr. Fogaça's advisor is Prof. Ricardo Reis.

Many guidance provided by (alphabetic order):

- Andrew B. Kahng
- Jiajia Li
- Kwangsoo Han
- Tom Spyrou

### License

BSD 3-Clause License. See LICENSE file.

### 5.2.21 Global Routing

The global routing module in OpenROAD (grt) is based on FastRoute, an open-source global router originally derived from Iowa State University's FastRoute4.1 algorithm.

### Commands

---

#### Note:

- Parameters in square brackets [-param param] are optional.
  - Parameters without square brackets -param2 param2 are required.
-

## Global Route

```
global_route
  [-guide_file out_file]
  [-congestion_iterations iterations]
  [-congestion_report_file file_name]
  [-congestion_report_iter_step steps]
  [-grid_origin {x y}]
  [-critical_nets_percentage percent]
  [-allow_congestion]
  [-verbose]
  [-start_incremental]
  [-end_incremental]
```

## Options

Switch Name	Description
-guide_file	Set the output guides file name (e.g., route.guide).
-congestion_iterations	Number of iterations made to remove the overflow of the routing. The default value is 50, and the allowed values are integers [0, MAX_INT].
-congestion_report_file	Report file name to save the congestion report. The file generated can be read by the DRC viewer in the GUI (e.g., report_file.rpt).
-congestion_report_iter_step	Iterations to report. The default value is 0, and the allowed values are integers [0, MAX_INT].
-grid_origin	Set the (x, y) origin of the routing grid in DBU. For example, -grid_origin {1 1} corresponds to the die (0, 0) + 1 DBU in each x-, y- direction.
-critical_nets_percentage	Percentage of nets with the worst slack value that are considered timing critical, having preference over other nets during congestion iterations (e.g. -critical_nets_percentage 30). The default value is 0, and the allowed values are integers [0, MAX_INT].
-allow_congestion	Allow global routing results to be generated with remaining congestion. The default is false.
-verbose	This flag enables the full reporting of the global routing.
-start_incremental	This flag initializes the GRT listener to get the net modified. The default is false.
-end_incremental	This flag run incremental GRT with the nets modified. The default is false.

## Set Routing Layers

```
set_routing_layers  
  [-signal min-max]  
  [-clock min-max]
```

### Options

Switch Name	Description
-signal	Set the min and max routing signal layer (names) in this format “%s-%s”.
-clock	Set the min and max routing clock layer (names) in this format “%s-%s”.

Example: `set_routing_layers -signal Metal2-Metal10 -clock Metal6-Metal9`

## Set Macro Extension

```
set_macro_extension extension
```

### Options

Argument Name	Description
extension	Number of GCells added to the blockage boundaries from macros. A GCell is typically defined in terms of Mx routing tracks. The default GCell size is 15 M3 pitches.

Example: `set_macro_extension 2`

## Set Pin Offset

```
set_pin_offset offset
```

### Options

Argument Name	Description
offset	Pin offset in microns (must be a positive integer).

## Set Global Routing Layer Adjustment

The `set_global_routing_layer_adjustment` command sets routing resource adjustments in the routing layers of the design. Such adjustments reduce the number of routing tracks that the global router assumes to exist. This promotes the spreading of routing and reduces peak congestion, to reduce challenges for detailed routing.

```
set_global_routing_layer_adjustment layer adjustment
```

### Options

Argument Name	Description
<code>layer</code>	Integer for the layer number (e.g. for M1 you would use 1).
<code>adjustment</code>	Float indicating the percentage reduction of each edge in the specified layer.

You can set adjustment for a specific layer, e.g., `set_global_routing_layer_adjustment Metal4 0.5` reduces the routing resources of routing layer Metal4 by 50%. You can also set adjustment for all layers at once using `*`, e.g., `set_global_routing_layer_adjustment * 0.3` reduces the routing resources of all routing layers by 30%. And, you can also set resource adjustment for a layer range, e.g.: `set_global_routing_layer_adjustment Metal4-Metal8 0.3` reduces the routing resources of routing layers Metal4, Metal5, Metal6, Metal7 and Metal8 by 30%.

## Set Routing Alpha

By default the global router uses heuristic rectilinear Steiner minimum trees (RSMTs) as an initial basis to construct route guides. An RSMT tries to minimize the total wirelength needed to connect a given set of pins. The Prim-Dijkstra heuristic is an alternative net topology algorithm that supports a trade-off between total wirelength and maximum path depth from the net driver to its loads. The `set_routing_alpha` command enables the Prim/Dijkstra algorithm and sets the alpha parameter used to trade-off wirelength and path depth. Alpha is between 0.0 and 1.0. When alpha is 0.0 the net topology minimizes total wirelength (i.e. capacitance). When alpha is 1.0 it minimizes longest path between the driver and loads (i.e., maximum resistance). Typical values are 0.4-0.8. You can call it multiple times for different nets.

```
set_routing_alpha
[-net net_name]
[-min_fanout fanout]
[-min_hpwl hpwl]
[-clock_nets]
alpha
```

### Options

Switch Name	Description
<code>-net</code>	Net name.
<code>-min_fanout</code>	Set the minimum number for fanout.
<code>-min_hpwl</code>	Set the minimum half-perimeter wirelength (microns).
<code>-clock_nets</code>	Flag to set routing alpha for clock nets. The default value is <code>False</code> , and the allowed values are bools.
<code>alpha</code>	Set the trade-off value between wirelength and path depth. The allowed values are floats [0, 1].

Example: `set_routing_alpha -net clk 0.3` sets the alpha value of 0.3 for net *clk*.

### Set Global Routing Region Adjustment

```
set_global_routing_region_adjustment
  [lower_left_x lower_left_y upper_right_x upper_right_y]
  [-layer layer]
  [-adjustment adjustment]
```

#### Options

Switch Name	Description
<code>lower_left_x, lower_left_y, upper_right_x , upper_right_y</code>	Bounding box to consider.
<code>-layer</code>	Integer for the layer number (e.g. for M1 you would use 1).
<code>-adjustment</code>	Float indicating the percentage reduction of each edge in the specified layer.

Example: `set_global_routing_region_adjustment {1.5 2 20 30.5} -layer Metal4 -adjustment 0.7`

### Set Global Routing Randomness

The randomized global routing shuffles the order of the nets and randomly subtracts or adds to the capacities of a random set of edges.

```
set_global_routing_random
  [-seed seed]
  [-capacities_perturbation_percentage percent]
  [-perturbation_amount value]
```

#### Options

Switch Name	Description
<code>-seed</code>	Sets the random seed (must be non-zero for randomization).
<code>-capacities_perturbation_percentage</code>	Specifies the percentage of edges whose capacities are perturbed. By default, the edge capacities are perturbed by adding or subtracting 1 (track) from the original capacity.
<code>-perturbation_amount</code>	Sets the perturbation value of the edge capacities. This option is only meaningful when <code>-capacities_perturbation_percentage</code> is used.

Example: `set_global_routing_random -seed 42 \ -capacities_perturbation_percentage 50 \ -perturbation_amount 2`

## Set Specific Nets to Route

The `set_nets_to_route` command defines a list of nets to route. Only the nets defined in this command are routed, leaving the remaining nets without any global route guides.

```
set_nets_to_route
    net_names
```

### Options

Switch Name	Description
<code>net_names</code>	Tcl list of set of nets (e.g. <code>{net1, net2}</code> ).

## Repair Antennas

The `repair_antennas` command checks the global routing for antenna violations and repairs the violations by inserting diodes near the gates of the violating nets. By default the command runs only one iteration to repair antennas. Filler instances added by the `filler_placement` command should NOT be in the database when `repair_antennas` is called.

```
repair_antennas
    [diode_cell]
    [-iterations iterations]
    [-ratio_margin margin]
```

### Options

Switch Name	Description
<code>diode_cell</code>	Diode cell to fix antenna violations.
<code>-iterations</code>	Number of iterations. The default value is 1, and the allowed values are integers <code>[0, MAX_INT]</code> .
<code>-ratio_margin</code>	Add a margin to the antenna ratios. The default value is <code>0</code> , and the allowed values are integers <code>[0, 100]</code> .

See LEF/DEF 5.8 Language Reference, Appendix C, “Calculating and Fixing Process Antenna Violations” for a *description* of antenna violations.

If no `diode_cell` argument is specified the LEF cell with class CORE, ANTENNACELL will be used. If any repairs are made the filler instances are remove and must be placed with the `filler_placement` command.

If the LEF technology layer `ANTENNADIFFSIDEARARATIO` properties are constant instead of PWL, inserting diodes will not improve the antenna ratios, and thus, no diodes are inserted. The following warning message will be reported:

```
[WARNING GRT-0243] Unable to repair antennas on net with diodes.
```

## Write Global Routing Guides

```
write_guides file_name
```

Switch Name	Description
file_name	Guide file name.

Example: `write_guides route.guide.`

## Estimate Global Routing Parasitics

To estimate RC parasitics based on global route results, use the `-global_routing` option of the `estimate_parasitics` command.

---

**Note:** To see the function definition for `estimate_parasitics`, refer to [Resizer docs](#).

---

```
estimate_parasitics -global_routing
```

## Plot Global Routing Guides

The `draw_route_guides` command plots the route guides for a set of nets. To erase the route guides from the GUI, pass an empty list to this command: `draw_route_guides {}`.

```
draw_route_guides  
net_names  
[-show_pin_locations]
```

## Options

Switch Name	Description
net_names	Tcl list of set of nets (e.g. <code>{net1, net2}</code> ).
-show_pin_locations	Draw circles for the pin positions on the routing grid.

## Report Wirelength

The `report_wire_length` command reports the wire length of the nets. Use the `-global_route` and the `-detailed_route` flags to report the wire length from global and detailed routing, respectively. If none of these flags are used, the tool will identify the state of the design and report the wire length accordingly.

```
report_wire_length  
[-net net_list]  
[-file file]  
[-global_route]  
[-detailed_route]  
[-verbose]
```

## Options

Switch Name	Description
-net	List of nets to report the wirelength. Use * to report the wire length for all nets of the design.
-file	The name of the file for the wirelength report.
-global_route	Report the wire length of the global routing.
-detailed_route	Report the wire length of the detailed routing.
-verbose	This flag enables the full reporting of the layer-wise wirelength information.

Example: `report_wire_length -net {clk net60} -global_route -detailed_route -verbose -file out.csv`

## Debug Mode

The `global_route_debug` command allows you to start a debug mode to view the status of the Steiner Trees. It also allows you to dump the input positions for the Steiner tree creation of a net. This must be used before calling the `global_route` command. Set the name of the net and the trees that you want to visualize.

```
global_route_debug
  [-st]
  [-rst]
  [-tree2D]
  [-tree3D]
  [-saveSttInput file_name]
  [-net net_name]
```

## Options

Switch Name	Description
-st	Show the Steiner Tree generated by stt.
-rst	Show the Rectilinear Steiner Tree generated by grt.
-tree2D	Show the Rectilinear Steiner Tree generated by grt after the overflow iterations.
-tree3D	Show the 3D Rectilinear Steiner Tree post-layer assignment.
-saveSttInput	File name to save stt input of a net.
-net	The name of the net name to be displayed.

## Example scripts

Examples scripts demonstrating how to run FastRoute on a sample design of gcd as follows:

```
./test/gcd.tcl
```

### Read Global Routing Guides

```
read_guides file_name
```

### Options

Switch Name	Description
file_name	Path to global routing guide.

### Useful developer functions

If you are a developer, you might find these useful. More details can be found in the source file or the swig file.

Function Name	Description
check_routing_layer	Check if the layer is within the min/max routing layer specified.
parse_layer_name	Get routing layer number from layer name
parse_layer_range	Parses a range from layer_range argument of format (%s-%s). cmd argument is not used.
check_region	Checks the defined region if its within the die area.
define_layer_range	Provide a Tcl list of layers and automatically generate the min and max layers for signal routing.
define_clock_layer_range	Provide a Tcl list of layers and automatically generate the min and max layers for clock routing.
have_detailed_route	Checks if block has detailed route already.

### Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

### Limitations

#### Using the Python interface to grt

**Warning:** The Python interface is currently in development and is subject to change.

The Python API tries to stay close to the API defined in the C++ class `GlobalRouter` that is located here

When initializing a design, a sequence of Python commands might look like the following:

```
from openroad import Design, Tech
tech = Tech()
tech.readLef(...)
```

(continues on next page)

(continued from previous page)

```
design = Design(tech)
design.readDef(...)
gr = design.getGlobalRouter()
```

Here are some options to the `global_route` command. (See `GlobalRouter.h` for a complete list)

<code>gr.setGridOrigin(x, y)</code>	<code># int, default 0,0</code>
<code>gr.setCongestionReportFile(file_name)</code>	<code># string</code>
<code>gr.setOverflowIterations(n)</code>	<code># int, default 50</code>
<code>gr.setAllowCongestion(allowCongestion)</code>	<code># boolean, default False</code>
<code>gr.setCriticalNetsPercentage(percentage)</code>	<code># float</code>
<code>gr.setMinRoutingLayer(minLayer)</code>	<code># int</code>
<code>gr.setMaxRoutingLayer(maxLayer)</code>	<code># int</code>
<code>gr.setMinLayerForClock(minLayer)</code>	<code># int</code>
<code>gr.setMaxLayerForClock(maxLayer)</code>	<code># int</code>
<code>gr.setVerbose(v)</code>	<code># boolean, default False</code>

and when ready to actually do the global route:

```
gr.globalRoute(save_guides) # boolean, default False
```

If you have set `save_guides` to True, you can then save the guides in `file_name` with:

```
design.getBlock().writeGuides(file_name)
```

You can find the index of a named layer with

```
lindex = tech.getDB().getTech().findLayer(layer_name)
```

or, if you only have the Python design object

```
lindex = design.getTech().getDB().getTech().findLayer(layer_name)
```

Be aware that much of the error checking is done in Tc1, so that with the current C++ / Python API, that might be an issue to deal with. There are also some useful Python functions located in the `grt_aux.py` file but these are not considered a part of the *final* API and may be subject to change.

## FAQs

Check out [GitHub discussion](#) about this tool.

## References

- Database comes from [OpenDB](#)
- FastRoute 4.1 documentation. The FastRoute4.1 version was received from [Yue Xu](#) on June 15, 2019.
- Min Pan, Yue Xu, Yanheng Zhang and Chris Chu. “FastRoute: An Efficient and High-Quality Global Router. VLSI Design, Article ID 608362, 2012.” Available [here](#).
- C. J. Alpert, T. C. Hu, J. H. Huang, A. B. Kahng and D. Karger, “Prim-Dijkstra Tradeoffs for Improved Performance-Driven Global Routing”, IEEE Transactions on Computer-Aided Design of Integrated Circuits and Systems 14(7) (1995), pp. 890-896. Available [here](#).

## License

BSD 3-Clause License. See LICENSE file.

## Flute3

Flute3 is an open-source rectilinear Steiner minimum tree heuristic with improvements made by UFRGS students and James Cherry. This tool is used for the calculation of wirelength in `grt` and `rsz`.

The version in this repository uses CMake and C++ namespace, and has dynamic memory allocation. Flute3 can handle nets with any degree.

## External references (Optional)

The algorithm base is Flute3.1, extracted from the FastRoute4.1 version that was received from [yueyu@iastate.edu](mailto:yueyu@iastate.edu) on June 15, 2019, with the BSD-3 open source license as given in the FastRoute [website](#).

## License

See LICENSE file.

### 5.2.22 Antenna Rule Checker

This tool checks antenna violations and generates a report to indicate violated nets. See LEF/DEF 5.8 Language Reference, Appendix C, “Calculating and Fixing Process Antenna Violations” (p.389) for a [description](#) of antenna violations.

This is an example of the detailed and simple reports of the antenna checker:

```
[1] M2M3_PR_M:
PAR: 0.16 Ratio: 6.00 (Area)
CAR: 0.37 Ratio: 0.00 (C.Area)

[1] M1M2_PR:
PAR: 0.09 Ratio: 6.00 (Area)
CAR: 0.21 Ratio: 0.00 (C.Area)

[1] L1M1_PR_MR:
PAR: 0.12 Ratio: 3.00 (Area)
CAR: 0.12 Ratio: 0.00 (C.Area)

output50 (sky130_fd_sc_ms_buf_1) A
[1] met3:
PAR: 40.63 Ratio: 0.00 (Area)
PAR: 218.43 Ratio: 2878.88 (S.Area)
CAR: 179.21 Ratio: 0.00 (C.Area)
CAR: 912.89 Ratio: 0.00 (C.S.Area)

[1] met2:
PAR: 83.70 Ratio: 0.00 (Area)
PAR: 419.64* Ratio: 400.00 (S.Area)
CAR: 138.58 Ratio: 0.00 (C.Area)
CAR: 694.46 Ratio: 0.00 (C.S.Area)

[1] met1:
PAR: 54.81 Ratio: 0.00 (Area)
PAR: 274.73 Ratio: 400.00 (S.Area)
CAR: 54.88 Ratio: 0.00 (C.Area)
CAR: 274.81 Ratio: 0.00 (C.S.Area)
```

```
Warning - class CORE ANTENNACELL is not found. This
Net - net50
output50 (sky130_fd_sc_ms_buf_1) A
[1] met2:
PAR: 419.64* Ratio: 400.00 (S.Area)

Number of pins violated: 1
Number of nets violated: 1
Total number of unspecial nets: 2
~
```

## Simple report

## Full report

Abbreviations Index:

- PAR: Partial Area Ratio
- CAR: Cumulative Area Ratio
- Area: Gate Area
- S. Area: Side Diffusion Area
- C. Area: Cumulative Gate Area
- C. S. Area: Cumulative Side (Diffusion) Area

Antenna violations can be repaired after global routing with the `repair_design` command.

## Commands

### Note:

- Parameters in square brackets [-param param] are optional.
- Parameters without square brackets -param2 param2 are required.

## Check Antennas

```
check_antennas
  [-net net]
  [-verbose]
```

## Options

Switch Name	Description
-verbose	Report all antenna calculations for violating nets.
-net	Check antennas on the specified net.

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

## FAQs

Check out [GitHub discussion](#) about this tool.



**Algorithm**

<p>Antenna Checker Algorithm: WireGraph Example</p>	<p>Step 1: (a) Start from the root node (ITerm) using upper Via to find a node for a new wire. (b) Save the ITerm area for cumulative gate/diffusion area.</p>
<p>Step 2: From the node of the wire, find all the nodes in the wire through segment wires and find the “root” node of this wire.</p>	<p>Step 3: (a) From the “root” node of the wire, along the outgoing segment edge that goes to other nodes belonging to this wire, calculate the area of this wire. (b) Then, find all the ITerms below these nodes, except for the root node (directly use an ITerm or lower Vias to find ITerms for lower metals). © Sum up the areas of all the ITerms found with the cumulative areas and calculate the PAR of this wire. (d) Add the PAR value and the wire info (layer, Index) into the PAR table. Add the new area to the cumulative areas.</p>
<p>Step 4: Find all the upper Vias on this wire (for all the nodes on this wire), and go to the higher-level metal.</p>	<p>Step 5: Repeat Steps 2 and 3 for new-found upper-level wires.</p>
<p>140</p>	<p>Chapter 5. Site Map</p>

## License

BSD 3-Clause License. See LICENSE file.

### 5.2.23 Detailed Routing

The Detailed Routing (drt) module in OpenROAD is based on the open-source detailed router, TritonRoute. TritonRoute consists of several main building blocks, including pin access analysis, track assignment, initial detailed routing, search and repair, and a DRC engine. The initial development of the router is inspired by the [ISPD-2018 initial detailed routing contest](#). However, the current framework differs and is built from scratch, aiming for an industrial-oriented scalable and flexible flow.

TritonRoute provides industry-standard LEF/DEF interface with support of [ISPD-2018](#) and [ISPD-2019](#) contest-compatible route guide format.

## Commands

### Note:

- Parameters in square brackets [-param param] are optional.
- Parameters without square brackets -param2 param2 are required.

### Detailed Route

```
detailed_route
[-output_maze filename]
[-output_drc filename]
[-output_cmap filename]
[-output_guide_coverage filename]
[-drc_report_iter_step step]
[-db_process_node name]
[-disable_via_gen]
[-droute_end_iter iter]
[-via_in_pin_bottom_layer layer]
[-via_in_pin_top_layer layer]
[-or_seed seed]
[-or_k_ k]
[-bottom_routing_layer layer]
[-top_routing_layer layer]
[-verbose level]
[-distributed]
[-remote_host rhost]
[-remote_port rport]
[-shared_volume vol]
[-cloud_size sz]
[-clean_patches]
[-no_pin_access]
[-min_access_points count]
```

(continues on next page)

(continued from previous page)

<code>[-save_guide_updates]</code>
<code>[-repair_pdn_vias layer]</code>

## Options

Switch Name	Description
<code>-output_maze</code>	Path to output maze log file (e.g. <code>output_maze.log</code> ).
<code>-output_drc</code>	Path to output DRC report file (e.g. <code>output_drc.rpt</code> ).
<code>-output_cmap</code>	Path to output congestion map file (e.g. <code>output.cmap</code> ).
<code>-output_guide_cov</code>	Path to output guide coverage file (e.g. <code>sample_coverage.csv</code> ).
<code>-drc_report_iter_s</code>	Report DRC on each iteration which is a multiple of this step. The default value is <code>0</code> , and the allowed values are integers [ <code>0</code> , <code>MAX_INT</code> ].
<code>-db_process_node</code>	Specify the process node.
<code>-disable_via_gen</code>	Option to disable via generation with bottom and top routing layer. The default value is disabled.
<code>-droute_end_iter</code>	Number of detailed routing iterations. The default value is <code>-1</code> , and the allowed values are integers [ <code>1</code> , <code>64</code> ].
<code>-via_in_pin_bottom</code>	Via layer-in pin bottom layer name.
<code>-via_in_pin_top_l</code>	Via layer-in pin top layer name.
<code>-or_seed</code>	Refer to developer arguments <a href="#">here</a> .
<code>-or_k</code>	Refer to developer arguments <a href="#">here</a> .
<code>-bottom_routing_l</code>	Bottommost routing layer name.
<code>-top_routing_layer</code>	Topmost routing layer name.
<code>-verbose</code>	Sets verbose mode if the value is greater than <code>1</code> , else non-verbose mode (must be integer, or error will be triggered.)
<code>-distributed</code>	Refer to distributed arguments <a href="#">here</a> .
<code>-clean_patches</code>	Clean unneeded patches during detailed routing.
<code>-no_pin_access</code>	Disables pin access for routing.
<code>-min_access_points</code>	Minimum access points for standard cell and macro cell pins.
<code>-save_guide_update</code>	Flag to save guides updates.
<code>-repair_pdn_vias</code>	This option is used for PDKs where M1 and M2 power rails run in parallel.

## Developer arguments

Some arguments that are helpful for developers are listed here.

Switch Name	Description
<code>-or_seed</code>	Random seed for the order of nets to reroute. The default value is <code>-1</code> , and the allowed values are integers [ <code>0</code> , <code>MAX_INT</code> ].
<code>-or_k</code>	Number of swaps is given by $k * sizeof(rerouteNets)$ . The default value is <code>0</code> , and the allowed values are integers [ <code>0</code> , <code>MAX_INT</code> ].

## Detailed Route Debugging

The following command and arguments are useful when debugging error messages from drt and to understand its behavior.

```
detailed_route_debug
  [-pa]
  [-ta]
  [-dr]
  [-maze]
  [-net name]
  [-pin name]
  [-worker x y]
  [-iter iter]
  [-pa_markers]
  [-dump_dr]
  [-dump_dir dir]
  [-pa_edge]
  [-pa_commit]
  [-write_net_tracks]
```

## Options

Switch Name	Description
-pa	Enable debug for pin access.
-ta	Enable debug for track assignment.
-dr	Enable debug for detailed routing.
-maze	Enable debug for maze routing.
-net	Enable debug for net name.
-pin	Enable debug for pin name.
-worker	Debugs routes that pass through the point {x, y}.
-iter	Specifies the number of debug iterations. The default value is 0, and the accepted values are integers [0, MAX_INT].
-pa_markers	Enable pin access markers.
-dump_dr	Filename for detailed routing dump.
-dump_dir	Directory for detailed routing dump.
-pa_edge	Enable visibility of pin access edges.
-pa_commit	Enable visibility of pin access commits.
-write_net_tracks	Enable writing of net track assignments.

## Check Pin Access

```
pin_access
  [-db_process_node name]
  [-bottom_routing_layer layer]
  [-top_routing_layer layer]
  [-min_access_points count]
  [-verbose level]
  [-distributed]
```

(continues on next page)

(continued from previous page)

<code>[-remote_host rhost]</code>
<code>[-remote_port rport]</code>
<code>[-shared_volume vol]</code>
<code>[-cloud_size sz]</code>

## Options

Switch Name	Description
<code>-db_process_node</code>	Specify process node.
<code>-bottom_routing_layer</code>	Bottommost routing layer.
<code>-top_routing_layer</code>	Topmost routing layer.
<code>-min_access_points</code>	Minimum number of access points per pin.
<code>-verbose</code>	Sets verbose mode if the value is greater than 1, else non-verbose mode (must be integer, or error will be triggered.)
<code>-distributed</code>	Refer to distributed arguments <a href="#">here</a> .

## Distributed arguments

We have compiled all distributed arguments in this section.

---

**Note:** Additional setup is required. Please refer to this guide.

---

Switch Name	Description
<code>-distributed</code>	Enable distributed mode with Kubernetes and Google Cloud.
<code>-remote_host</code>	The host IP.
<code>-remote_port</code>	The value of the port to access from.
<code>-shared_volume</code>	The mount path of the nfs shared folder.
<code>-cloud_size</code>	The number of workers.

## Useful developer functions

If you are a developer, you might find these useful. More details can be found in the source file or the swig file.

Function Name	Description
<code>detailed_route_set_default_via</code>	Set default via.
<code>detailed_route_set_unidirectional_layer</code>	Set unidirectional layer.
<code>step_dr</code>	Refer to function <code>detailed_route_step_drt</code> .
<code>check_drc</code>	Refer to function <code>check_drc_cmd</code> .

## Example scripts

Example script demonstrating how to run TritonRoute on a sample design of gcd in the Nangate45 technology node.

```
# single machine example  
./test/gcd_nangate45.tcl  
  
# distributed example  
./test/gcd_nangate45_distributed.tcl
```

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

## FAQs

Check out [GitHub discussion](#) about this tool.

## References

Please cite the following paper(s) for publication:

1. A. B. Kahng, L. Wang and B. Xu, “TritonRoute: The Open Source Detailed Router”, IEEE Transactions on Computer-Aided Design of Integrated Circuits and Systems (2020), doi:10.1109/TCAD.2020.3003234. ([.pdf](#))
2. A. B. Kahng, L. Wang and B. Xu, “The Tao of PAO: Anatomy of a Pin Access Oracle for Detailed Routing”, Proc. ACM/IEEE Design Automation Conf., 2020, pp. 1-6. ([.pdf](#))

## Authors

TritonRoute was developed by graduate students Lutong Wang and Bangqi Xu from UC San Diego, and serves as the detailed router in the [OpenROAD](#) project.

## License

BSD 3-Clause License. See LICENSE file.

## 5.2.24 Metal fill

This module inserts floating metal fill shapes to meet metal density design rules while obeying DRC constraints. It is driven by a json configuration file.

### Commands

---

#### Note:

- Parameters in square brackets [-param param] are optional.
  - Parameters without square brackets -param2 param2 are required.
- 

### Density Fill

```
density_fill
  [-rules rules_file]
  [-area {lx ly ux uy}]
```

### Options

Switch Name	Description
-rules	Specify json rule file.
-area	Optional. If not specified, the core area will be used.

### Example scripts

The rules json file controls fill and you can see an example [here](#).

The schema for the json is:

```
{
  "layers": {
    "<group_name>": {
      "layers": "<list of integer gds layers>",
      "names": "<list of name strings>",
      "opc": {
        "datatype": "<list of integer gds datatypes>",
        "width": "<list of widths in microns>",
        "height": "<list of heights in microns>",
        "space_to_fill": "<real: spacing between fills in microns>",
        "space_to_non_fill": "<real: spacing to non-fill shapes in microns>",
        "space_line_end": "<real: spacing to end of line in microns>"
      },
      "non-opc": {
        "datatype": "<list of integer gds datatypes>",
        "width": "<list of widths in microns>",
        "height": "<list of heights in microns>"
      }
    }
  }
}
```

(continues on next page)

(continued from previous page)

```

    "height": "<list of heights in microns>",
    "space_to_fill": "<real: spacing between fills in microns>",
    "space_to_non_fill": "<real: spacing to non-fill shapes in microns>"
}
},
},
}
}

```

The `opc` section is optional depending on your process.

The width/height lists are effectively parallel arrays of shapes to try in left to right order (generally larger to smaller).

The layer grouping is for convenience. For example in some technologies many layers have similar rules so it is convenient to have a `Mx, Cx` group.

This all started out in `klayout` so there are some obsolete fields that the parser accepts but ignores (e.g., `space_to_outline`).

## Regression tests

There are a set of regression tests in `./test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Limitations

## FAQs

Check out [GitHub discussion](#) about this tool.

## License

BSD 3-Clause License. See `LICENSE` file.

### 5.2.25 Parasitics Extraction

The parasitics extraction module in OpenROAD (`rcx`) is based on the open-source OpenRCX, a Parasitic Extraction (PEX, or RCX) tool that works on OpenDB design APIs. It extracts routed designs based on the LEF/DEF layout model.

OpenRCX extracts both Resistance and Capacitance for wires, based on coupling distance to the nearest wire and the track density context over and/or under the wire of interest, as well as cell abstracts. The capacitance and resistance measurements are based on equations of coupling distance interpolated on exact measurements from a calibration file, called the Extraction Rules file. The Extraction Rules file (RC technology file) is generated once for every process node and corner, using a provided utility for DEF wire pattern generation and regression modeling.

OpenRCX stores resistance, coupling capacitance and ground (i.e., grounded) capacitance on OpenDB objects with direct pointers to the associated wire and via db objects. Optionally, OpenRCX can generate a `.spef` file.

## Commands

---

**Note:**

- Parameters in square brackets [-param param] are optional.
  - Parameters without square brackets -param2 param2 are required.
- 

### Define Process Corner

```
define_process_corner
    [-ext_model_index index]
    filename
```

### Options

Switch Name	Description
-ext_model_index	Extraction model index. Expects 2 inputs (an index, and corner name).
filename	Path to process corner file rcx_patterns.rules.

### Extract Parasitics

The extract\_parasitics command performs parasitic extraction based on the routed design. If there are no information on routed design, no parasitics are returned.

```
extract_parasitics
    [-ext_model_file filename]
    [-corner_cnt count]
    [-max_res ohms]
    [-coupling_threshold fF]
    [-debug_net_id id]
    [-lef_res]
    [-cc_model track]
    [-context_depth depth]
    [-no_merge_via_res]
```

## Options

Switch Name	Description
-ext_model	Specify the Extraction Rules file used for the extraction.
-corner_cnt	Defines the number of corners used during the parasitic extraction.
-max_res	Combines resistors in series up to the threshold value.
-coupling	The threshold below this threshold is grounded. The default value is 0.1, units are in fF, accepted values are floats.
-debug_net	<i>Developer Option:</i> Net ID to evaluate.
-lef_res	Override LEF resistance per unit.
-cc_model	Specify the maximum number of tracks of lateral context that the tool considers on the same routing level. The default value is 10, and the allowed values are integers [0, MAX_INT].
-context_depth	Specify the number of levels of vertical context that OpenRCX needs to consider for the over/under context overlap for capacitance calculation. The default value is 5, and the allowed values are integers [0, MAX_INT].
-no_merge	Separates the via resistance from the wire resistance.

## Write SPEF

The `write_spef` command writes the `.spef` output of the parasitics stored in the database.

```
write_spef
  [-net_id net_id]
  [-nets nets]
  filename
```

## Options

Switch Name	Description
-net_id	Output the parasitics info for specific net IDs.
-nets	Net name.
filename	Output filename.

## Scale RC

Use the `adjust_rc` command to scale the resistance, ground, and coupling capacitance.

```
adjust_rc
  [-res_factor res]
  [-cc_factor cc]
  [-gndc_factor gndc]
```

## Options

Switch Name	Description
-res_factor	Scale factor for resistance.
-cc_factor	Scale factor for coupling capacitance.
-gndc_factor	Scale factor for ground capacitance.

## Comparing SPEF files

The `diff_spef` command compares the parasitics in the reference database `<filename>.spef`. The output of this command is `diff_spef.out` and contains the RC numbers from the parasitics in the database and the `<filename>.spef`, and the percentage RC difference of the two data.

```
diff_spef
[-file filename]
[-r_res]
[-r_cap]
[-r_cc_cap]
[-r_conn]
```

## Options

Switch Name	Description
-file	Path to the input .spef filename.
-r_res	Read resistance.
-r_cap	Read capacitance.
-r_cc_cap	Read coupled capacitance.
r_conn	Read connections.

## Extraction Rules File Generation

The `bench_wires` command produces a layout which contains various patterns that are used to characterize per-unit length R and C values. The generated patterns model the lateral, vertical, and diagonal coupling capacitances, as well as ground capacitance effects. This command generates a .def file that contains a number of wire patterns.

This command is specifically intended for the Extraction Rules file generation only.

```
bench_wires
[-met_cnt mcnt]
[-cnt count]
[-len wire_len]
[-over]
[-diag]
[-all]
[-db_only]
[-under_met layer]
[-w_list width]
[-s_list space]
```

(continues on next page)

(continued from previous page)

<code>[-over_dist dist]</code>
<code>[-under_dist dist]</code>

## Options

Switch Name	Description
<code>-met_cnt</code>	Number of layers used in each pattern. The default value is -1, meaning it is not set, and the allowed values are integers [0, MAX_INT].
<code>-cnt</code>	Number of wires in each pattern. The default value is 5, and the default values are integers [0, MAX_INT].
<code>-len</code>	Wirelength in microns in the pattern. The default value is 100, and the allowed values are integers [0, MAX_INT].
<code>-all</code>	Consider all different pattern geometries (over, under, over_under, and diagonal).
<code>-db_only</code>	Run with db values only. All parameters in bench_wires are ignored.
<code>-under_met</code>	Consider under metal layer.
<code>-w_list</code>	Lists of wire width multipliers from the minimum spacing defined in the LEF.
<code>-s_list</code>	Lists of wire spacing multipliers from the minimum spacing defined in the LEF. The list will be the input index on the OpenRCX RC table (Extraction Rules file).
<code>-over_dist,</code> <code>-under_dist</code>	Consider over and under metal distance respectively.

## Generate verilog netlist

`bench_verilog` is used after the `bench_wires` command. This command generates a Verilog netlist of the generated pattern layout by the `bench_wires` command.

This command is optional when running the Extraction Rules generation flow. This step is required if the favorite extraction tool (i.e., reference extractor) requires a Verilog netlist to extract parasitics of the pattern layout.

<code>bench_verilog</code>
<code>[filename]</code>

## Options

Switch Name	Description
<code>filename</code>	Name for the Verilog output file (e.g., <code>output.v</code> ).

## Read SPEF

The `bench_read_spef` command reads a `<filename>.spef` file and stores the parasitics into the database.

```
bench_read_spef  
  [filename]
```

## Options

Switch Name	Description
<code>filename</code>	Path to the input .spef file.

## Write Rule File

The `write_rules` command writes the Extraction Rules file (RC technology file) for OpenRCX. It processes the parasitics data from the layout patterns that are generated using the `bench_wires` command, and writes the Extraction Rules file with `<filename>` as the output file.

This command is specifically intended for the purpose of Extraction Rules file generation.

```
write_rules  
  [-file filename]  
  [-dir dir]  
  [-name name]  
  [-pattern pattern]
```

## Options

Switch Name	Description
<code>-file</code>	Output file name.
<code>-dir</code>	Output file directory.
<code>-name</code>	Name of rule.
<code>-pattern</code>	Flag to write the pattern to rulefile (0/1).

## Example scripts

Example scripts demonstrating how to run OpenRCX in the OpenROAD environment on sample designs can be found in `/test`. An example flow test taking a sample design from synthesizable RTL Verilog to final-routed layout in an open-source SKY130 technology is shown below.

```
./test/gcd.tcl
```

Example scripts demonstrating how to run the Extraction Rules file generation can be found in this directory.

```
./calibration/script/generate_patterns.tcl      # generate patterns
./calibration/script/generate_rules.tcl          # generate the Extraction Rules file
./calibration/script/ext_patterns.tcl            # check the accuracy of OpenRCX
```

## Regression tests

There are a set of regression tests in `/test`. For more information, refer to this [section](#).

Simply run the following script:

```
./test/regression
```

## Extraction Rules File Generation

This flow generates an Extraction Rules file (RC tech file, or RC table) for OpenRCX. This file provides resistance and capacitance tables used for RC extraction for a specific process corner.

The Extraction Rules file (RC technology file) is generated once for every process node and corner automatically.

The detailed documentation can be found [here](#).

## Limitations

## FAQs

Check out [GitHub discussion](#) about this tool.

## License

BSD 3-Clause License. See `LICENSE` file.

## Extraction Rules Generation Flow for OpenRCX

This flow generates the RC tech file for OpenRCX. The RC tech file provides resistance and capacitance tables used for RC extraction for a specific process corner.

### The flow involves:

A. Running OpenRCX `generate_patterns.tcl` to generate layout patterns.

- Input: tech LEF
- Output: `patterns.def`, `patterns.v`
- Script: `generate_patterns.tcl`
- Desc: OpenRCX generates many pattern geometries to model various types of capacitance and resistance (i.e., multi-conductor) geometric configurations.

B. Running your favorite extraction tool (i.e., reference extractor) to extract parasitics of the layout patterns.

- Input: `patterns.def`, `patterns.v` (if required), and additional files required by the reference extractor.
- Output: `patterns.spf`
- Script: Not provided
- Desc: Extract parasitics of the patterns generated by OpenRCX using a reference extractor. This one-time step provides the parasitics of various types of pattern geometries as reference for fitted per-unit length R, C calculation.

C. Running OpenRCX to convert `patterns.spf` to RC tech file.

- Input: `patterns.spf`
- Output: RC tech file
- Script: `generate_rules.tcl`
- Desc: OpenRCX takes the `.spf` from the reference extractor and performs calculations to produce capacitance and resistance tables for a wide range of wire geometries. The output of this flow is a custom RC tech file for OpenRCX.

D. Benchmarking - test the accuracy of OpenRCX on the patterns layout.

- Input: `patterns.def` and RC tech file
- Output: `rcx.spf`, `diff_spf.out`
- Script: `ext_patterns.tcl`
- Desc: Perform parasitic extraction on pattern layout for the calibration using the generated RC tech file. OpenRCX then compares the extracted parasitics with the golden parasitics that had been extracted by the reference extractor in Step (B) above.

### How to run:

1. Go to OpenRCX home directory (`./OpenROAD/src/rcx`).
2. Navigate to calibration folder `cd calibration`
3. Modify the `user_env.tcl` script in the script directory.
  - TECH\_LEF: points to the directory of the tech LEF
  - PROCESS\_NODE: the technology node
  - extRules: the name and the location of the OpenRCX tech file
4. Run the executable script `run.sh` → run Steps (A) through (D) of the flow above.
  - `source run.sh` or `./run.sh`

5. The OpenRCX RC tech file can be found in the directory that is specified in the extRules variable.

### 5.2.26 OpenROAD Messages Glossary

Listed below are the OpenROAD warning/errors you may encounter while using the application.

Tool	Code	Filename:Line Number	Type	Information
ANT	0001	AntennaChecker.cc:1776	INFO	-
ANT	0002	AntennaChecker.cc:1774	INFO	-
ANT	0008	AntennaChecker.cc:1733	ERROR	-
ANT	0009	AntennaChecker.cc:1996	WARN	-
ANT	0010	AntennaChecker.tcl:56	WARN	-
ANT	0011	AntennaChecker.tcl:59	WARN	-
ANT	0012	AntennaChecker.i:66	ERROR	-
ANT	0013	AntennaChecker.cc:205	WARN	-
ANT	0014	AntennaChecker.cc:1758	ERROR	-
CTS	0001	TritonCTS.cpp:155	INFO	-
CTS	0003	TritonCTS.cpp:445	INFO	-
CTS	0004	TritonCTS.cpp:449	INFO	-
CTS	0005	TritonCTS.cpp:453	INFO	-
CTS	0006	TritonCTS.cpp:457	INFO	-
CTS	0007	TritonCTS.cpp:841	INFO	-
CTS	0008	TritonCTS.cpp:866	INFO	-
CTS	0010	TritonCTS.cpp:985	INFO	-
CTS	0011	TritonCTS.cpp:1081	INFO	-
CTS	0012	TritonCTS.cpp:1287	INFO	-
CTS	0013	TritonCTS.cpp:1289	INFO	-
CTS	0014	TritonCTS.cpp:1293	INFO	-
CTS	0015	TritonCTS.cpp:1297	INFO	-
CTS	0016	TritonCTS.cpp:1306	INFO	-
CTS	0017	TritonCTS.cpp:1310	INFO	-
CTS	0018	TritonCTS.cpp:1460	INFO	-
CTS	0019	HTreeBuilder.cpp:271	INFO	-
CTS	0020	HTreeBuilder.cpp:283	INFO	-
CTS	0021	HTreeBuilder.cpp:292	INFO	-
CTS	0022	HTreeBuilder.cpp:300	INFO	-
CTS	0023	HTreeBuilder.cpp:327	INFO	-
CTS	0024	HTreeBuilder.cpp:344	INFO	-
CTS	0025	HTreeBuilder.cpp:345	INFO	-
CTS	0026	HTreeBuilder.cpp:346	INFO	-
CTS	0027	HTreeBuilder.cpp:1125	INFO	-
CTS	0028	HTreeBuilder.cpp:1127	INFO	-
CTS	0029	HTreeBuilder.cpp:1133	INFO	-
CTS	0030	HTreeBuilder.cpp:1141	INFO	-
CTS	0031	HTreeBuilder.cpp:1163	INFO	-
CTS	0032	HTreeBuilder.cpp:1175	INFO	-
CTS	0034	HTreeBuilder.cpp:1329	INFO	-
CTS	0035	HTreeBuilder.cpp:1897	INFO	-
CTS	0039	TechChar.cpp:1678	INFO	-
CTS	0040	TritonCTS.cpp:853	WARN	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
CTS	0041	TritonCTS.cpp:978	WARN	-
CTS	0043	TechChar.cpp:137	WARN	-
CTS	0045	TechChar.cpp:387	WARN	-
CTS	0046	TechChar.cpp:142	INFO	-
CTS	0047	TechChar.cpp:144	INFO	-
CTS	0048	TechChar.cpp:149	INFO	-
CTS	0049	TechChar.cpp:514	INFO	-
CTS	0050	TechChar.cpp:680	INFO	-
CTS	0051	TechChar.cpp:681	INFO	-
CTS	0052	TechChar.cpp:753	INFO	-
CTS	0053	TechChar.cpp:683	INFO	-
CTS	0056	TritonCTS.tcl:174	ERROR	-
CTS	0058	SinkClustering.cpp:174	ERROR	-
CTS	0065	TechChar.cpp:182	ERROR	-
CTS	0073	TechChar.cpp:470	ERROR	-
CTS	0074	TechChar.cpp:697	ERROR	-
CTS	0075	TechChar.cpp:576	ERROR	-
CTS	0076	TechChar.cpp:624	ERROR	-
CTS	0077	TreeBuilder.cpp:94	ERROR	-
CTS	0078	TechChar.cpp:668	ERROR	-
CTS	0079	HTreeBuilder.cpp:200	ERROR	-
CTS	0080	HTreeBuilder.cpp:1889	ERROR	-
CTS	0081	TritonCTS.cpp:140	ERROR	-
CTS	0082	TritonCTS.cpp:98	WARN	-
CTS	0083	TritonCTS.cpp:863	WARN	-
CTS	0085	TritonCTS.cpp:1265	ERROR	-
CTS	0087	TritonCTS.cpp:431	ERROR	-
CTS	0090	HTreeBuilder.cpp:1130	INFO	-
CTS	0093	LevelBalancer.cpp:52	INFO	-
CTS	0095	TritonCTS.cpp:839	INFO	-
CTS	0096	TechChar.cpp:597	ERROR	-
CTS	0097	TritonCTS.cpp:146	INFO	-
CTS	0098	TritonCTS.cpp:402	INFO	-
CTS	0099	TritonCTS.cpp:403	INFO	-
CTS	0100	TritonCTS.cpp:404	INFO	-
CTS	0101	TritonCTS.cpp:406	INFO	-
CTS	0102	TritonCTS.cpp:407	INFO	-
CTS	0103	TritonCTS.tcl:226	ERROR	-
CTS	0104	TechChar.cpp:450	WARN	-
CTS	0105	TritonCTS.cpp:1043	WARN	-
CTS	0106	TechChar.cpp:702	ERROR	-
CTS	0107	TechChar.cpp:611	ERROR	-
CTS	0108	TechChar.cpp:618	ERROR	-
CTS	0109	TritonCTS.tcl:200	ERROR	-
CTS	0110	TritonCTS.cpp:580	ERROR	-
CTS	0111	TechChar.cpp:495	ERROR	-
CTS	0112	TritonCTS.cpp:756	ERROR	-
CTS	0113	TechChar.cpp:508	ERROR	-
CTS	0114	TritonCTS.cpp:823	ERROR	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
CTS	0115	TritonCTS.tcl:111	WARN	-
CTS	0116	TritonCTS.cpp:192	INFO	-
CTS	0117	TritonCTS.cpp:750	ERROR	-
CTS	0118	TritonCTS.cpp:1856	ERROR	-
CTS	0119	TritonCTS.cpp:1883	ERROR	-
CTS	0120	TritonCTS.cpp:1841	ERROR	-
CTS	0121	TritonCTS.cpp:330	INFO	-
CTS	0122	TritonCTS.cpp:880	INFO	-
CTS	0123	TritonCTS.tcl:208	ERROR	-
CTS	0124	TritonCTS.cpp:387	INFO	-
CTS	0125	TritonCTS.cpp:389	INFO	-
CTS	0200	TreeBuilder.cpp:56	INFO	-
CTS	0201	TreeBuilder.cpp:71	INFO	-
CTS	0202	TritonCTS.cpp:1362	INFO	-
CTS	0203	TritonCTS.cpp:1598	WARN	-
CTS	0204	HTreeBuilder.cpp:160	INFO	-
CTS	0205	HTreeBuilder.cpp:167	INFO	-
CTS	0206	HTreeBuilder.cpp:173	INFO	-
CTS	0207	TritonCTS.cpp:409	INFO	-
CTS	0534	TechChar.cpp:532	ERROR	-
CTS	0541	TechChar.cpp:537	ERROR	-
CTS	0542	CtsOptions.h:162	ERROR	-
CTS	0543	CtsOptions.h:178	ERROR	-
DFT	0002	ScanReplace.cpp:384	WARN	-
DFT	0003	ScanReplace.cpp:374	INFO	-
DFT	0004	ClockDomain.cpp:52	ERROR	-
DFT	0005	ScanCellFactory.cpp:137	WARN	-
DFT	0006	dft.i:80	ERROR	-
DFT	0007	ScanCellFactory.cpp:146	WARN	-
DPL	0001	FillerPlacement.cpp:100	INFO	-
DPL	0002	FillerPlacement.cpp:137	ERROR	-
DPL	0012	dbToOpendp.cpp:141	ERROR	-
DPL	0013	Grid.cpp:873	ERROR	-
DPL	0014	Place.cpp:904	ERROR	-
DPL	0015	Place.cpp:314	ERROR	-
DPL	0016	Place.cpp:432	ERROR	-
DPL	0017	Place.cpp:486	ERROR	-
DPL	0018	Place.cpp:626	ERROR	-
DPL	0019	Place.cpp:1121	ERROR	-
DPL	0020	OptMirror.cpp:112	INFO	-
DPL	0021	OptMirror.cpp:114	INFO	-
DPL	0022	OptMirror.cpp:116	INFO	-
DPL	0023	OptMirror.cpp:121	INFO	-
DPL	0026	Place.cpp:1388	CRITICAL	-
DPL	0027	Opendp.tcl:80	ERROR	-
DPL	0028	Opendp.tcl:215	WARN	-
DPL	0029	Opendp.tcl:232	ERROR	-
DPL	0030	Opendp.tcl:248	ERROR	-
DPL	0031	Opendp.tcl:56	ERROR	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
DPL	0032	Opendp.tcl:190	ERROR	-
DPL	0033	CheckPlacement.cpp:144	ERROR	-
DPL	0034	Opendp.cpp:176	INFO	-
DPL	0035	Opendp.cpp:181	INFO	-
DPL	0036	Opendp.cpp:188	ERROR	-
DPL	0037	Opendp.cpp:147	WARN	-
DPL	0038	Opendp.cpp:163	WARN	-
DPL	0039	Opendp.tcl:219	any	-
This	could	be	ERROR	-
DPL	0040	CheckPlacement.cpp:225	ERROR	-
DPL	0041	Grid.cpp:920	ERROR	-
DPL	0042	Grid.cpp:696	WARN	-
DPL	0043	Opendp.cpp:582	ERROR	-
DPL	0044	Opendp.cpp:588	ERROR	-
DPL	0045	CheckPlacement.cpp:287	ERROR	-
DPL	0046	Opendp.cpp:601	ERROR	-
DPL	0048	CheckPlacement.cpp:166	ERROR	-
DPL	0049	dbToOpendp.cpp:144	ERROR	-
DPL	0128	Grid.cpp:185	ERROR	-
DPL	1599	Place.cpp:1031	ERROR	-
DPL	4219	Opendp.cpp:618	ERROR	-
DPL	5211	Opendp.cpp:610	ERROR	-
DPO	0001	detailed.cxx:174	ERROR	-
DPO	0031	Optdp.tcl:59	ERROR	-
DPO	0100	Optdp.cpp:433	INFO	-
DPO	0101	Optdp.cpp:562	ERROR	-
DPO	0102	Optdp.cpp:596	ERROR	-
DPO	0103	Optdp.cpp:624	ERROR	-
DPO	0104	Optdp.cpp:637	ERROR	-
DPO	0105	Optdp.cpp:653	ERROR	-
DPO	0106	Optdp.cpp:663	ERROR	-
DPO	0107	Optdp.cpp:670	ERROR	-
DPO	0108	Optdp.cpp:750	WARN	-
DPO	0109	Optdp.cpp:677	INFO	-
DPO	0110	Optdp.cpp:929	INFO	-
DPO	0200	legalize_shift.cxx:198	WARN	-
DPO	0201	legalize_shift.cxx:214	WARN	-
DPO	0202	detailed_mis.cxx:185	INFO	-
DPO	0203	detailed_random.cxx:398	INFO	-
DPO	0300	detailed_mis.cxx:164	INFO	-
DPO	0301	detailed_mis.cxx:194	INFO	-
DPO	0302	detailed_mis.cxx:226	INFO	-
DPO	0303	detailed.cxx:176	INFO	-
DPO	0304	detailed_reorder.cxx:113	INFO	-
DPO	0305	detailed_reorder.cxx:127	INFO	-
DPO	0306	detailed_global.cxx:133	INFO	-
DPO	0307	detailed_global.cxx:141	INFO	-
DPO	0308	detailed_vertical.cxx:135	INFO	-
DPO	0309	detailed_vertical.cxx:147	INFO	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
DPO	0310	detailed_manager.cxx:949	INFO	-
DPO	0311	detailed_manager.cxx:1351	INFO	-
DPO	0312	detailed_manager.cxx:1406	INFO	-
DPO	0313	detailed_manager.cxx:1587	INFO	-
DPO	0314	detailed_manager.cxx:1645	INFO	-
DPO	0315	detailed_manager.cxx:1677	INFO	-
DPO	0317	detailed_abu.cxx:422	INFO	-
DPO	0318	detailed_manager.cxx:1187	INFO	-
DPO	0319	detailed_manager.cxx:1231	INFO	-
DPO	0320	detailed_manager.cxx:1261	INFO	-
DPO	0321	detailed_manager.cxx:1293	INFO	-
DPO	0322	detailed_manager.cxx:303	INFO	-
DPO	0323	detailed.cxx:131	WARN	-
DPO	0324	detailed_random.cxx:192	INFO	-
DPO	0325	detailed_random.cxx:242	INFO	-
DPO	0326	detailed_random.cxx:264	INFO	-
DPO	0327	detailed_random.cxx:302	INFO	-
DPO	0328	detailed_random.cxx:321	INFO	-
DPO	0329	detailed_random.cxx:390	INFO	-
DPO	0330	detailed_random.cxx:428	INFO	-
DPO	0332	detailed_random.cxx:501	INFO	-
DPO	0333	detailed_random.cxx:515	INFO	-
DPO	0334	detailed_global.cxx:542	INFO	-
DPO	0335	detailed_random.cxx:671	INFO	-
DPO	0336	detailed_vertical.cxx:535	INFO	-
DPO	0337	detailed_random.cxx:843	INFO	-
DPO	0338	detailed_random.cxx:534	INFO	-
DPO	0339	detailed_manager.cxx:1467	WARN	-
DPO	0340	detailed_manager.cxx:1477	WARN	-
DPO	0380	detailed_orient.cxx:104	INFO	-
DPO	0381	detailed_orient.cxx:112	WARN	-
DPO	0382	detailed_orient.cxx:118	INFO	-
DPO	0383	detailed_orient.cxx:127	INFO	-
DPO	0384	detailed_orient.cxx:132	INFO	-
DPO	0385	detailed_random.cxx:589	ERROR	-
DPO	0400	detailed_manager.cxx:171	ERROR	-
DPO	0401	detailed_manager.cxx:134	INFO	-
DPO	0402	detailed_manager.cxx:152	INFO	-
DRT	0000	FlexDR_init.cpp:352	ERROR	-
DRT	0001	TritonRoute.cpp:1052	ERROR	-
DRT	0002	TritonRoute.cpp:203	ERROR	-
DRT	0003	io.cpp:3520	ERROR	-
DRT	0004	io.cpp:3526	ERROR	-
DRT	0005	frRegionQuery.cpp:120	ERROR	-
DRT	0006	frRegionQuery.cpp:131	ERROR	-
DRT	0007	frRegionQuery.cpp:149	ERROR	-
DRT	0008	frRegionQuery.cpp:321	ERROR	-
DRT	0009	frRegionQuery.cpp:347	ERROR	-
DRT	0010	frRegionQuery.cpp:357	ERROR	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
DRT	0011	frRegionQuery.cpp:381	ERROR	-
DRT	0012	frRegionQuery.cpp:392	ERROR	-
DRT	0013	frRegionQuery.cpp:403	ERROR	-
DRT	0014	frRegionQuery.cpp:451	ERROR	-
DRT	0015	frRegionQuery.cpp:468	ERROR	-
DRT	0016	frRegionQuery.cpp:513	ERROR	-
DRT	0017	frRegionQuery.cpp:532	ERROR	-
DRT	0018	frRegionQuery.cpp:736	INFO	-
DRT	0019	frRegionQuery.cpp:740	INFO	-
DRT	0020	frRegionQuery.cpp:752	INFO	-
DRT	0021	frRegionQuery.cpp:756	INFO	-
DRT	0022	frRegionQuery.cpp:773	INFO	-
DRT	0023	frRegionQuery.cpp:784	INFO	-
DRT	0024	frRegionQuery.cpp:794	INFO	-
DRT	0026	frRegionQuery.cpp:824	INFO	-
DRT	0027	frRegionQuery.cpp:828	INFO	-
DRT	0028	frRegionQuery.cpp:839	INFO	-
DRT	0029	frRegionQuery.cpp:868	INFO	-
DRT	0030	frRegionQuery.cpp:872	INFO	-
DRT	0031	frRegionQuery.cpp:160	ERROR	-
DRT	0032	frRegionQuery.cpp:1001	INFO	-
DRT	0033	frRegionQuery.cpp:1015	INFO	-
DRT	0034	frRegionQuery.cpp:1043	INFO	-
DRT	0035	frRegionQuery.cpp:882	INFO	-
DRT	0036	frRegionQuery.cpp:1029	INFO	-
DRT	0037	FlexGC_init.cpp:88	ERROR	-
DRT	0038	FlexGC_init.cpp:99	ERROR	-
DRT	0039	FlexGC_init.cpp:105	ERROR	-
DRT	0041	FlexGC_main.cpp:130	WARN	-
DRT	0042	FlexGC_main.cpp:204	ERROR	-
DRT	0043	FlexGC_main.cpp:284	WARN	-
DRT	0044	FlexGC_main.cpp:2749	WARN	-
DRT	0045	FlexGC_main.cpp:2928	WARN	-
DRT	0046	FlexGC_main.cpp:2935	WARN	-
DRT	0047	FlexGC_main.cpp:2942	WARN	-
DRT	0048	FlexGC_main.cpp:2949	WARN	-
DRT	0050	FlexGC_main.cpp:2956	WARN	-
DRT	0051	FlexGC_main.cpp:2963	WARN	-
DRT	0052	FlexGC_main.cpp:2970	WARN	-
DRT	0053	FlexGC_init.cpp:995	ERROR	-
DRT	0054	FlexGC_main.cpp:3061	WARN	-
DRT	0055	FlexGC_main.cpp:3066	WARN	-
DRT	0056	FlexGC_main.cpp:3074	WARN	-
DRT	0057	FlexGC_main.cpp:3082	WARN	-
DRT	0058	FlexGC_main.cpp:3087	WARN	-
DRT	0059	FlexGC_main.cpp:3092	WARN	-
DRT	0060	FlexGC_main.cpp:3098	WARN	-
DRT	0061	FlexGC_main.cpp:3105	WARN	-
DRT	0062	FlexGC_main.cpp:3110	WARN	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
DRT	0063	FlexGC_main.cpp:3115	WARN	-
DRT	0065	FlexPA_unique.cpp:89	ERROR	-
DRT	0066	FlexPA_unique.cpp:98	WARN	-
DRT	0067	FlexPA_prep.cpp:116	ERROR	-
DRT	0068	FlexPA_prep.cpp:458	ERROR	-
DRT	0069	FlexPA_unique.cpp:253	ERROR	-
DRT	0070	FlexPA_prep.cpp:806	ERROR	-
DRT	0073	FlexPA_prep.cpp:1563	ERROR	-
DRT	0074	FlexPA_prep.cpp:1612	ERROR	-
DRT	0076	FlexPA_prep.cpp:1575	INFO	-
DRT	0077	FlexPA_prep.cpp:1579	INFO	-
DRT	0078	FlexPA_prep.cpp:1623	INFO	-
DRT	0079	FlexPA_prep.cpp:1790	INFO	-
DRT	0080	FlexPA_prep.cpp:1795	INFO	-
DRT	0081	FlexPA_prep.cpp:1807	INFO	-
DRT	0082	FlexPA_prep.cpp:1720	INFO	-
DRT	0083	FlexPA_prep.cpp:1724	INFO	-
DRT	0084	FlexPA_prep.cpp:1736	INFO	-
DRT	0085	FlexPA_prep.cpp:2034	ERROR	-
DRT	0086	FlexPA_prep.cpp:2292	ERROR	-
DRT	0087	FlexPA_prep.cpp:1776	WARN	-
DRT	0089	FlexPA_prep.cpp:2479	WARN	-
DRT	0090	FlexPA_prep.cpp:2727	ERROR	-
DRT	0091	FlexPA_prep.cpp:2800	ERROR	-
DRT	0092	FlexRP_prep.cpp:1522	WARN	-
DRT	0093	FlexRP_prep.cpp:1546	WARN	-
DRT	0094	io.cpp:86	ERROR	-
DRT	0095	io.cpp:129	ERROR	-
DRT	0096	io.cpp:134	ERROR	-
DRT	0097	io.cpp:214	ERROR	-
DRT	0098	io.cpp:224	ERROR	-
DRT	0099	io.cpp:245	ERROR	-
DRT	0100	io.cpp:337	ERROR	-
DRT	0101	io.cpp:340	ERROR	-
DRT	0102	io.cpp:484	ERROR	-
DRT	0103	io.cpp:514	ERROR	-
DRT	0104	io.cpp:563	ERROR	-
DRT	0105	io.cpp:589	ERROR	-
DRT	0106	io.cpp:596	ERROR	-
DRT	0107	io.cpp:685	ERROR	-
DRT	0108	io.cpp:828	ERROR	-
DRT	0109	io.cpp:892	ERROR	-
DRT	0110	FlexPA_prep.cpp:1674	INFO	-
DRT	0111	FlexPA_prep.cpp:1678	INFO	-
DRT	0112	io.cpp:1025	ERROR	-
DRT	0113	io.cpp:3191	ERROR	-
DRT	0114	io.cpp:3327	ERROR	-
DRT	0115	FlexPA_graphics.cpp:66	INFO	-
DRT	0116	io.cpp:1189	ERROR	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
DRT	0117	io.cpp:1193	ERROR	-
DRT	0118	TritonRoute.tcl:271	ERROR	-
DRT	0119	FlexPA_graphics.cpp:271	INFO	-
DRT	0122	io.cpp:2349	WARN	-
DRT	0123	io.cpp:2387	WARN	-
DRT	0124	io.cpp:2618	WARN	-
DRT	0125	io.cpp:2642	ERROR	-
DRT	0126	io.cpp:2650	ERROR	-
DRT	0127	io.cpp:2661	ERROR	-
DRT	0128	io.cpp:2499	ERROR	-
DRT	0129	io.cpp:2506	ERROR	-
DRT	0130	io.cpp:2520	ERROR	-
DRT	0131	io.cpp:2541	WARN	-
DRT	0132	io.cpp:2562	WARN	-
DRT	0133	io.cpp:2572	WARN	-
DRT	0134	io.cpp:2587	WARN	-
DRT	0135	io.cpp:2597	WARN	-
DRT	0136	io.cpp:2712	ERROR	-
DRT	0139	io.cpp:1931	WARN	-
DRT	0141	io.cpp:1972	WARN	-
DRT	0142	io.cpp:1974	WARN	-
DRT	0143	io.cpp:1976	WARN	-
DRT	0147	io.cpp:2221	WARN	-
DRT	0149	io.cpp:2707	INFO	-
DRT	0150	io.cpp:1184	INFO	-
DRT	0153	io.cpp:2773	ERROR	-
DRT	0154	io.cpp:2778	ERROR	-
DRT	0155	io.cpp:2796	ERROR	-
DRT	0156	io.cpp:2819	INFO	-
DRT	0157	io.cpp:2823	INFO	-
DRT	0160	io_parser_helper.cpp:167	WARN	-
DRT	0161	io.cpp:1660	WARN	-
DRT	0162	io_pin.cpp:36	INFO	-
DRT	0163	io_pin.cpp:82	INFO	-
DRT	0164	io_pin.cpp:136	INFO	-
DRT	0165	FlexPA.cpp:180	INFO	-
DRT	0166	FlexPA.cpp:217	INFO	-
DRT	0167	frTechObject.h:259	INFO	-
DRT	0168	io_parser_helper.cpp:834	INFO	-
DRT	0169	io_parser_helper.cpp:847	INFO	-
DRT	0170	io_parser_helper.cpp:1029	ERROR	-
DRT	0171	io_parser_helper.cpp:1034	ERROR	-
DRT	0172	io_parser_helper.cpp:1084	ERROR	-
DRT	0173	io_parser_helper.cpp:1089	ERROR	-
DRT	0174	io_parser_helper.cpp:1129	ERROR	-
DRT	0175	io_parser_helper.cpp:1145	ERROR	-
DRT	0176	io_parser_helper.cpp:1151	INFO	-
DRT	0177	io_parser_helper.cpp:1157	INFO	-
DRT	0178	io_parser_helper.cpp:885	INFO	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
DRT	0179	io_parser_helper.cpp:888	INFO	-
DRT	0180	io.cpp:3166	INFO	-
DRT	0181	FlexTA.cpp:333	INFO	-
DRT	0182	FlexTA.cpp:346	INFO	-
DRT	0183	FlexTA.cpp:223	INFO	-
DRT	0184	FlexTA.cpp:241	INFO	-
DRT	0185	io_parser_helper.cpp:904	INFO	-
DRT	0186	FlexTA.cpp:307	INFO	-
DRT	0187	FlexDR.cpp:460	INFO	-
DRT	0190	io.cpp:231	WARN	-
DRT	0191	io.cpp:251	WARN	-
DRT	0192	io.cpp:2627	WARN	-
DRT	0194	FlexDR.cpp:474	INFO	-
DRT	0195	FlexDR.cpp:555	INFO	-
DRT	0198	FlexDR.cpp:836	INFO	-
DRT	0199	FlexDR.cpp:774	INFO	-
DRT	0201	FlexGR.cpp:658	ERROR	-
DRT	0202	FlexGR.cpp:687	WARN	-
DRT	0203	FlexGR.cpp:666	WARN	-
DRT	0204	TritonRoute.cpp:1110	WARN	-
DRT	0206	FlexDR_conn.cpp:1328	ERROR	-
DRT	0207	FlexDR_graphics.cpp:761	INFO	-
DRT	0210	io.cpp:1842	WARN	-
DRT	0214	io_guide.cpp:896	WARN	-
DRT	0215	io_guide.cpp:905	WARN	-
DRT	0216	io_guide.cpp:914	WARN	-
DRT	0217	io_guide.cpp:919	WARN	-
DRT	0218	io_guide.cpp:956	ERROR	-
DRT	0219	io_guide.cpp:958	ERROR	-
DRT	0220	io_guide.cpp:1005	WARN	-
DRT	0221	io_guide.cpp:1024	WARN	-
DRT	0222	io_guide.cpp:1032	WARN	-
DRT	0223	io_guide.cpp:1086	ERROR	-
DRT	0224	io_guide.cpp:1291	WARN	-
DRT	0225	io_guide.cpp:1301	WARN	-
DRT	0226	FlexGC_eol.cpp:487	ERROR	-
DRT	0228	io_guide.cpp:379	ERROR	-
DRT	0229	io_guide.cpp:510	ERROR	-
DRT	0230	io_guide.cpp:601	WARN	-
DRT	0231	io_guide.cpp:617	WARN	-
DRT	0232	io_guide.cpp:558	ERROR	-
DRT	0233	io_parser_helper.cpp:133	ERROR	-
DRT	0234	io_parser_helper.cpp:125	ERROR	-
DRT	0235	io_parser_helper.cpp:238	WARN	-
DRT	0236	io_parser_helper.cpp:245	INFO	-
DRT	0237	io_parser_helper.cpp:263	WARN	-
DRT	0238	io_parser_helper.cpp:270	INFO	-
DRT	0239	io_parser_helper.cpp:327	ERROR	-
DRT	0240	io_parser_helper.cpp:334	WARN	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
DRT	0241	io_parser_helper.cpp:341	WARN	-
DRT	0242	io_parser_helper.cpp:349	ERROR	-
DRT	0243	io_parser_helper.cpp:361	ERROR	-
DRT	0244	io_parser_helper.cpp:366	WARN	-
DRT	0245	io_parser_helper.cpp:893	INFO	-
DRT	0246	io_parser_helper.cpp:938	WARN	-
DRT	0247	io.cpp:2851	WARN	-
DRT	0248	io_pin.cpp:71	WARN	-
DRT	0249	FlexDR_graphics.cpp:682	INFO	-
DRT	0250	FlexDR_graphics.cpp:685	INFO	-
DRT	0253	FlexGC_init.cpp:179	ERROR	-
DRT	0255	FlexDR_maze.cpp:1820	ERROR	-
DRT	0256	io.cpp:376	WARN	-
DRT	0258	io.cpp:1653	WARN	-
DRT	0259	io.cpp:1667	WARN	-
DRT	0261	io.cpp:1688	WARN	-
DRT	0262	io.cpp:1695	WARN	-
DRT	0263	io.cpp:1702	WARN	-
DRT	0267	frTime.cpp:47	INFO	-
DRT	0268	FlexTA.cpp:289	INFO	-
DRT	0269	FlexGC_eol.cpp:58	ERROR	-
DRT	0270	FlexGC_eol.cpp:240	ERROR	-
DRT	0271	FlexGC_eol.cpp:412	ERROR	-
DRT	0272	io.cpp:2725	WARN	-
DRT	0273	io.cpp:2737	WARN	-
DRT	0275	FlexDR_graphics.cpp:688	INFO	-
DRT	0276	FlexPA_prep.cpp:2102	ERROR	-
DRT	0277	FlexPA_prep.cpp:2879	ERROR	-
DRT	0278	FlexPA_prep.cpp:2917	ERROR	-
DRT	0279	io.cpp:1714	WARN	-
DRT	0280	FlexPA_graphics.cpp:344	WARN	-
DRT	0281	FlexPA_graphics.cpp:350	INFO	-
DRT	0282	io.cpp:175	WARN	-
DRT	0290	TritonRoute.cpp:1316	WARN	-
DRT	0291	TritonRoute.cpp:1385	ERROR	-
DRT	0292	FlexPA_graphics.cpp:306	INFO	-
DRT	0293	FlexPA_graphics.cpp:74	ERROR	-
DRT	0294	io.cpp:3415	ERROR	-
DRT	0295	io.cpp:3420	ERROR	-
DRT	0296	io.cpp:3424	ERROR	-
DRT	0297	io.cpp:3451	ERROR	-
DRT	0298	io.cpp:3458	ERROR	-
DRT	0299	io.cpp:3462	ERROR	-
DRT	0300	io.cpp:3475	ERROR	-
DRT	0301	io.cpp:3487	ERROR	-
DRT	0302	io.cpp:988	ERROR	-
DRT	0303	io.cpp:3496	ERROR	-
DRT	0304	TritonRoute.cpp:854	ERROR	-
DRT	0305	io.cpp:529	ERROR	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
DRT	0306	io.cpp:552	ERROR	-
DRT	0307	io.cpp:578	ERROR	-
DRT	0308	TritonRoute.tcl:467	ERROR	-
DRT	0311	FlexGC_main.cpp:2048	WARN	-
DRT	0312	FlexGC_main.cpp:2055	WARN	-
DRT	0313	FlexGC_main.cpp:2060	WARN	-
DRT	0314	FlexGC_main.cpp:2063	WARN	-
DRT	0315	FlexGC_main.cpp:2066	WARN	-
DRT	0316	FlexGC_main.cpp:2069	WARN	-
DRT	0317	io.cpp:2116	WARN	-
DRT	0318	io.cpp:2124	WARN	-
DRT	0319	io.cpp:2132	WARN	-
DRT	0320	FlexPA_unique.cpp:222	ERROR	-
DRT	0321	FlexPA_unique.cpp:232	ERROR	-
DRT	0322	FlexPA_unique.cpp:240	ERROR	-
DRT	0323	io.cpp:2334	WARN	-
DRT	0324	io.cpp:1756	WARN	-
DRT	0325	io.cpp:1764	WARN	-
DRT	0326	io.cpp:1772	WARN	-
DRT	0327	io.cpp:1780	WARN	-
DRT	0328	io.cpp:1788	WARN	-
DRT	0329	FlexPA_prep.cpp:1656	ERROR	-
DRT	0330	FlexPA_prep.cpp:1823	ERROR	-
DRT	0331	FlexPA.cpp:152	ERROR	-
DRT	0332	FlexPA_prep.cpp:1702	ERROR	-
DRT	0333	io.cpp:1454	WARN	-
DRT	0334	io.cpp:1459	WARN	-
DRT	0335	io.cpp:1489	WARN	-
DRT	0400	io.cpp:1337	WARN	-
DRT	0401	io.cpp:1345	WARN	-
DRT	0403	io.cpp:1353	WARN	-
DRT	0404	io.cpp:1114	ERROR	-
DRT	0405	io.cpp:1118	ERROR	-
DRT	0406	FlexTA_assign.cpp:624	ERROR	-
DRT	0410	FlexGC_main.cpp:2187	ERROR	-
DRT	0411	FlexGC_main.cpp:2192	ERROR	-
DRT	0412	FlexTA_assign.cpp:802	ERROR	-
DRT	0415	TritonRoute.cpp:1144	ERROR	-
DRT	0416	io_parser_helper.cpp:651	ERROR	-
DRT	0417	io_parser_helper.cpp:703	ERROR	-
DRT	0418	io_parser_helper.cpp:809	WARN	-
DRT	0419	io_parser_helper.cpp:812	WARN	-
DRT	0421	io_parser_helper.cpp:771	WARN	-
DRT	0422	io_parser_helper.cpp:774	WARN	-
DRT	0423	FlexDR_maze.cpp:2144	ERROR	-
DRT	0500	FlexDR.cpp:1288	ERROR	-
DRT	0506	TritonRoute.tcl:169	ERROR	-
DRT	0507	TritonRoute.tcl:174	ERROR	-
DRT	0508	TritonRoute.tcl:179	ERROR	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
DRT	0512	frRegionQuery.cpp:306	ERROR	-
DRT	0513	frRegionQuery.cpp:233	ERROR	-
DRT	0516	TritonRoute.tcl:184	ERROR	-
DRT	0517	TritonRoute.tcl:375	ERROR	-
DRT	0519	FlexPA_prep.cpp:950	WARN	-
DRT	0520	TritonRoute.tcl:381	ERROR	-
DRT	0550	FlexGridGraph.h:1044	ERROR	-
DRT	0551	FlexGridGraph.h:1056	ERROR	-
DRT	0552	TritonRoute.tcl:338	ERROR	-
DRT	0553	TritonRoute.tcl:343	ERROR	-
DRT	0554	TritonRoute.tcl:348	ERROR	-
DRT	0555	TritonRoute.tcl:353	ERROR	-
DRT	0606	TritonRoute.cpp:559	WARN	-
DRT	0607	TritonRoute.cpp:571	WARN	-
DRT	0608	io_parser_helper.cpp:85	ERROR	-
DRT	0610	TritonRoute.cpp:1212	ERROR	-
DRT	0611	TritonRoute.cpp:1218	ERROR	-
DRT	0612	TritonRoute.tcl:486	ERROR	-
DRT	0613	TritonRoute.tcl:493	ERROR	-
DRT	0615	TritonRoute.cpp:1227	ERROR	-
DRT	0616	TritonRoute.cpp:1232	ERROR	-
DRT	0617	TritonRoute.cpp:583	WARN	-
DRT	0618	TritonRoute.cpp:1235	ERROR	-
DRT	0999	FlexDR.cpp:1306	ERROR	-
DRT	1000	io_guide.cpp:103	INFO	-
DRT	1001	io_guide.cpp:153	WARN	-
DRT	1002	io_guide.cpp:221	ERROR	-
DRT	1003	FlexPA_prep.cpp:402	ERROR	-
DRT	1004	FlexPA_prep.cpp:410	ERROR	-
DRT	1005	FlexPA_prep.cpp:421	ERROR	-
DRT	1006	FlexDR_maze.cpp:1876	ERROR	-
DRT	1007	io_guide.cpp:101	ERROR	-
DRT	1008	io_guide.cpp:282	ERROR	-
DRT	1009	FlexDR_init.cpp:1325	ERROR	-
DRT	1010	FlexDR_init.cpp:66	ERROR	-
DRT	1011	io.cpp:1158	ERROR	-
DRT	12304	TritonRoute.cpp:774	ERROR	-
DRT	2000	FlexDR_maze.cpp:2174	INFO	-
DRT	2001	FlexDR_maze.cpp:1584	INFO	-
DRT	2002	FlexDR_maze.cpp:1798	INFO	-
DRT	2003	FlexDR_maze.cpp:1864	INFO	-
DRT	2005	FlexDR_maze.cpp:2054	INFO	-
DRT	2006	FlexDR_maze.cpp:2058	INFO	-
DRT	2007	FlexDR_maze.cpp:2092	INFO	-
DRT	2008	TritonRoute.tcl:259	ERROR	-
DRT	3000	io_guide.cpp:302	ERROR	-
DRT	4000	FlexPA_graphics.cpp:79	INFO	-
DRT	4500	FlexGC_main.cpp:2162	ERROR	-
DRT	4501	FlexGC_main.cpp:2175	ERROR	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
DRT	5000	FlexPA_graphics.cpp:86	WARN	-
DRT	6000	FlexPA_prep.cpp:773	WARN	-
DRT	6001	FlexDR_conn.cpp:1028	WARN	-
DRT	7461	FlexDR.cpp:1264	ERROR	-
DRT	9199	TritonRoute.cpp:482	ERROR	-
DRT	9504	TritonRoute.cpp:808	ERROR	-
DRT	9999	TritonRoute.cpp:418	ERROR	-
DST	0001	Distributed.cc:92	ERROR	-
DST	0002	Distributed.tcl:42	ERROR	-
DST	0003	Distributed.tcl:47	ERROR	-
DST	0004	WorkerConnection.cc:122	WARN	-
DST	0005	WorkerConnection.cc:112	WARN	-
DST	0006	BalancerConnection.cc:102	WARN	-
DST	0007	LoadBalancer.cc:43	INFO	-
DST	0008	BalancerConnection.cc:232	WARN	-
DST	0009	Distributed.cc:110	ERROR	-
DST	0010	Distributed.tcl:66	ERROR	-
DST	0011	Distributed.tcl:71	ERROR	-
DST	0012	Distributed.cc:226	WARN	-
DST	0013	Distributed.cc:236	WARN	-
DST	0014	Distributed.cc:270	WARN	-
DST	0016	Distributed.tcl:91	ERROR	-
DST	0017	Distributed.tcl:96	ERROR	-
DST	0020	Distributed.cc:279	WARN	-
DST	0022	Distributed.cc:289	WARN	-
DST	0041	WorkerConnection.cc:78	WARN	-
DST	0042	BalancerConnection.cc:87	WARN	-
DST	0112	Distributed.cc:165	WARN	-
DST	0113	Distributed.cc:175	WARN	-
DST	0114	Distributed.cc:201	WARN	-
DST	0203	LoadBalancer.cc:199	WARN	-
DST	0204	BalancerConnection.cc:137	WARN	-
DST	0205	BalancerConnection.cc:147	WARN	-
DST	0207	BalancerConnection.cc:210	WARN	-
DST	9999	Distributed.cc:256	ERROR	-
FIN	0001	DensityFill.cpp:179	ERROR	-
FIN	0002	DensityFill.cpp:190	ERROR	-
FIN	0003	DensityFill.cpp:450	INFO	-
FIN	0004	DensityFill.cpp:488	INFO	-
FIN	0005	DensityFill.cpp:507	INFO	-
FIN	0006	DensityFill.cpp:513	INFO	-
FIN	0007	finale.tcl:49	ERROR	-
FIN	0008	finale.tcl:55	ERROR	-
FIN	0009	DensityFill.cpp:475	INFO	-
FIN	0010	DensityFill.cpp:533	WARN	-
GPL	0002	placerBase.cpp:778	INFO	-
GPL	0003	placerBase.cpp:806	INFO	-
GPL	0004	placerBase.cpp:807	INFO	-
GPL	0005	placerBase.cpp:808	INFO	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
GPL	0006	placerBase.cpp:1263	INFO	-
GPL	0007	placerBase.cpp:1267	INFO	-
GPL	0008	placerBase.cpp:1268	INFO	-
GPL	0009	placerBase.cpp:1269	INFO	-
GPL	0010	placerBase.cpp:1270	INFO	-
GPL	0011	placerBase.cpp:1271	INFO	-
GPL	0012	placerBase.cpp:1273	INFO	-
GPL	0013	placerBase.cpp:1274	INFO	-
GPL	0014	placerBase.cpp:1275	INFO	-
GPL	0015	placerBase.cpp:1276	INFO	-
GPL	0016	placerBase.cpp:1282	INFO	-
GPL	0017	placerBase.cpp:1283	INFO	-
GPL	0018	placerBase.cpp:1285	INFO	-
GPL	0019	placerBase.cpp:1286	INFO	-
GPL	0020	placerBase.cpp:1288	INFO	-
GPL	0021	placerBase.cpp:1289	INFO	-
GPL	0023	nesterovBase.cpp:614	INFO	-
GPL	0024	nesterovBase.cpp:615	INFO	-
GPL	0025	nesterovBase.cpp:616	INFO	-
GPL	0026	nesterovBase.cpp:617	INFO	-
GPL	0027	nesterovBase.cpp:618	INFO	-
GPL	0028	nesterovBase.cpp:648	INFO	-
GPL	0029	nesterovBase.cpp:653	INFO	-
GPL	0030	nesterovBase.cpp:670	INFO	-
GPL	0031	nesterovBase.cpp:1292	INFO	-
GPL	0032	nesterovBase.cpp:1293	INFO	-
GPL	0033	nesterovBase.cpp:1294	INFO	-
GPL	0034	nesterovBase.cpp:1651	INFO	-
GPL	0035	nesterovBase.cpp:1669	INFO	-
GPL	0036	routeBase.cpp:149	INFO	-
GPL	0037	routeBase.cpp:150	INFO	-
GPL	0038	routeBase.cpp:151	INFO	-
GPL	0039	routeBase.cpp:152	INFO	-
GPL	0040	routeBase.cpp:174	INFO	-
GPL	0045	routeBase.cpp:608	INFO	-
GPL	0046	routeBase.cpp:609	INFO	-
GPL	0047	routeBase.cpp:627	INFO	-
GPL	0048	routeBase.cpp:628	INFO	-
GPL	0049	routeBase.cpp:640	INFO	-
GPL	0050	routeBase.cpp:641	INFO	-
GPL	0051	routeBase.cpp:642	INFO	-
GPL	0052	routeBase.cpp:643	INFO	-
GPL	0053	routeBase.cpp:647	INFO	-
GPL	0054	routeBase.cpp:666	INFO	-
GPL	0055	routeBase.cpp:667	INFO	-
GPL	0056	routeBase.cpp:668	INFO	-
GPL	0057	routeBase.cpp:669	INFO	-
GPL	0058	routeBase.cpp:671	INFO	-
GPL	0059	routeBase.cpp:672	INFO	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
GPL	0063	routeBase.cpp:738	INFO	-
GPL	0064	routeBase.cpp:739	INFO	-
GPL	0065	routeBase.cpp:740	INFO	-
GPL	0066	routeBase.cpp:795	INFO	-
GPL	0067	routeBase.cpp:796	INFO	-
GPL	0068	routeBase.cpp:797	INFO	-
GPL	0069	routeBase.cpp:798	INFO	-
GPL	0070	routeBase.cpp:800	INFO	-
GPL	0071	routeBase.cpp:801	INFO	-
GPL	0072	routeBase.cpp:802	INFO	-
GPL	0073	routeBase.cpp:803	INFO	-
GPL	0074	routeBase.cpp:811	INFO	-
GPL	0075	routeBase.cpp:824	INFO	-
GPL	0100	timingBase.cpp:163	INFO	-
GPL	0102	timingBase.cpp:166	WARN	-
GPL	0103	timingBase.cpp:204	INFO	-
GPL	0114	timingBase.cpp:153	WARN	-
GPL	0115	replace.tcl:144	WARN	-
GPL	0116	replace.tcl:156	WARN	-
GPL	0118	placerBase.cpp:797	ERROR	-
GPL	0119	placerBase.cpp:840	ERROR	-
GPL	0120	placerBase.cpp:844	ERROR	-
GPL	0121	replace.tcl:116	ERROR	-
GPL	0122	mbff.cpp:164	ERROR	-
GPL	0130	replace.tcl:315	ERROR	-
GPL	0131	replace.tcl:416	ERROR	-
GPL	0132	replace.cpp:186	INFO	-
GPL	0133	replace.cpp:203	INFO	-
GPL	0134	placerBase.cpp:109	WARN	-
GPL	0135	replace.tcl:178	ERROR	-
GPL	0136	replace.cpp:290	WARN	-
GPL	0150	replace.tcl:120	WARN	-
GPL	0151	replace.tcl:151	WARN	-
GPL	0250	initialPlace.cpp:104	WARN	-
GPL	0251	initialPlace.cpp:109	WARN	-
GPL	0301	placerBase.cpp:1292	ERROR	-
GPL	0302	nesterovBase.cpp:1401	ERROR	-
GPL	0303	nesterovBase.cpp:1633	ERROR	-
GPL	0304	nesterovPlace.cpp:267	ERROR	-
GPL	0305	placerBase.cpp:791	ERROR	-
GPL	9032	mbff.cpp:546	ERROR	-
GRT	0001	GlobalRouter.cpp:765	INFO	-
GRT	0002	GlobalRouter.cpp:766	INFO	-
GRT	0003	GlobalRouter.cpp:3379	INFO	-
GRT	0004	GlobalRouter.cpp:3101	INFO	-
GRT	0005	GlobalRouter.tcl:511	ERROR	-
GRT	0006	GlobalRouter.cpp:323	INFO	-
GRT	0009	GlobalRouter.cpp:4011	INFO	-
GRT	0010	GlobalRouter.cpp:2948	ERROR	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
GRT	0011	GlobalRouter.cpp:3021	ERROR	-
GRT	0012	RepairAntennas.cpp:94	INFO	-
GRT	0014	GlobalRouter.cpp:280	INFO	-
GRT	0015	GlobalRouter.cpp:330	INFO	-
GRT	0018	GlobalRouter.cpp:2227	INFO	-
GRT	0019	GlobalRouter.cpp:2888	INFO	-
GRT	0020	GlobalRouter.cpp:3604	INFO	-
GRT	0021	GlobalRouter.cpp:3605	INFO	-
GRT	0022	GlobalRouter.cpp:3606	INFO	-
GRT	0023	GlobalRouter.cpp:3607	INFO	-
GRT	0025	MakeWireParasitics.cpp:237	WARN	-
GRT	0026	MakeWireParasitics.cpp:344	WARN	-
GRT	0027	RepairAntennas.cpp:414	WARN	-
GRT	0028	GlobalRouter.cpp:3374	ERROR	-
GRT	0029	GlobalRouter.cpp:2986	ERROR	-
GRT	0030	GlobalRouter.cpp:1391	WARN	-
GRT	0031	GlobalRouter.cpp:2181	WARN	-
GRT	0033	GlobalRouter.cpp:2452	WARN	-
GRT	0034	GlobalRouter.cpp:2937	WARN	-
GRT	0035	GlobalRouter.cpp:2969	WARN	-
GRT	0036	GlobalRouter.cpp:3032	WARN	-
GRT	0037	GlobalRouter.cpp:3168	WARN	-
GRT	0038	GlobalRouter.cpp:3320	WARN	-
GRT	0039	GlobalRouter.cpp:3357	WARN	-
GRT	0040	GlobalRouter.cpp:3414	WARN	-
GRT	0041	GlobalRouter.cpp:3447	WARN	-
GRT	0042	GlobalRouter.cpp:3057	ERROR	-
GRT	0043	GlobalRouter.cpp:3537	INFO	-
GRT	0044	GlobalRouter.tcl:62	ERROR	-
GRT	0045	GlobalRouter.tcl:344	ERROR	-
GRT	0047	GlobalRouter.tcl:76	ERROR	-
GRT	0048	GlobalRouter.tcl:84	ERROR	-
GRT	0051	GlobalRouter.tcl:219	ERROR	-
GRT	0052	GlobalRouter.tcl:223	ERROR	-
GRT	0053	GlobalRouter.cpp:3619	INFO	-
GRT	0054	GlobalRouter.cpp:335	INFO	-
GRT	0055	GlobalRouter.tcl:234	ERROR	-
GRT	0057	GlobalRouter.tcl:570	ERROR	-
GRT	0059	GlobalRouter.tcl:483	ERROR	-
GRT	0062	GlobalRouter.tcl:526	ERROR	-
GRT	0063	GlobalRouter.tcl:533	ERROR	-
GRT	0064	GlobalRouter.tcl:539	ERROR	-
GRT	0065	GlobalRouter.tcl:543	ERROR	-
GRT	0066	GlobalRouter.tcl:547	ERROR	-
GRT	0067	GlobalRouter.tcl:551	ERROR	-
GRT	0068	RepairAntennas.cpp:145	ERROR	-
GRT	0069	GlobalRouter.tcl:309	ERROR	-
GRT	0071	GlobalRouter.cpp:1040	ERROR	-
GRT	0072	GlobalRouter.cpp:1253	ERROR	-

continues on next page

Table 3 – continued from previous page

Tool	Code	Filename:Line Number	Type	Information
GRT	0073	GlobalRouter.tcl:322	ERROR	-
GRT	0074	GlobalRouter.cpp:1928	ERROR	-
GRT	0075	GlobalRouter.cpp:1906	ERROR	-
GRT	0076	GlobalRouter.cpp:1984	ERROR	-
GRT	0078	GlobalRouter.cpp:2066	ERROR	-
GRT	0079	GlobalRouter.cpp:2168	ERROR	-
GRT	0080	GlobalRouter.cpp:2197	ERROR	-
GRT	0084	GlobalRouter.cpp:461	ERROR	-
GRT	0085	GlobalRouter.cpp:456	ERROR	-
GRT	0086	GlobalRouter.cpp:2717	ERROR	-
GRT	0088	GlobalRouter.cpp:2732	INFO	-
GRT	0090	GlobalRouter.cpp:2792	ERROR	-
GRT	0094	GlobalRouter.cpp:3388	ERROR	-
GRT	0096	GlobalRouter.cpp:3671	INFO	-
GRT	0101	FastRoute.cpp:1005	INFO	-
GRT	0103	FastRoute.cpp:1139	INFO	-
GRT	0111	FastRoute.cpp:1312	INFO	-
GRT	0112	FastRoute.cpp:1313	INFO	-
GRT	0113	FastRoute.cpp:391	WARN	-
GRT	0114	FastRoute.cpp:421	WARN	-
GRT	0115	GlobalRouter.cpp:272	WARN	-
GRT	0118	GlobalRouter.cpp:1574	ERROR	# Helpful Information

Do refer to the GUI guide and global routing debugging tips. || GRT | 0119 | GlobalRouter.cpp:1567 | ERROR | # Helpful Information

Do refer to the GUI guide and global routing debugging tips. || GRT | 0122 | RipUp.cpp:450 | ERROR | - | GRT | 0123 | RipUp.cpp:572 | ERROR | - | GRT | 0125 | maze.cpp:820 | ERROR | - | GRT | 0126 | GlobalRouter.cpp:481 | ERROR | - | GRT | 0146 | GlobalRouter.tcl:274 | WARN | - | GRT | 0149 | utility.cpp:2045 | ERROR | - | GRT | 0150 | maze.cpp:1838 | ERROR | - | GRT | 0151 | maze.cpp:1872 | WARN | - | GRT | 0152 | maze.cpp:1993 | WARN | - | GRT | 0153 | maze.cpp:2028 | WARN | - | GRT | 0164 | utility.cpp:1764 | WARN | - | GRT | 0165 | utility.cpp:1778 | WARN | - | GRT | 0166 | utility.cpp:1794 | WARN | - | GRT | 0167 | utility.cpp:1808 | WARN | - | GRT | 0169 | maze.cpp:1020 | ERROR | - | GRT | 0170 | maze.cpp:1198 | WARN | - | GRT | 0171 | maze3D.cpp:413 | ERROR | - | GRT | 0172 | maze3D.cpp:737 | ERROR | - | GRT | 0179 | route.cpp:329 | WARN | - | GRT | 0181 | route.cpp:936 | WARN | - | GRT | 0183 | maze3D.cpp:1124 | ERROR | - | GRT | 0184 | maze3D.cpp:715 | WARN | - | GRT | 0187 | maze3D.cpp:399 | ERROR | - | GRT | 0188 | RSMT.cpp:139 | ERROR | - | GRT | 0189 | RSMT.cpp:147 | ERROR | - | GRT | 0197 | utility.cpp:361 | INFO | - | GRT | 0198 | utility.cpp:362 | INFO | - | GRT | 0199 | utility.cpp:363 | INFO | - | GRT | 0200 | utility.cpp:601 | WARN | - | GRT | 0201 | maze.cpp:891 | ERROR | - | GRT | 0202 | utility.cpp:706 | ERROR | - | GRT | 0203 | utility.cpp:1112 | ERROR | - | GRT | 0204 | utility.cpp:1195 | ERROR | - | GRT | 0206 | utility.cpp:1331 | ERROR | - | GRT | 0207 | utility.cpp:1745 | WARN | - | GRT | 0208 | utility.cpp:1753 | WARN | - | GRT | 0209 | GlobalRouter.cpp:3037 | ERROR | - | GRT | 0214 | FastRoute.cpp:597 | ERROR | - | GRT | 0215 | GlobalRouter.tcl:338 | WARN | - | GRT | 0219 | GlobalRouter.tcl:147 | ERROR | - | GRT | 0220 | GlobalRouter.tcl:159 | ERROR | - | GRT | 0221 | RepairAntennas.cpp:225 | ERROR | - | GRT | 0222 | GlobalRouter.tcl:506 | ERROR | - | GRT | 0223 | GlobalRouter.tcl:386 | ERROR | - | GRT | 0224 | GlobalRouter.tcl:447 | ERROR | - | GRT | 0225 | RipUp.cpp:176 | ERROR | - | GRT | 0226 | RipUp.cpp:267 | ERROR | - | GRT | 0228 | utility.cpp:1641 | ERROR | - | GRT | 0229 | utility.cpp:1655 | ERROR | - | GRT | 0230 | FastRoute.cpp:1283 | WARN | - | GRT | 0231 | GlobalRouter.tcl:429 | ERROR | - | GRT | 0232 | GlobalRouter.cpp:4064 | ERROR | - | GRT | 0233 | GlobalRouter.cpp:1601 | ERROR | - | GRT | 0234 | GlobalRouter.cpp:1624 | ERROR | - | GRT | 0235 | GlobalRouter.cpp:1644 | ERROR | - | GRT | 0236 | GlobalRouter.cpp:1652 | ERROR | - | GRT | 0237 | GlobalRouter.cpp:3809 | INFO | - | GRT | 0238 | GlobalRouter.tcl:475 | ERROR | - | GRT | 0239 | GlobalRouter.cpp:3833 | WARN | - | GRT | 0240 | GlobalRouter.cpp:3839 | INFO | - | GRT | 0241 | GlobalRouter.cpp:3804 | WARN | - | GRT | 0242 | GlobalRouter.tcl:179 | ERROR | - | GRT | 0243 | RepairAntennas.cpp:451 | WARN | - | GRT | 0244 | GlobalRouter.cpp:312 | ERROR | - | GRT | 0245 | Global-

Router.tcl:325 | ERROR |- || GRT | 0246 | GlobalRouter.cpp:306 | WARN |- || GRT | 0247 | utility.cpp:1611 | ERROR |- || GRT | 0248 | utility.cpp:1622 | ERROR |- || GRT | 0249 | GlobalRouter.cpp:1588 | ERROR |- || GRT | 0250 | GlobalRouter.cpp:1633 | WARN |- || GRT | 0251 | GlobalRouter.cpp:235 | ERROR |- || GRT | 0252 | GlobalRouter.tcl:358 | ERROR |- || GRT | 0253 | GlobalRouter.cpp:1792 | ERROR |- || GRT | 0254 | utility.cpp:248 | ERROR |- || GRT | 0300 | GlobalRouter.cpp:1546 | WARN |- || GRT | 0301 | GlobalRouter.cpp:1374 | WARN |- || GRT | 0350 | MakeWireParasitics.cpp:453 | WARN |- || GRT | 0500 | RipUp.cpp:337 | ERROR |- || GRT | 0600 | utility.cpp:2550 | ERROR |- || GRT | 1247 | utility.cpp:1498 | ERROR |- || GRT | 1248 | utility.cpp:1511 | ERROR |- || GUI | 0001 | gui.i:47 | INFO |- || GUI | 0002 | gui.i:53 | ERROR |- || GUI | 0003 | gui.i:64 | ERROR |- || GUI | 0005 | gui.i:68 | ERROR |- || GUI | 0006 | gui.i:72 | ERROR |- || GUI | 0007 | gui.i:337 | ERROR |- || GUI | 0008 | gui.cpp:1249 | WARN |- || GUI | 0009 | gui.i:360 | ERROR |- || GUI | 0010 | gui\_utils.cpp:71 | WARN |- || GUI | 0011 | gui\_utils.cpp:121 | WARN |- || GUI | 0012 | gui\_utils.cpp:126 | WARN |- || GUI | 0013 | displayControls.cpp:1087 | ERROR |- || GUI | 0014 | displayControls.cpp:1108 | WARN |- || GUI | 0015 | gui.cpp:683 | ERROR |- || GUI | 0016 | gui.cpp:716 | ERROR |- || GUI | 0017 | gui.tcl:132 | ERROR |- || GUI | 0018 | gui.tcl:146 | ERROR |- || GUI | 0019 | gui.tcl:118 | ERROR |- || GUI | 0020 | gui.tcl:48 | ERROR |- || GUI | 0021 | gui.tcl:53 | ERROR |- || GUI | 0022 | mainWindow.cpp:723 | ERROR |- || GUI | 0023 | mainWindow.cpp:1207 | WARN |- || GUI | 0024 | mainWindow.cpp:1028 | WARN |- || GUI | 0025 | mainWindow.cpp:814 | ERROR |- || GUI | 0026 | gui.tcl:79 | ERROR |- || GUI | 0027 | gui.tcl:84 | ERROR |- || GUI | 0028 | gui.cpp:879 | ERROR |- || GUI | 0029 | gui.cpp:908 | ERROR |- || GUI | 0030 | drcWidget.cpp:517 | ERROR |- || GUI | 0031 | gui.tcl:138 | WARN |- || GUI | 0032 | drcWidget.cpp:500 | ERROR |- || GUI | 0033 | gui.cpp:291 | WARN |- || GUI | 0034 | displayControls.cpp:1120 | WARN |- || GUI | 0035 | gui.cpp:504 | ERROR |- || GUI | 0036 | gui.i:497 | ERROR |- || GUI | 0037 | gui.i:503 | ERROR |- || GUI | 0038 | gui.tcl:224 | ERROR |- || GUI | 0039 | gui.tcl:252 | WARN |- || GUI | 0040 | drcWidget.cpp:594 | WARN |- || GUI | 0041 | drcWidget.cpp:688 | WARN |- || GUI | 0042 | drcWidget.cpp:677 | WARN |- || GUI | 0043 | drcWidget.cpp:666 | WARN |- || GUI | 0044 | drcWidget.cpp:655 | WARN |- || GUI | 0045 | drcWidget.cpp:548 | ERROR |- || GUI | 0046 | drcWidget.cpp:563 | ERROR |- || GUI | 0047 | drcWidget.cpp:583 | ERROR |- || GUI | 0048 | drcWidget.cpp:613 | ERROR |- || GUI | 0049 | drcWidget.cpp:619 | ERROR |- || GUI | 0050 | drcWidget.cpp:626 | ERROR |- || GUI | 0051 | drcWidget.cpp:715 | WARN |- || GUI | 0052 | drcWidget.cpp:709 | WARN |- || GUI | 0053 | gui.cpp:1152 | ERROR |- || GUI | 0054 | displayControls.cpp:810 | WARN |- || GUI | 0055 | drcWidget.cpp:755 | ERROR |- || GUI | 0056 | gui.tcl:243 | ERROR |- || GUI | 0057 | displayControls.cpp:732 | WARN |- || GUI | 0058 | drcWidget.cpp:823 | ERROR |- || GUI | 0059 | gui.cpp:484 | ERROR |- || GUI | 0060 | gui.cpp:927 | ERROR |- || GUI | 0061 | gui.cpp:936 | ERROR |- || GUI | 0062 | gui.cpp:945 | ERROR |- || GUI | 0063 | gui.cpp:952 | ERROR |- || GUI | 0064 | gui.cpp:696 | ERROR |- || GUI | 0065 | gui.cpp:701 | ERROR |- || GUI | 0066 | heatMap.cpp:649 | WARN |- || GUI | 0067 | gui.tcl:286 | ERROR |- || GUI | 0068 | gui.tcl:295 | ERROR |- || GUI | 0069 | gui.tcl:298 | ERROR |- || GUI | 0070 | gui.tcl:329 | ERROR |- || GUI | 0071 | gui.tcl:336 | ERROR |- || GUI | 0072 | heatMap.cpp:96 | ERROR |- || GUI | 0073 | heatMap.cpp:101 | ERROR |- || GUI | 0074 | clockWidget.cpp:1511 | ERROR |- || GUI | 0075 | gui.cpp:487 | ERROR |- || GUI | 0076 | mainWindow.cpp:1601 | ERROR |- || GUI | 0077 | mainWindow.cpp:1595 | WARN |- || GUI | 0078 | layoutViewer.cpp:2105 | WARN |- || GUI | 0079 | drcWidget.cpp:791 | WARN |- || GUI | 0080 | drcWidget.cpp:881 | WARN |- || GUI | 0081 | drcWidget.cpp:874 | WARN |- || GUI | 0082 | drcWidget.cpp:861 | WARN |- || GUI | 0083 | drcWidget.cpp:854 | WARN |- || GUI | 0084 | drcWidget.cpp:846 | WARN |- || GUI | 0085 | drcWidget.cpp:839 | WARN |- || GUI | 0086 | drcWidget.cpp:779 | ERROR |- || GUI | 0087 | drcWidget.cpp:765 | ERROR |- || GUI | 0088 | gui.tcl:202 | ERROR |- || GUI | 0089 | clockWidget.cpp:1475 | ERROR |- || GUI | 0090 | gui.i:591 | ERROR |- || GUI | 0091 | gui.i:604 | ERROR |- || GUI | 0092 | gui.i:617 | ERROR |- || GUI | 0093 | gui.i:630 | ERROR |- || GUI | 0094 | layoutViewer.cpp:2068 | WARN |- || GUI | 0095 | gui.cpp:978 | ERROR |- || GUI | 0096 | gui.tcl:153 | ERROR |- || GUI | 0097 | chartsWidget.cpp:164 | WARN |- || GUI | 0098 | gui.tcl:158 | ERROR |- || GUI | 0099 | drcWidget.cpp:805 | WARN |- || IFP | 0001 | InitFloorplan.cc:437 | INFO |- || IFP | 0010 | InitFloorplan.tcl:165 | ERROR |- || IFP | 0011 | InitFloorplan.tcl:56 | WARN |- || IFP | 0013 | InitFloorplan.tcl:84 | ERROR |- || IFP | 0015 | InitFloorplan.tcl:108 | ERROR |- || IFP | 0016 | InitFloorplan.tcl:120 | ERROR |- || IFP | 0017 | InitFloorplan.tcl:137 | ERROR |- || IFP | 0018 | InitFloorplan.i:149 | ERROR |- || IFP | 0019 | InitFloorplan.tcl:140 | ERROR |- || IFP | 0021 | InitFloorplan.cc:711 | WARN |- || IFP | 0022 | InitFloorplan.cc:719 | WARN |- || IFP | 0025 | InitFloorplan.tcl:168 | ERROR |- || IFP | 0026 | InitFloorplan.cc:314 | WARN |- || IFP | 0027 | InitFloorplan.cc:345 | WARN |- || IFP | 0028 | InitFloorplan.cc:208 | WARN |- || IFP | 0029 | InitFloorplan.cc:632 | ERROR |- || IFP | 0030 | InitFloorplan.cc:657 | INFO |- || IFP | 0031 | InitFloorplan.tcl:234 | ERROR |- || IFP | 0032 | InitFloorplan.tcl:239 | ERROR |- || IFP | 0038 | InitFloorplan.i:66 | ERROR |- || IFP | 0039 | InitFloorplan.cc:616 | ERROR |- || IFP | 0040 | InitFloorplan.cc:446 | ERROR |- || IFP | 0043 | InitFloorplan.cc:397 | WARN |- || IFP | 0044 | InitFloorplan.cc:776 | ERROR |- || IFP | 0045 | InitFloorplan.cc:789 | ERROR |- || IFP | 0048 | InitFloorplan.cc:508 | ERROR |- || IFP | 0049 | InitFloorplan.cc:545 | INFO |- || IFP | 0050 | InitFloorplan.cc:571 | INFO |- || MPL | 0001 |

mpl.tcl:83 | ERROR | | | MPL | 0002 | hier\_rtlmp.cpp:934 | ERROR | - | | MPL | 0003 | hier\_rtlmp.cpp:2806 | ERROR | - | | MPL | 0004 | hier\_rtlmp.cpp:3026 | ERROR | - | | MPL | 0005 | hier\_rtlmp.cpp:3837 | ERROR | - | | MPL | 0006 | hier\_rtlmp.cpp:4089 | ERROR | - | | MPL | 0007 | hier\_rtlmp.cpp:5242 | ERROR | - | | MPL | 0008 | hier\_rtlmp.cpp:5261 | ERROR | - | | MPL | 0009 | hier\_rtlmp.cpp:5408 | ERROR | - | | MPL | 0010 | hier\_rtlmp.cpp:5610 | ERROR | - | | MPL | 0011 | hier\_rtlmp.cpp:6413 | ERROR | - | | MPL | 0012 | mpl.tcl:280 | ERROR | - | | MPL | 0015 | graphics.cpp:335 | ERROR | - | | MPL | 0016 | hier\_rtlmp.cpp:469 | ERROR | - | | MPL | 0017 | hier\_rtlmp.cpp:464 | INFO | - | | MPL | 0018 | mpl.tcl:290 | WARN | - | | MPL | 0019 | mpl.tcl:268 | ERROR | - | | MPL | 0020 | mpl.tcl:303 | ERROR | - | | MPL | 0021 | mpl.tcl:305 | ERROR | - | | MPL | 0022 | mpl.tcl:276 | ERROR | - | | MPL | 0025 | hier\_rtlmp.cpp:532 | WARN | - | | MPL | 0026 | hier\_rtlmp.cpp:970 | WARN | - | | MPL | 0027 | hier\_rtlmp.cpp:619 | WARN | - | | MPL | 0034 | rtl\_mp.cpp:143 | ERROR | - | | MPL | 0035 | rtl\_mp.cpp:186 | INFO | - | | MPL | 0036 | rtl\_mp.cpp:176 | WARN | - | | MPL | 0038 | object.cpp:626 | ERROR | - | | MPL | 0039 | hier\_rtlmp.cpp:6405 | WARN | - | | MPL | 0040 | hier\_rtlmp.cpp:5110 | ERROR | - | | MPL | 0061 | MacroPlacer.cpp:432 | WARN | - | | MPL | 0064 | MacroPlacer.cpp:709 | ERROR | - | | MPL | 0065 | MacroPlacer.cpp:1287 | WARN | - | | MPL | 0066 | MacroPlacer.cpp:232 | WARN | - | | MPL | 0067 | MacroPlacer.cpp:208 | INFO | - | | MPL | 0068 | MacroPlacer.cpp:230 | INFO | - | | MPL | 0069 | MacroPlacer.cpp:279 | INFO | - | | MPL | 0070 | MacroPlacer.cpp:404 | INFO | - | | MPL | 0071 | MacroPlacer.cpp:452 | INFO | - | | MPL | 0072 | MacroPlacer.cpp:489 | WARN | - | | MPL | 0073 | MacroPlacer.cpp:482 | INFO | - | | MPL | 0076 | MacroPlacer.cpp:575 | INFO | - | | MPL | 0077 | MacroPlacer.cpp:628 | INFO | - | | MPL | 0079 | MacroPlacer.cpp:640 | INFO | - | | MPL | 0080 | MacroPlacer.cpp:776 | INFO | - | | MPL | 0085 | MacroPlacer.tcl:86 | WARN | - | | MPL | 0089 | MacroPlacer.tcl:69 | ERROR | - | | MPL | 0092 | MacroPlacer.tcl:49 | ERROR | - | | MPL | 0093 | MacroPlacer.tcl:60 | ERROR | - | | MPL | 0095 | MacroPlacer.tcl:103 | ERROR | - | | MPL | 0096 | MacroPlacer.tcl:116 | ERROR | - | | MPL | 0097 | MacroPlacer.cpp:522 | ERROR | - | | MPL | 0098 | MacroPlacer.cpp:164 | WARN | - | | MPL | 0099 | MacroPlacer.cpp:808 | ERROR | - | | MPL | 0100 | MacroPlacer.cpp:829 | WARN | - | | MPL | 0101 | MacroPlacer.cpp:833 | INFO | - | | MPL | 0102 | MacroPlacer.cpp:196 | INFO | - | | ODB | 0000 | dbWireCodec.cpp:1483 | ERROR | - | | ODB | 0002 | dbDatabase.cpp:542 | ERROR | - | | ODB | 0005 | dbBlock.cpp:1967 | WARN | - | | ODB | 0006 | dbBlock.cpp:1992 | WARN | - | | ODB | 0007 | dbBlock.cpp:2017 | WARN | - | | ODB | 0008 | dbBlock.cpp:2591 | ERROR | - | | ODB | 0009 | dbBlock.cpp:2595 | WARN | - | | ODB | 0010 | dbBlock.cpp:2842 | INFO | - | | ODB | 0011 | dbBlock.cpp:2983 | WARN | - | | ODB | 0012 | dbBlock.cpp:2993 | ERROR | - | | ODB | 0013 | dbBlock.cpp:3148 | ERROR | - | | ODB | 0014 | dbBlock.cpp:3322 | WARN | - | | ODB | 0015 | tmg\_conn\_w.cpp:98 | INFO | - | | ODB | 0016 | tmg\_conn.cpp:1659 | ERROR | - | | ODB | 0018 | tmg\_conn.cpp:1882 | ERROR | - | | ODB | 0019 | dbBlock.cpp:3403 | WARN | - | | ODB | 0021 | dbCCSeg.cpp:408 | INFO | - | | ODB | 0022 | dbCCSeg.cpp:434 | INFO | - | | ODB | 0023 | dbCCSeg.cpp:755 | ERROR | - | | ODB | 0024 | dbCapNode.cpp:182 | WARN | - | | ODB | 0025 | dbCapNode.cpp:1082 | INFO | - | | ODB | 0034 | dbITerm.cpp:593 | WARN | - | | ODB | 0036 | dbInst.cpp:686 | INFO | - | | ODB | 0037 | dbInst.cpp:996 | INFO | - | | ODB | 0038 | dbInst.cpp:1017 | WARN | - | | ODB | 0039 | dbInst.cpp:1022 | WARN | - | | ODB | 0040 | dbInst.cpp:1030 | WARN | - | | ODB | 0041 | dbInst.cpp:1035 | WARN | - | | ODB | 0042 | dbInst.cpp:1043 | WARN | - | | ODB | 0043 | dbInst.cpp:1052 | WARN | - | | ODB | 0044 | dbInst.cpp:1163 | WARN | - | | ODB | 0045 | dbInst.cpp:1211 | WARN | - | | ODB | 0046 | dbInst.cpp:1238 | WARN | - | | ODB | 0047 | dbInst.cpp:1589 | WARN | - | | ODB | 0048 | dbNet.cpp:1013 | WARN | - | | ODB | 0049 | dbNet.cpp:2131 | ERROR | - | | ODB | 0050 | dbNet.cpp:2137 | ERROR | - | | ODB | 0051 | dbNet.cpp:2161 | ERROR | - | | ODB | 0052 | dbNet.cpp:2576 | WARN | - | | ODB | 0053 | dbNet.cpp:2622 | WARN | - | | ODB | 0054 | dbRSeg.cpp:553 | INFO | - | | ODB | 0056 | dbRSeg.cpp:559 | INFO | - | | ODB | 0057 | dbRSeg.cpp:836 | WARN | - | | ODB | 0058 | dbTech.cpp:964 | WARN | - | | ODB | 0059 | dbTech.cpp:973 | ERROR | - | | ODB | 0060 | dbTech.cpp:982 | ERROR | - | | ODB | 0061 | dbTech.cpp:991 | ERROR | - | | ODB | 0062 | dbWire.cpp:1773 | WARN | - | | ODB | 0063 | dbWireCodec.cpp:1224 | WARN | - | | ODB | 0064 | dbWireCodec.cpp:1233 | INFO | - | | ODB | 0065 | dbWireCodec.cpp:1242 | INFO | - | | ODB | 0066 | dbWireCodec.cpp:1254 | INFO | - | | ODB | 0067 | dbWireCodec.cpp:1263 | INFO | - | | ODB | 0068 | dbWireCodec.cpp:1286 | INFO | - | | ODB | 0069 | dbWireCodec.cpp:1298 | INFO | - | | ODB | 0070 | dbWireCodec.cpp:1310 | INFO | - | | ODB | 0071 | dbWireCodec.cpp:1320 | INFO | - | | ODB | 0072 | dbWireCodec.cpp:1329 | WARN | - | | ODB | 0073 | dbWireCodec.cpp:1348 | INFO | - | | ODB | 0074 | dbWireCodec.cpp:1355 | INFO | - | | ODB | 0075 | dbWireCodec.cpp:1370 | INFO | - | | ODB | 0076 | dbWireCodec.cpp:1377 | INFO | - | | ODB | 0077 | dbWireCodec.cpp:1384 | INFO | - | | ODB | 0078 | dbWireCodec.cpp:1390 | INFO | - | | ODB | 0079 | dbWireCodec.cpp:1396 | INFO | - | | ODB | 0080 | dbWireCodec.cpp:1405 | INFO | - | | ODB | 0081 | dbWireCodec.cpp:1419 | INFO | - | | ODB | 0082 | dbWireCodec.cpp:1424 | INFO | - | | ODB | 0083 | dbWireCodec.cpp:1432 | ERROR | - | | ODB | 0084 | dbWireCodec.cpp:1441 | INFO | - | | ODB | 0085 | dbWireCodec.cpp:1450 | INFO | - | | ODB | 0086 | dbWireCodec.cpp:1458 | ERROR | - | | ODB | 0087 | dbWirePathItr.cpp:515 | WARN | - | | ODB | 0088 | definBlockage.cpp:73 | WARN | - | | ODB | 0089 | definBlockage.cpp:84 | WARN | - | | ODB | 0090 | definBlockage.cpp:206 | WARN | - | | ODB | 0091 | definBlockage.cpp:227 | WARN | - | | ODB | 0092 | definComponent.cpp:151 | WARN | - | | ODB | 0093 | definComponent.cpp:173 | WARN | - | | ODB | 0094

| definComponent.cpp:179 | INFO |- || ODB | 0095 | definFill.cpp:64 | WARN |- || ODB | 0096 | definNet.cpp:122 |  
WARN |- || ODB | 0097 | definNet.cpp:147 | INFO |- || ODB | 0098 | definNet.cpp:161 | WARN |- || ODB | 0099 |  
definNet.cpp:200 | WARN |- || ODB | 0100 | definNet.cpp:210 | WARN |- || ODB | 0102 | definNet.cpp:264 | WARN |- ||  
ODB | 0103 | definNet.cpp:278 | WARN |- || ODB | 0104 | definNet.cpp:363 | WARN |- || ODB | 0105 | definNet.cpp:378  
| WARN |- || ODB | 0106 | definNet.cpp:404 | WARN |- || ODB | 0107 | definNet.cpp:518 | WARN |- || ODB | 0108 |  
definNet.cpp:550 | WARN |- || ODB | 0109 | definNet.cpp:574 | WARN |- || ODB | 0110 | definNet.cpp:591 | WARN |- ||  
ODB | 0111 | definNonDefaultRule.cpp:64 | WARN |- || ODB | 0112 | definNonDefaultRule.cpp:85 | WARN |- || ODB |  
0113 | definNonDefaultRule.cpp:101 | WARN |- || ODB | 0114 | definNonDefaultRule.cpp:118 | WARN |- || ODB | 0115  
| definNonDefaultRule.cpp:134 | WARN |- || ODB | 0116 | definNonDefaultRule.cpp:142 | WARN |- || ODB | 0117 |  
definPin.cpp:118 | WARN |- || ODB | 0118 | definPin.cpp:124 | WARN |- || ODB | 0119 | definPin.cpp:202 | WARN |- ||  
ODB | 0120 | definPin.cpp:217 | WARN |- || ODB | 0121 | definPin.cpp:242 | WARN |- || ODB | 0122 | definPin.cpp:377  
| WARN |- || ODB | 0123 | definPin.cpp:390 | WARN |- || ODB | 0124 | definReader.cpp:551 | WARN |- || ODB | 0125 |  
definReader.cpp:1660 | INFO |- || ODB | 0126 | definReader.cpp:1665 | WARN |- || ODB | 0127 | definReader.cpp:1694  
| INFO |- || ODB | 0128 | definReader.cpp:361 | INFO |- || ODB | 0129 | definReader.cpp:1698 | WARN |- || ODB | 0130 |  
definReader.cpp:1703 | INFO |- || ODB | 0131 | definReader.cpp:1709 | INFO |- || ODB | 0132 | definReader.cpp:1720  
| INFO |- || ODB | 0133 | definReader.cpp:1727 | INFO |- || ODB | 0134 | definReader.cpp:1740 | INFO |- || ODB | 0135 |  
definReader.cpp:1753 | INFO |- || ODB | 0136 | definNet.cpp:247 | WARN |- || ODB | 0137 | definReader.cpp:1757 |  
WARN |- || ODB | 0138 | definReader.cpp:1762 | INFO |- || ODB | 0139 | definReader.cpp:1765 | INFO |- || ODB | 0140 |  
definReader.cpp:1772 | INFO |- || ODB | 0141 | definReader.cpp:1779 | INFO |- || ODB | 0142 | definReader.cpp:1785 |  
INFO |- || ODB | 0143 | definReader.cpp:1796 | INFO |- || ODB | 0144 | definReader.cpp:1800 | WARN |- || ODB | 0145 |  
definReader.cpp:1805 | INFO |- || ODB | 0146 | definReader.cpp:1809 | INFO |- || ODB | 0147 | definReader.cpp:1811  
| INFO |- || ODB | 0148 | definReader.cpp:1881 | WARN |- || ODB | 0149 | definReader.cpp:1902 | WARN |- || ODB |  
0150 | definReader.cpp:1917 | WARN |- || ODB | 0151 | definReader.cpp:1938 | WARN |- || ODB | 0152 | definRe-  
gion.cpp:65 | WARN |- || ODB | 0153 | dbPowerSwitch.cpp:345 | ERROR |- || ODB | 0154 | dbPowerSwitch.cpp:355 |  
ERROR |- || ODB | 0155 | definRow.cpp:111 | WARN |- || ODB | 0156 | definSNet.cpp:123 | WARN |- || ODB | 0157 |  
definSNet.cpp:178 | WARN |- || ODB | 0158 | definSNet.cpp:188 | WARN |- || ODB | 0159 | definSNet.cpp:249 | WARN  
|- || ODB | 0160 | definSNet.cpp:269 | WARN |- || ODB | 0161 | definSNet.cpp:304 | WARN |- || ODB | 0162 | defin-  
SNet.cpp:322 | WARN |- || ODB | 0163 | definSNet.cpp:457 | WARN |- || ODB | 0164 | definSNet.cpp:520 | WARN |- ||  
ODB | 0165 | definTracks.cpp:70 | WARN |- || ODB | 0166 | definVia.cpp:67 | WARN |- || ODB | 0167 | definVia.cpp:80  
| WARN |- || ODB | 0168 | definVia.cpp:116 | WARN |- || ODB | 0169 | definVia.cpp:125 | WARN |- || ODB | 0170 |  
definVia.cpp:134 | WARN |- || ODB | 0171 | definVia.cpp:231 | WARN |- || ODB | 0172 | defout\_impl.cpp:153 | WARN  
|- || ODB | 0173 | defout\_impl.cpp:928 | WARN |- || ODB | 0174 | defout\_impl.cpp:1668 | WARN |- || ODB | 0175 |  
lefin.cpp:199 | WARN |- || ODB | 0176 | lefin.cpp:221 | WARN |- || ODB | 0177 | lefin.cpp:407 | WARN |- || ODB |  
0178 | lefin.cpp:427 | WARN |- || ODB | 0179 | lefin.cpp:540 | ERROR |- || ODB | 0180 | lefin.cpp:618 | WARN |- ||  
ODB | 0181 | lefin.cpp:639 | WARN |- || ODB | 0182 | lefin.cpp:648 | WARN |- || ODB | 0183 | lefin.cpp:852 | ERROR  
|- || ODB | 0184 | lefin.cpp:1219 | WARN |- || ODB | 0185 | lefin.cpp:1228 | WARN |- || ODB | 0186 | lefin.cpp:1251  
| WARN |- || ODB | 0187 | lefin.cpp:1302 | WARN |- || ODB | 0188 | lefin.cpp:1313 | WARN |- || ODB | 0189 |  
lefin.cpp:1350 | WARN |- || ODB | 0190 | lefin.cpp:1358 | WARN |- || ODB | 0191 | lefin.cpp:1381 | WARN |- || ODB |  
0192 | lefin.cpp:1394 | WARN |- || ODB | 0193 | lefin.cpp:1408 | WARN |- || ODB | 0194 | lefin.cpp:1462 | WARN  
|- || ODB | 0195 | lefin.cpp:1487 | WARN |- || ODB | 0196 | lefin.cpp:1504 | WARN |- || ODB | 0197 | lefin.cpp:1521  
| WARN |- || ODB | 0198 | lefin.cpp:1538 | WARN |- || ODB | 0199 | lefin.cpp:1564 | WARN |- || ODB | 0200 |  
lefin.cpp:1580 | WARN |- || ODB | 0201 | lefin.cpp:1596 | WARN |- || ODB | 0202 | lefin.cpp:1613 | WARN |- || ODB |  
0203 | lefin.cpp:1738 | WARN |- || ODB | 0204 | lefin.cpp:1744 | WARN |- || ODB | 0205 | lefin.cpp:1787 | WARN |- ||  
ODB | 0206 | lefin.cpp:1817 | WARN |- || ODB | 0207 | lefin.cpp:1834 | WARN |- || ODB | 0208 | lefin.cpp:1717 | WARN  
|- || ODB | 0209 | lefin.cpp:1890 | WARN |- || ODB | 0210 | lefin.cpp:1920 | WARN |- || ODB | 0211 | lefin.cpp:1936  
| WARN |- || ODB | 0212 | lefin.cpp:1945 | WARN |- || ODB | 0213 | lefin.cpp:1953 | WARN |- || ODB | 0214 |  
lefin.cpp:2007 | WARN |- || ODB | 0215 | lefin.cpp:2017 | WARN |- || ODB | 0216 | lefin.cpp:2047 | WARN |- || ODB |  
0217 | lefin.cpp:2066 | WARN |- || ODB | 0218 | lefin.cpp:2076 | WARN |- || ODB | 0219 | dbPowerSwitch.cpp:372  
| ERROR |- || ODB | 0220 | dbPowerSwitch.cpp:382 | ERROR |- || ODB | 0221 | lefin.cpp:2144 | INFO |- || ODB |  
0222 | lefin.cpp:2152 | INFO |- || ODB | 0228 | lefin.cpp:2300 | WARN |- || ODB | 0229 | lefin.cpp:2305 | WARN |- ||  
ODB | 0230 | lefin.cpp:2337 | WARN |- || ODB | 0231 | lefin.cpp:2343 | WARN |- || ODB | 0240 | reader.cpp:557 |  
WARN |- || ODB | 0241 | create\_box.cpp:163 | WARN |- || ODB | 0242 | create\_box.cpp:193 | WARN |- || ODB | 0243 |  
create\_box.cpp:196 | INFO |- || ODB | 0244 | create\_box.cpp:231 | WARN |- || ODB | 0245 | create\_box.cpp:261 |  
WARN |- || ODB | 0246 | lefin.cpp:2225 | ERROR |- || ODB | 0247 | definReader.cpp:944 | WARN |- || ODB | 0248 |

definReader.cpp:466 | WARN | || ODB | 0249 | definReader.cpp:1474 | WARN | || ODB | 0250 | definReader.cpp:1684 |  
 ERROR | || ODB | 0252 | definReader.cpp:1706 | INFO | || ODB | 0253 | definReader.cpp:1716 | INFO | || ODB | 0254  
 | definReader.cpp:1734 | INFO | || ODB | 0260 | definReader.cpp:70 | WARN | || ODB | 0261 | definReader.cpp:334 |  
 WARN | || ODB | 0270 | reader.cpp:548 | WARN | || ODB | 0271 | definReader.cpp:1890 | WARN | || ODB | 0273 |  
 dbUtil.cpp:922 | INFO | || ODB | 0274 | create\_box.cpp:60 | WARN | || ODB | 0275 | definReader.cpp:705 | WARN  
 | || ODB | 0276 | create\_box.cpp:266 | INFO | || ODB | 0277 | lefin.cpp:2169 | WARN | || ODB | 0279 | lefin.cpp:757  
 | WARN | || ODB | 0280 | lefin.cpp:2185 | WARN | || ODB | 0282 | dbTechLayer.cpp:1935 | ERROR | || ODB | 0283  
 | cdl.cpp:113 | ERROR | || ODB | 0284 | cdl.cpp:144 | WARN | || ODB | 0285 | cdl.cpp:148 | WARN | || ODB | 0286  
 | cdl.cpp:159 | WARN | || ODB | 0287 | cdl.cpp:220 | ERROR | || ODB | 0288 | lefin.cpp:2285 | ERROR | || ODB  
 | 0289 | lefin.cpp:2365 | ERROR | || ODB | 0292 | lefin.cpp:2322 | ERROR | || ODB | 0293 | definReader.cpp:1317 |  
 WARN | || ODB | 0297 | dbModule.cpp:186 | ERROR | || ODB | 0298 | dbModule.cpp:300 | ERROR | || ODB | 0299 |  
 definVia.cpp:257 | ERROR | || ODB | 0300 | definVia.cpp:267 | ERROR | || ODB | 0301 | definVia.cpp:277 | ERROR  
 | || ODB | 0302 | definVia.cpp:293 | ERROR | || ODB | 0303 | util.cpp:458 | INFO | || ODB | 0304 | definGroup.cpp:61  
 | WARN | || ODB | 0305 | definGroup.cpp:74 | WARN | || ODB | 0306 | definGroup.cpp:99 | WARN | || ODB | 0307  
 | dbBlock.cpp:3430 | ERROR | || ODB | 0308 | odb.tcl:10 | ERROR | || ODB | 0309 | odb.tcl:15 | ERROR | || ODB  
 | 0310 | odb.tcl:27 | ERROR | || ODB | 0311 | odb.tcl:35 | ERROR | || ODB | 0312 | odb.tcl:38 | ERROR | || ODB |  
 0313 | odb.tcl:47 | ERROR | || ODB | 0314 | odb.tcl:59 | ERROR | || ODB | 0315 | odb.tcl:196 | ERROR | || ODB |  
 0316 | odb.tcl:204 | ERROR | || ODB | 0317 | odb.tcl:211 | ERROR | || ODB | 0318 | odb.tcl:216 | ERROR | || ODB |  
 0319 | odb.tcl:223 | ERROR | || ODB | 0320 | odb.tcl:236 | ERROR | || ODB | 0321 | odb.tcl:241 | ERROR | || ODB |  
 0322 | odb.tcl:244 | ERROR | || ODB | 0323 | odb.tcl:257 | ERROR | || ODB | 0324 | odb.tcl:262 | ERROR | || ODB |  
 0325 | odb.tcl:265 | ERROR | || ODB | 0326 | odb.tcl:277 | ERROR | || ODB | 0327 | odb.tcl:282 | ERROR | || ODB |  
 0328 | odb.tcl:287 | ERROR | || ODB | 0329 | odb.tcl:293 | ERROR | || ODB | 0330 | odb.tcl:296 | ERROR | || ODB |  
 0331 | odb.tcl:299 | ERROR | || ODB | 0332 | odb.tcl:311 | ERROR | || ODB | 0333 | odb.tcl:316 | ERROR | || ODB |  
 0334 | odb.tcl:321 | ERROR | || ODB | 0335 | odb.tcl:327 | ERROR | || ODB | 0336 | odb.tcl:330 | ERROR | || ODB |  
 0337 | odb.tcl:333 | ERROR | || ODB | 0338 | odb.tcl:347 | ERROR | || ODB | 0339 | odb.tcl:352 | ERROR | || ODB |  
 0340 | odb.tcl:355 | ERROR | || ODB | 0341 | odb.tcl:360 | ERROR | || ODB | 0342 | odb.tcl:367 | ERROR | || ODB |  
 0343 | odb.tcl:374 | ERROR | || ODB | 0344 | odb.tcl:377 | ERROR | || ODB | 0345 | odb.tcl:392 | ERROR | || ODB |  
 0346 | odb.tcl:397 | ERROR | || ODB | 0347 | odb.tcl:400 | ERROR | || ODB | 0348 | odb.tcl:405 | ERROR | || ODB |  
 0349 | odb.tcl:409 | ERROR | || ODB | 0350 | odb.tcl:416 | ERROR | || ODB | 0351 | odb.tcl:423 | ERROR | || ODB |  
 0352 | odb.tcl:426 | ERROR | || ODB | 0353 | odb.tcl:438 | ERROR | || ODB | 0354 | odb.tcl:456 | ERROR | || ODB |  
 0355 | odb.tcl:519 | ERROR | || ODB | 0356 | lefin.cpp:2201 | WARN | || ODB | 0357 | cdl.cpp:214 | WARN | || ODB |  
 0358 | cdl.cpp:189 | ERROR | || ODB | 0359 | dbInst.cpp:477 | ERROR | || ODB | 0360 | dbInst.cpp:571 | ERROR |  
 || ODB | 0361 | lefin.cpp:2215 | WARN | || ODB | 0362 | dbInst.cpp:1461 | ERROR | || ODB | 0364 | dbNet.cpp:2976  
 | ERROR | || ODB | 0367 | dbModule.cpp:199 | ERROR | || ODB | 0368 | dbInst.cpp:1155 | ERROR | || ODB |  
 0369 | dbITerm.cpp:381 | ERROR | || ODB | 0370 | dbITerm.cpp:450 | ERROR | || ODB | 0371 | dbModule.cpp:234  
 | ERROR | || ODB | 0372 | dbITerm.cpp:461 | ERROR | || ODB | 0373 | dbITerm.cpp:389 | ERROR | || ODB |  
 0374 | dBTerm.cpp:744 | ERROR | || ODB | 0375 | dBTerm.cpp:473 | ERROR | || ODB | 0376 | dBTerm.cpp:655  
 | ERROR | || ODB | 0377 | dBTerm.cpp:438 | ERROR | || ODB | 0378 | dbBlock.cpp:3924 | WARN | || ODB |  
 0379 | dbGlobalConnect.cpp:307 | WARN | || ODB | 0380 | dbGlobalConnect.cpp:336 | WARN | || ODB | 0381  
 | dbBlock.cpp:3898 | ERROR | || ODB | 0382 | dbBlock.cpp:3902 | WARN | || ODB | 0383 | dbBlock.cpp:3970 |  
 WARN | || ODB | 0384 | dbGlobalConnect.cpp:267 | ERROR | || ODB | 0385 | dbInst.cpp:1333 | ERROR | || ODB |  
 0386 | util.cpp:439 | WARN | || ODB | 0387 | definNonDefaultRule.cpp:224 | WARN | || ODB | 0388 | lefin.cpp:764  
 | INFO | || ODB | 0389 | dbUtil.cpp:92 | ERROR | || ODB | 0390 | tmg\_conn.cpp:1205 | ERROR | || ODB | 0391 |  
 tmg\_conn.cpp:1235 | ERROR | || ODB | 0392 | tmg\_conn.cpp:1271 | ERROR | || ODB | 0393 | tmg\_conn.cpp:1742  
 | ERROR | || ODB | 0394 | lefin.cpp:1679 | INFO | || ODB | 0395 | tmg\_conn.cpp:1557 | WARN | || ODB | 0396 |  
 tmg\_conn.cpp:1639 | WARN | || ODB | 0398 | dbUtil.cpp:728 | WARN | || ODB | 0399 | dbUtil.cpp:770 | WARN | ||  
 ODB | 0400 | dbUtil.cpp:1015 | WARN | || ODB | 0401 | dbUtil.cpp:1018 | WARN | || ODB | 0402 | dbUtil.cpp:1067  
 | WARN | || ODB | 0403 | dbUtil.cpp:1093 | WARN | || ODB | 0404 | dbUtil.cpp:1306 | WARN | || ODB | 0405 |  
 dbUtil.cpp:1309 | WARN | || ODB | 0406 | dbUtil.cpp:1383 | WARN | || ODB | 0407 | dbUtil.cpp:1397 | WARN | ||  
 ODB | 0408 | dbUtil.cpp:1508 | WARN | || ODB | 0409 | dbUtil.cpp:1515 | WARN | || ODB | 0410 | dbUtil.cpp:1537  
 | WARN | || ODB | 0411 | dbUtil.cpp:1545 | WARN | || ODB | 0412 | dbUtil.cpp:1571 | WARN | || ODB | 0413 |  
 dbUtil.cpp:1579 | WARN | || ODB | 0414 | dbTrackGrid.cpp:266 | ERROR | || ODB | 0415 | dbTrackGrid.cpp:279  
 | ERROR | || ODB | 0416 | dbTrackGrid.cpp:285 | ERROR | || ODB | 0417 | dbUtil.cpp:130 | WARN | || ODB | 0418 |  
 dbTrackGrid.cpp:255 | ERROR | || ODB | 0420 | tmg\_conn.cpp:602 | ERROR | || ODB | 0421 | definReader.cpp:1900

| ERROR | | ODB | 0422 | [definReader.cpp:1936](#) | ERROR | | ODB | 0423 | [lefin.cpp:624](#) | WARN | | ODB | 0424 | [parse.cpp:65](#) | ERROR | | ODB | 0425 | [definComponentMaskShift.cpp:55](#) | WARN | | ODB | 0428 | [parse.cpp:50](#) | ERROR | | ODB | 0429 | [parse.cpp:412](#) | ERROR | | ODB | 0430 | [dbBox.cpp:798](#) | ERROR | | ODB | 0431 | [dbMaster.cpp:759](#) | ERROR | | ODB | 0432 | [dbDatabase.cpp:452](#) | ERROR | | ODB | 0433 | [dbITerm.cpp:396](#) | ERROR | | ODB | 0434 | [dbBox.cpp:465](#) | ERROR | | ODB | 0435 | [dbBox.cpp:776](#) | ERROR | | ODB | 0436 | [dbInst.cpp:1419](#) | ERROR | | ODB | 0437 | [definReader.cpp:984](#) | WARN | | ODB | 0438 | [dbDatabase.cpp:155](#) | CRITICAL | | ODB | 0439 | [odb.tcl:533](#) | ERROR | | ODB | 0440 | [dbITerm.cpp:372](#) | ERROR | | ODB | 1000 | [odb.tcl:69](#) | WARN | | ODB | 1001 | [odb.tcl:137](#) | WARN | | ODB | 1002 | [odb.tcl:140](#) | WARN | | ODB | 1004 | [odb.tcl:152](#) | ERROR | | ODB | 1005 | [odb.tcl:159](#) | ERROR | | ODB | 1006 | [odb.tcl:164](#) | ERROR | | ODB | 1007 | [odb.tcl:171](#) | ERROR | | ODB | 1008 | [odb.tcl:179](#) | ERROR | | ODB | 1009 | [odb.tcl:89](#) | WARN | | ODB | 1100 | [dbAccessPoint.cpp:315](#) | ERROR | | ODB | 1101 | [dbAccessPoint.cpp:335](#) | ERROR | | ODB | 1102 | [dbWireCodec.cpp:630](#) | ERROR | | ODB | 1103 | [dbWireCodec.cpp:654](#) | ERROR | | ODB | 2000 | [lefin.cpp:1203](#) | WARN | | ORD | 0001 | [OpenRoad.tcl:45](#) | ERROR | | ORD | 0002 | [OpenRoad.tcl:48](#) | ERROR | | ORD | 0003 | [OpenRoad.tcl:85](#) | ERROR | | ORD | 0004 | [OpenRoad.tcl:88](#) | ERROR | | ORD | 0005 | [OpenRoad.tcl:94](#) | ERROR | | ORD | 0006 | [OpenRoad.tcl:125](#) | ERROR | | ORD | 0007 | [OpenRoad.tcl:191](#) | ERROR | | ORD | 0008 | [OpenRoad.tcl:194](#) | ERROR | | ORD | 0014 | [Metrics.tcl:64](#) | ERROR | | ORD | 0015 | [OpenRoad.i:426](#) | ERROR | | ORD | 0017 | [Metrics.tcl:81](#) | ERROR | | ORD | 0018 | [Metrics.tcl:98](#) | ERROR | | ORD | 0019 | [Metrics.tcl:48](#) | ERROR | | ORD | 0030 | [OpenRoad.cc:592](#) | INFO | | ORD | 0031 | [OpenRoad.cc:578](#) | WARN | | ORD | 0032 | [OpenRoad.cc:609](#) | WARN | | ORD | 0033 | [OpenRoad.tcl:97](#) | WARN | | ORD | 0034 | [OpenRoad.cc:414](#) | INFO | | ORD | 0036 | [Design.cc:66](#) | ERROR | | ORD | 0037 | [Design.cc:127](#) | ERROR | | ORD | 0038 | [Main.cc:280](#) | WARN | | ORD | 0039 | [Main.cc:284](#) | WARN | | ORD | 0042 | [OpenRoad.tcl:303](#) | ERROR | | ORD | 0043 | [OpenRoad.tcl:311](#) | ERROR | | ORD | 0045 | [OpenRoad.tcl:341](#) | ERROR | | ORD | 0046 | [OpenRoad.tcl:333](#) | WARN | | ORD | 0047 | [OpenRoad.cc:468](#) | ERROR | | ORD | 0048 | [OpenRoad.cc:317](#) | INFO | | ORD | 0049 | [OpenRoad.i:476](#) | ERROR | | ORD | 0050 | [OpenRoad.i:487](#) | ERROR | | ORD | 0051 | [OpenRoad.cc:295](#) | ERROR | | ORD | 0052 | [OpenRoad.i:335](#) | ERROR | | ORD | 0053 | [OpenRoad.cc:397](#) | ERROR | | ORD | 0054 | [OpenRoad.cc:480](#) | ERROR | | ORD | 0101 | [Design.cc:82](#) | ERROR | | ORD | 0102 | [Design.cc:88](#) | ERROR | | ORD | 0104 | [Timing.cc:148](#) | ERROR | | ORD | 0105 | [OpenRoad.cc:514](#) | ERROR | | ORD | 0201 | [Resizer.tcl:48](#) | ERROR | | ORD | 0202 | [Resizer.tcl:57](#) | ERROR | | ORD | 0203 | [Resizer.tcl:61](#) | ERROR | | ORD | 0204 | [Resizer.tcl:65](#) | ERROR | | ORD | 0205 | [Resizer.tcl:98](#) | ERROR | | ORD | 0206 | [Resizer.tcl:102](#) | WARN | | ORD | 0208 | [Resizer.tcl:120](#) | ERROR | | ORD | 0209 | [Resizer.tcl:123](#) | ERROR | | ORD | 0560 | [OpenRoad.tcl:412](#) | ERROR | | ORD | 1009 | [OpenRoad.tcl:212](#) | ERROR | | ORD | 1010 | [OpenRoad.tcl:215](#) | ERROR | | ORD | 1011 | [OpenRoad.tcl:221](#) | ERROR | | ORD | 1012 | [OpenRoad.tcl:227](#) | ERROR | | ORD | 1013 | [OpenRoad.tcl:174](#) | ERROR | | ORD | 2001 | [dbNetwork.cc:916](#) | WARN | | ORD | 2002 | [dbNetwork.cc:1039](#) | WARN | | ORD | 2003 | [dbNetwork.cc:1216](#) | CRITICAL | | ORD | 2004 | [dbNetwork.cc:1271](#) | CRITICAL | | ORD | 2005 | [dbNetwork.cc:1276](#) | CRITICAL | | ORD | 2006 | [dbNetwork.cc:1340](#) | CRITICAL | | ORD | 2007 | [dbNetwork.cc:1397](#) | CRITICAL | | ORD | 2008 | [dbNetwork.cc:1469](#) | CRITICAL | | ORD | 2009 | [dbReadVerilog.tcl:51](#) | ERROR | | ORD | 2010 | [dbReadVerilog.tcl:58](#) | ERROR | | ORD | 2011 | [dbReadVerilog.cc:426](#) | WARN | | ORD | 2012 | [dbReadVerilog.cc:432](#) | WARN | | ORD | 2013 | [dbReadVerilog.cc:294](#) | WARN | | ORD | 2014 | [dbReadVerilog.cc:276](#) | WARN | | ORD | 2015 | [dbReadVerilog.cc:303](#) | WARN | | ORD | 2016 | [dbNetwork.cc:1312](#) | CRITICAL | | PAD | 0001 | [ICeWall.cpp:655](#) | ERROR | | PAD | 0002 | [ICeWall.cpp:1134](#) | ERROR | | PAD | 0003 | [RDLRouter.cpp:160](#) | WARN | | PAD | 0004 | [RDLRouter.cpp:174](#) | WARN | | PAD | 0005 | [RDLRouter.cpp:232](#) | INFO | | PAD | 0006 | [RDLRouter.cpp:278](#) | WARN | | PAD | 0007 | [RDLRouter.cpp:300](#) | ERROR | | PAD | 0008 | [RDLRouter.cpp:347](#) | ERROR | | PAD | 0009 | [RDLRouter.cpp:472](#) | ERROR | | PAD | 0010 | [RDLRouter.cpp:1201](#) | ERROR | | PAD | 0011 | [ICeWall.cpp:76](#) | ERROR | | PAD | 0012 | [ICeWall.cpp:90](#) | ERROR | | PAD | 0013 | [ICeWall.cpp:453](#) | ERROR | | PAD | 0014 | [ICeWall.cpp:302](#) | ERROR | | PAD | 0015 | [ICeWall.cpp:305](#) | ERROR | | PAD | 0016 | [ICeWall.cpp:308](#) | ERROR | | PAD | 0018 | [ICeWall.cpp:487](#) | ERROR | | PAD | 0019 | [ICeWall.cpp:503](#) | ERROR | | PAD | 0020 | [ICeWall.cpp:689](#) | ERROR | | PAD | 0021 | [ICeWall.cpp:867](#) | ERROR | | PAD | 0022 | [ICeWall.cpp:1324](#) | ERROR | | PAD | 0023 | [ICeWall.cpp:73](#) | ERROR | | PAD | 0024 | [ICeWall.cpp:196](#) | ERROR | | PAD | 0025 | [ICeWall.cpp:201](#) | ERROR | | PAD | 0026 | [ICeWall.cpp:771](#) | ERROR | | PAD | 0027 | [ICeWall.cpp:892](#) | ERROR | | PAD | 0028 | [ICeWall.cpp:446](#) | ERROR | | PAD | 0029 | [ICeWall.cpp:562](#) | ERROR | | PAD | 0030 | [ICeWall.cpp:847](#) | ERROR | | PAD | 0031 | [ICeWall.cpp:928](#) | WARN | | PAD | 0032 | [ICeWall.cpp:922](#) | ERROR | | PAD | 0033 | [ICeWall.cpp:159](#) | WARN | | PAD | 0034 | [ICeWall.cpp:166](#) | ERROR | | PAD | 0035 | [ICeWall.cpp:221](#) | ERROR | | PAD | 0036 | [ICeWall.cpp:227](#) | ERROR | | PAD | 0037 | [RDLRouter.cpp:1299](#) | ERROR | | PAD | 0100 | [pad.tcl:447](#) | ERROR | | PAD | 0101 | [pad.tcl:455](#) | ERROR | | PAD | 0102 | [pad.tcl:463](#) | ERROR | | PAD | 0103 | [pad.tcl:471](#) | ERROR | | PAD | 0104 | [pad.tcl:479](#) | ERROR | | PAD

| 0105 | pad.tcl:393 | ERROR |- || PAD | 0106 | pad.i:161 | ERROR |- || PAD | 0107 | pad.tcl:399 | ERROR |- || PAD | 0108 | pad.tcl:406 | ERROR |- || PAD | 0109 | pad.tcl:487 | ERROR |- || PAD | 0110 | pad.tcl:492 | ERROR |- || PAD | 0111 | pad.tcl:497 | ERROR |- || PAD | 0112 | pad.tcl:158 | WARN |- || PAD | 0113 | pad.tcl:115 | ERROR |- || PAD | 0114 | pad.tcl:121 | ERROR |- || PAD | 0115 | ICeWall.cpp:1032 | ERROR |- || PAD | 0116 | ICeWall.cpp:177 | INFO |- || PAD | 0117 | pad.tcl:308 | ERROR |- || PAD | 0118 | ICeWall.cpp:494 | ERROR |- || PAD | 0119 | ICeWall.cpp:626 | ERROR |- || PAD | 0120 | ICeWall.cpp:1042 | ERROR |- || PAD | 0232 | grid.cpp:1550 | WARN |- || PAD | 9001 | ICeWall.tcl:1926 | ERROR |- || PAD | 9002 | ICeWall.tcl:1722 | ERROR |- || PAD | 9004 | ICeWall.tcl:2509 | WARN |- || PAD | 9005 | ICeWall.tcl:413 | ERROR |- || PAD | 9006 | ICeWall.tcl:459 | ERROR |- || PAD | 9007 | ICeWall.tcl:1896 | ERROR |- || PAD | 9008 | ICeWall.tcl:1135 | ERROR |- || PAD | 9009 | ICeWall.tcl:5021 | ERROR |- || PAD | 9010 | ICeWall.tcl:5050 | ERROR |- || PAD | 9011 | ICeWall.tcl:1684 | WARN |- || PAD | 9012 | ICeWall.tcl:2553 | WARN |- || PAD | 9014 | ICeWall.tcl:4672 | ERROR |- || PAD | 9015 | ICeWall.tcl:4345 | ERROR |- || PAD | 9016 | ICeWall.tcl:769 | ERROR |- || PAD | 9017 | ICeWall.tcl:2039 | ERROR |- || PAD | 9018 | ICeWall.tcl:4697 | WARN |- || PAD | 9019 | ICeWall.tcl:2600 | WARN |- || PAD | 9021 | ICeWall.tcl:1342 | ERROR |- || PAD | 9022 | ICeWall.tcl:1324 | ERROR |- || PAD | 9023 | ICeWall.tcl:1329 | ERROR |- || PAD | 9024 | ICeWall.tcl:496 | ERROR |- || PAD | 9025 | ICeWall.tcl:567 | ERROR |- || PAD | 9026 | ICeWall.tcl:507 | ERROR |- || PAD | 9027 | ICeWall.tcl:3277 | ERROR |- || PAD | 9028 | ICeWall.tcl:3297 | ERROR |- || PAD | 9029 | ICeWall.tcl:4749 | ERROR |- || PAD | 9030 | ICeWall.tcl:4817 | ERROR |- || PAD | 9031 | ICeWall.tcl:672 | ERROR |- || PAD | 9032 | ICeWall.tcl:968 | ERROR |- || PAD | 9033 | ICeWall.tcl:1241 | ERROR |- || PAD | 9034 | ICeWall.tcl:2728 | ERROR |- || PAD | 9035 | ICeWall.tcl:2814 | ERROR |- || PAD | 9036 | ICeWall.tcl:2894 | ERROR |- || PAD | 9037 | ICeWall.tcl:2866 | ERROR |- || PAD | 9038 | ICeWall.tcl:2905 | ERROR |- || PAD | 9039 | ICeWall.tcl:2917 | ERROR |- || PAD | 9040 | ICeWall.tcl:2930 | ERROR |- || PAD | 9041 | ICeWall.tcl:686 | ERROR |- || PAD | 9042 | ICeWall.tcl:2096 | WARN |- || PAD | 9043 | ICeWall.tcl:2099 | ERROR |- || PAD | 9044 | ICeWall.tcl:2231 | ERROR |- || PAD | 9045 | ICeWall.tcl:2247 | ERROR |- || PAD | 9046 | ICeWall.tcl:2286 | WARN |- || PAD | 9047 | ICeWall.tcl:2291 | WARN |- || PAD | 9048 | ICeWall.tcl:2655 | WARN |- || PAD | 9049 | ICeWall.tcl:1144 | ERROR |- || PAD | 9050 | ICeWall.tcl:4662 | WARN |- || PAD | 9051 | ICeWall.tcl:2540 | INFO |- || PAD | 9052 | ICeWall.tcl:3832 | INFO |- || PAD | 9053 | ICeWall.tcl:4703 | INFO |- || PAD | 9054 | ICeWall.tcl:375 | ERROR |- || PAD | 9055 | ICeWall.tcl:378 | ERROR |- || PAD | 9056 | ICeWall.tcl:421 | ERROR |- || PAD | 9057 | ICeWall.tcl:424 | ERROR |- || PAD | 9058 | ICeWall.tcl:470 | ERROR |- || PAD | 9059 | ICeWall.tcl:474 | ERROR |- || PAD | 9060 | ICeWall.tcl:586 | ERROR |- || PAD | 9061 | ICeWall.tcl:717 | ERROR |- || PAD | 9062 | ICeWall.tcl:728 | ERROR |- || PAD | 9063 | ICeWall.tcl:865 | ERROR |- || PAD | 9064 | ICeWall.tcl:871 | ERROR |- || PAD | 9065 | ICeWall.tcl:913 | ERROR |- || PAD | 9066 | ICeWall.tcl:1013 | ERROR |- || PAD | 9070 | ICeWall.tcl:1190 | ERROR |- || PAD | 9071 | ICeWall.tcl:1204 | ERROR |- || PAD | 9072 | ICeWall.tcl:1399 | ERROR |- || PAD | 9073 | ICeWall.tcl:1403 | ERROR |- || PAD | 9074 | ICeWall.tcl:1406 | ERROR |- || PAD | 9075 | ICeWall.tcl:1443 | ERROR |- || PAD | 9076 | ICeWall.tcl:1446 | ERROR |- || PAD | 9077 | ICeWall.tcl:1449 | ERROR |- || PAD | 9078 | ICeWall.tcl:2567 | ERROR |- || PAD | 9079 | ICeWall.tcl:2969 | ERROR |- || PAD | 9080 | ICeWall.tcl:4429 | ERROR |- || PAD | 9081 | ICeWall.tcl:4439 | ERROR |- || PAD | 9082 | ICeWall.tcl:4564 | ERROR |- || PAD | 9083 | ICeWall.tcl:4568 | ERROR |- || PAD | 9084 | ICeWall.tcl:4722 | ERROR |- || PAD | 9085 | ICeWall.tcl:4726 | ERROR |- || PAD | 9086 | ICeWall.tcl:4882 | ERROR |- || PAD | 9087 | ICeWall.tcl:4886 | ERROR |- || PAD | 9091 | ICeWall.tcl:5294 | ERROR |- || PAD | 9092 | ICeWall.tcl:5292 | ERROR |- || PAD | 9093 | ICeWall.tcl:5308 | ERROR |- || PAD | 9094 | ICeWall.tcl:5324 | ERROR |- || PAD | 9095 | ICeWall.tcl:5334 | ERROR |- || PAD | 9096 | ICeWall.tcl:1146 | ERROR |- || PAD | 9097 | ICeWall.tcl:1148 | ERROR |- || PAD | 9098 | ICeWall.tcl:5337 | ERROR |- || PAD | 9099 | ICeWall.tcl:5435 | ERROR |- || PAD | 9100 | ICeWall.tcl:5442 | ERROR |- || PAD | 9101 | ICeWall.tcl:5445 | ERROR |- || PAD | 9102 | ICeWall.tcl:5450 | ERROR |- || PAD | 9103 | ICeWall.tcl:5455 | ERROR |- || PAD | 9104 | ICeWall.tcl:5458 | ERROR |- || PAD | 9105 | ICeWall.tcl:5472 | ERROR |- || PAD | 9106 | ICeWall.tcl:5481 | ERROR |- || PAD | 9109 | ICeWall.tcl:5859 | ERROR |- || PAD | 9110 | ICeWall.tcl:5877 | ERROR |- || PAD | 9111 | ICeWall.tcl:5780 | ERROR |- || PAD | 9112 | ICeWall.tcl:5910 | ERROR |- || PAD | 9113 | ICeWall.tcl:6539 | ERROR |- || PAD | 9114 | ICeWall.tcl:605 | ERROR |- || PAD | 9115 | ICeWall.tcl:625 | ERROR |- || PAD | 9116 | ICeWall.tcl:788 | ERROR |- || PAD | 9117 | ICeWall.tcl:804 | ERROR |- || PAD | 9119 | ICeWall.tcl:809 | ERROR |- || PAD | 9120 | ICeWall.tcl:1168 | ERROR |- || PAD | 9121 | ICeWall.tcl:1171 | ERROR |- || PAD | 9122 | ICeWall.tcl:5540 | ERROR |- || PAD | 9123 | ICeWall.tcl:5926 | ERROR |- || PAD | 9124 | ICeWall.tcl:5956 | ERROR |- || PAD | 9125 | ICeWall.tcl:5963 | ERROR |- || PAD | 9126 | ICeWall.tcl:5969 | ERROR |- || PAD | 9127 | ICeWall.tcl:5988 | ERROR |- || PAD | 9128 | ICeWall.tcl:5995 | ERROR |- || PAD | 9129 | ICeWall.tcl:6013 | ERROR |- || PAD | 9130 | ICeWall.tcl:6019 | ERROR |- || PAD | 9131 | ICeWall.tcl:6032 | ERROR |- || PAD | 9132 | ICeWall.tcl:6038 | ERROR |- || PAD | 9133 | ICeWall.tcl:6052 | ERROR |- || PAD | 9134 | ICeWall.tcl:6063 | ERROR |- || PAD | 9135 | ICeWall.tcl:6067 | WARN |- || PAD | 9136 | ICeWall.tcl:6078 | ERROR |- || PAD | 9137 | ICeWall.tcl:6082 | ERROR |- || PAD | 9140 | ICeWall.tcl:5950 | ERROR |- || PAD | 9141 | ICeWall.tcl:2026 | ERROR

- || PAD | 9142 | ICeWall.tcl:5602 | ERROR |- || PAD | 9143 | ICeWall.tcl:5607 | ERROR |- || PAD | 9144 | ICeWall.tcl:5627 | ERROR |- || PAD | 9145 | ICeWall.tcl:5632 | ERROR |- || PAD | 9146 | ICeWall.tcl:5731 | ERROR |- || PAD | 9147 | ICeWall.tcl:5708 | ERROR |- || PAD | 9159 | ICeWall.tcl:6006 | INFO |- || PAD | 9160 | ICeWall.tcl:5717 | ERROR |- || PAD | 9161 | ICeWall.tcl:1061 | ERROR |- || PAD | 9162 | ICeWall.tcl:2978 | ERROR |- || PAD | 9163 | ICeWall.tcl:6111 | ERROR |- || PAD | 9164 | ICeWall.tcl:6114 | ERROR |- || PAD | 9165 | ICeWall.tcl:6166 | ERROR |- || PAD | 9166 | ICeWall.tcl:6179 | ERROR |- || PAD | 9167 | ICeWall.tcl:6185 | ERROR |- || PAD | 9168 | ICeWall.tcl:6192 | ERROR |- || PAD | 9169 | ICeWall.tcl:6198 | ERROR |- || PAD | 9170 | ICeWall.tcl:6208 | ERROR |- || PAD | 9171 | ICeWall.tcl:6214 | ERROR |- || PAD | 9173 | ICeWall.tcl:6229 | ERROR |- || PAD | 9174 | ICeWall.tcl:6313 | ERROR |- || PAD | 9175 | ICeWall.tcl:6324 | ERROR |- || PAD | 9176 | ICeWall.tcl:6344 | ERROR |- || PAD | 9177 | ICeWall.tcl:6348 | ERROR |- || PAD | 9178 | ICeWall.tcl:6364 | ERROR |- || PAD | 9179 | ICeWall.tcl:6372 | ERROR |- || PAD | 9180 | ICeWall.tcl:6411 | ERROR |- || PAD | 9181 | ICeWall.tcl:6427 | ERROR |- || PAD | 9182 | ICeWall.tcl:6438 | ERROR |- || PAD | 9183 | ICeWall.tcl:6479 | ERROR |- || PAD | 9184 | ICeWall.tcl:6493 | ERROR |- || PAD | 9185 | ICeWall.tcl:6513 | ERROR |- || PAD | 9187 | ICeWall.tcl:366 | ERROR |- || PAD | 9188 | ICeWall.tcl:6617 | ERROR |- || PAD | 9189 | ICeWall.tcl:6626 | ERROR |- || PAD | 9190 | ICeWall.tcl:6633 | ERROR |- || PAD | 9191 | ICeWall.tcl:6641 | ERROR |- || PAD | 9192 | ICeWall.tcl:6644 | ERROR |- || PAD | 9193 | ICeWall.tcl:6651 | ERROR |- || PAD | 9194 | ICeWall.tcl:6654 | ERROR |- || PAD | 9195 | ICeWall.tcl:6657 | ERROR |- || PAD | 9196 | ICeWall.tcl:6660 | ERROR |- || PAD | 9197 | ICeWall.tcl:6667 | ERROR |- || PAD | 9198 | ICeWall.tcl:6672 | ERROR |- || PAD | 9199 | ICeWall.tcl:6678 | ERROR |- || PAD | 9200 | ICeWall.tcl:5902 | ERROR |- || PAD | 9201 | ICeWall.tcl:6390 | ERROR |- || PAD | 9202 | ICeWall.tcl:6398 | ERROR |- || PAD | 9203 | ICeWall.tcl:359 | ERROR |- || PAD | 9204 | ICeWall.tcl:362 | ERROR |- || PAD | 9205 | ICeWall.tcl:5686 | ERROR |- || PAD | 9207 | ICeWall.tcl:4780 | ERROR |- || PAD | 9208 | ICeWall.tcl:206 | ERROR |- || PAD | 9209 | ICeWall.tcl:5790 | ERROR |- || PAD | 9210 | ICeWall.tcl:5795 | ERROR |- || PAD | 9211 | ICeWall.tcl:5808 | ERROR |- || PAD | 9212 | ICeWall.tcl:5819 | ERROR |- || PAD | 9213 | ICeWall.tcl:5822 | ERROR |- || PAD | 9214 | ICeWall.tcl:5834 | ERROR |- || PAD | 9215 | ICeWall.tcl:5841 | ERROR |- || PAD | 9216 | ICeWall.tcl:5881 | ERROR |- || PAD | 9217 | ICeWall.tcl:2382 | ERROR |- || PAD | 9218 | ICeWall.tcl:52 | ERROR |- || PAD | 9219 | ICeWall.tcl:125 | ERROR |- || PAD | 9220 | ICeWall.tcl:196 | ERROR |- || PAD | 9221 | ICeWall.tcl:236 | ERROR |- || PAD | 9222 | ICeWall.tcl:251 | ERROR |- || PAD | 9223 | ICeWall.tcl:2354 | ERROR |- || PAD | 9224 | ICeWall.tcl:232 | ERROR |- || PAD | 9225 | ICeWall.tcl:192 | ERROR |- || PAD | 9226 | ICeWall.tcl:117 | ERROR |- || PAD | 9227 | ICeWall.tcl:244 | ERROR |- || PAD | 9228 | ICeWall.tcl:6605 | ERROR |- || PAD | 9229 | ICeWall.tcl:5422 | ERROR |- || PAD | 9230 | ICeWall.tcl:5425 | ERROR |- || PAD | 9231 | ICeWall.tcl:61 | ERROR |- || PAD | 9232 | ICeWall.tcl:84 | ERROR |- || PAD | 9233 | ICeWall.tcl:73 | ERROR |- || PAD | 9234 | ICeWall.tcl:76 | ERROR |- || PAD | 9235 | ICeWall.tcl:3737 | ERROR |- || PAD | 9236 | ICeWall.tcl:3864 | ERROR |- || PAD | 9237 | ICeWall.tcl:69 | ERROR |- || PAD | 9238 | ICeWall.tcl:3710 | ERROR |- || PAD | 9239 | ICeWall.tcl:5352 | ERROR |- || PAD | 9240 | ICeWall.tcl:5345 | ERROR |- || PAD | 9241 | ICeWall.tcl:5376 | ERROR |- || PAD | 9242 | ICeWall.tcl:5380 | ERROR |- || PAD | 9243 | ICeWall.tcl:5409 | ERROR |- || PAD | 9244 | ICeWall.tcl:5412 | ERROR |- || PAD | 9245 | ICeWall.tcl:5415 | ERROR |- || PAD | 9246 | ICeWall.tcl:5778 | INFO |- || PAD | 9247 | ICeWall.tcl:4222 | ERROR |- || PAD | 9248 | ICeWall.tcl:4273 | ERROR |- || PAD | 9249 | ICeWall.tcl:4241 | ERROR |- || PAD | 9250 | ICeWall.tcl:4034 | ERROR |- || PAD | 9251 | ICeWall.tcl:1124 | WARN |- || PAD | 9252 | ICeWall.tcl:2643 | ERROR |- || PAD | 9253 | ICeWall.tcl:3815 | ERROR |- || PAD | 9254 | ICeWall.tcl:5082 | WARN |- || PAD | 9255 | ICeWall.tcl:5084 | WARN |- || PAD | 9256 | ICeWall.tcl:5087 | ERROR |- || PAD | 9257 | ICeWall.tcl:2622 | ERROR |- || PAD | 9258 | ICeWall.tcl:5750 | ERROR |- || PAD | 9259 | ICeWall.tcl:5740 | ERROR |- || PAD | 9260 | ICeWall.tcl:3466 | ERROR |- || PAD | 9261 | ICeWall.tcl:3501 | ERROR |- || PAD | 9262 | ICeWall.tcl:3442 | WARN |- || PAD | 9263 | ICeWall.tcl:3446 | WARN |- || PAD | 9264 | ICeWall.tcl:3588 | WARN |- || PAD | 9265 | ICeWall.tcl:3626 | WARN |- || PAD | 9266 | ICeWall.tcl:3628 | WARN |- || PAD | 9267 | ICeWall.tcl:3657 | WARN |- || PAD | 9268 | ICeWall.tcl:3659 | WARN |- || PAD | 9269 | ICeWall.tcl:3666 | WARN |- || PAD | 9270 | ICeWall.tcl:3668 | WARN |- || PAD | 9271 | ICeWall.tcl:3678 | WARN |- || PAR | 0001 | PartitionMgr.cpp:762 | INFO |- || PAR | 0002 | TritonPart.cpp:234 | INFO |- || PAR | 0003 | TritonPart.cpp:275 | WARN |- || PAR | 0004 | TritonPart.cpp:323 | INFO |- || PAR | 0005 | TritonPart.cpp:392 | INFO |- || PAR | 0006 | TritonPart.cpp:446 | INFO |- || PAR | 0007 | TritonPart.cpp:481 | INFO |- || PAR | 0008 | TritonPart.cpp:521 | ERROR |- || PAR | 0009 | TritonPart.cpp:532 | WARN |- || PAR | 0010 | TritonPart.cpp:692 | INFO |- || PAR | 0011 | TritonPart.cpp:769 | INFO |- || PAR | 0012 | TritonPart.cpp:886 | INFO |- || PAR | 0013 | TritonPart.cpp:892 | INFO |- || PAR | 0015 | PartitionMgr.cpp:771 | WARN |- || PAR | 0017 | TritonPart.cpp:1216 | INFO |- || PAR | 0018 | TritonPart.cpp:1527 | INFO |- || PAR | 0019 | TritonPart.cpp:1736 | WARN |- || PAR | 0021 | TritonPart.cpp:1351 | WARN |- || PAR | 0022 | TritonPart.cpp:1378 | WARN |- || PAR | 0023 | TritonPart.cpp:1405 | WARN |- || PAR | 0024 | TritonPart.cpp:1544 | WARN |- || PAR | 0025 | PartitionMgr.cpp:838 | ERROR |- || PAR | 0026 | PartitionMgr.cpp:847 | ERROR |- || PAR | 0027 | PartitionMgr.cpp:870 | ERROR |- || PAR | 0028 | Partition-

Mgr.cpp:881 | ERROR |- || PAR | 0029 | TritonPart.cpp:901 | ERROR |- || PAR | 0030 | TritonPart.cpp:997 | ERROR |- || PAR | 0031 | TritonPart.cpp:1078 | ERROR |- || PAR | 0032 | TritonPart.cpp:1096 | ERROR |- || PAR | 0033 | TritonPart.cpp:1117 | ERROR |- || PAR | 0034 | TritonPart.cpp:1140 | ERROR |- || PAR | 0035 | TritonPart.cpp:1501 | ERROR |- || PAR | 0036 | PartitionMgr.cpp:860 | ERROR |- || PAR | 0037 | TritonPart.cpp:1496 | INFO |- || PAR | 0051 | partitionmgr.tcl:1015 | ERROR |- || PAR | 0142 | Evaluator.cpp:286 | WARN |- || PAR | 0924 | partitionmgr.tcl:114 | ERROR |- || PAR | 0925 | partitionmgr.tcl:350 | ERROR |- || PDN | 0001 | grid.cpp:134 | INFO |- || PDN | 0100 | domain.cpp:260 | ERROR |- || PDN | 0101 | domain.cpp:282 | INFO |- || PDN | 0102 | domain.cpp:291 | INFO |- || PDN | 0103 | domain.cpp:84 | ERROR |- || PDN | 0104 | domain.cpp:87 | ERROR |- || PDN | 0105 | rings.cpp:123 | WARN |- || PDN | 0106 | grid\_component.cpp:364 | ERROR |- || PDN | 0107 | grid\_component.cpp:376 | ERROR |- || PDN | 0108 | grid\_component.cpp:446 | ERROR |- || PDN | 0109 | straps.cpp:473 | ERROR |- || PDN | 0110 | via.cpp:986 | WARN |- || PDN | 0113 | PdnGen.tcl:576 | ERROR |- || PDN | 0114 | grid\_component.cpp:424 | ERROR |- || PDN | 0115 | sroute.cpp:95 | ERROR |- || PDN | 0116 | sroute.cpp:151 | ERROR |- || PDN | 0174 | PdnGen.tcl:6612 | ERROR |- || PDN | 0175 | straps.cpp:102 | ERROR |- || PDN | 0178 | straps.cpp:2229 | WARN |- || PDN | 0179 | straps.cpp:2238 | ERROR |- || PDN | 0180 | rings.cpp:63 | ERROR |- || PDN | 0181 | domain.cpp:267 | ERROR |- || PDN | 0182 | PdnGen.cc:523 | WARN |- || PDN | 0183 | PdnGen.cc:319 | WARN |- || PDN | 0184 | PdnGen.cc:347 | ERROR |- || PDN | 0185 | straps.cpp:127 | ERROR |- || PDN | 0186 | grid.cpp:116 | ERROR |- || PDN | 0187 | straps.cpp:82 | ERROR |- || PDN | 0188 | grid.cpp:1692 | ERROR |- || PDN | 0189 | PdnGen.cc:918 | WARN |- || PDN | 0190 | straps.cpp:347 | ERROR |- || PDN | 0191 | techlayer.cpp:147 | ERROR |- || PDN | 0192 | grid.cpp:618 | ERROR |- || PDN | 0193 | grid.cpp:626 | ERROR |- || PDN | 0194 | grid.cpp:650 | ERROR |- || PDN | 0195 | via.cpp:2874 | WARN |- || PDN | 0196 | PdnGen.cc:389 | ERROR |- || PDN | 0197 | power\_cells.cpp:153 | ERROR |- || PDN | 0198 | power\_cells.cpp:124 | ERROR |- || PDN | 0199 | PdnGen.cc:360 | ERROR |- || PDN | 0200 | shape.cpp:385 | WARN |- || PDN | 0201 | PdnGen.cc:461 | ERROR |- || PDN | 0202 | PdnGen.cc:465 | ERROR |- || PDN | 0203 | PdnGen.cc:988 | ERROR |- || PDN | 0204 | PdnGen.cc:997 | ERROR |- || PDN | 0205 | PdnGen.cc:1028 | ERROR |- || PDN | 0206 | PdnGen.cc:1035 | ERROR |- || PDN | 0207 | PdnGen.cc:1042 | ERROR |- || PDN | 0208 | PdnGen.cc:1049 | ERROR |- || PDN | 0209 | PdnGen.cc:1063 | WARN |- || PDN | 0210 | PdnGen.cc:326 | ERROR |- || PDN | 0220 | power\_cells.cpp:247 | ERROR |- || PDN | 0221 | power\_cells.cpp:300 | ERROR |- || PDN | 0222 | power\_cells.cpp:236 | WARN |- || PDN | 0223 | power\_cells.cpp:328 | WARN |- || PDN | 0224 | grid\_component.cpp:472 | ERROR |- || PDN | 0225 | pdn.tcl:343 | ERROR |- || PDN | 0226 | via\_repair.cpp:130 | WARN |- || PDN | 0227 | via.cpp:907 | WARN |- || PDN | 0228 | PdnGen.cc:799 | WARN |- || PDN | 0229 | PdnGen.cc:343 | ERROR |- || PDN | 0230 | pdn.tcl:471 | ERROR |- || PDN | 0231 | grid.cpp:1523 | WARN |- || PDN | 0232 | PdnGen.cc:168 | WARN |- || PDN | 0233 | PdnGen.cc:175 | ERROR |- || PDN | 0234 | PdnGen.cc:933 | WARN |- || PDN | 0235 | PdnGen.cc:938 | ERROR |- || PDN | 0236 | PdnGen.cc:1118 | ERROR |- || PDN | 0237 | PdnGen.cc:1126 | ERROR |- || PDN | 0238 | PdnGen.cc:1058 | ERROR |- || PDN | 1001 | pdn.tcl:99 | ERROR |- || PDN | 1002 | pdn.tcl:103 | ERROR |- || PDN | 1003 | pdn.tcl:108 | ERROR |- || PDN | 1004 | pdn.tcl:112 | ERROR |- || PDN | 1005 | pdn.tcl:121 | ERROR |- || PDN | 1006 | pdn.tcl:136 | ERROR |- || PDN | 1007 | pdn.tcl:293 | ERROR |- || PDN | 1008 | pdn.tcl:298 | ERROR |- || PDN | 1009 | pdn.tcl:304 | ERROR |- || PDN | 1011 | pdn.tcl:422 | ERROR |- || PDN | 1013 | pdn.tcl:432 | ERROR |- || PDN | 1014 | pdn.tcl:438 | ERROR |- || PDN | 1015 | pdn.tcl:444 | ERROR |- || PDN | 1016 | pdn.tcl:446 | ERROR |- || PDN | 1017 | pdn.tcl:458 | ERROR |- || PDN | 1019 | pdn.tcl:564 | ERROR |- || PDN | 1020 | pdn.tcl:566 | ERROR |- || PDN | 1021 | pdn.tcl:602 | ERROR |- || PDN | 1022 | pdn.tcl:824 | ERROR |- || PDN | 1023 | pdn.tcl:838 | ERROR |- || PDN | 1024 | pdn.tcl:847 | WARN |- || PDN | 1025 | pdn.tcl:869 | ERROR |- || PDN | 1026 | pdn.tcl:962 | ERROR |- || PDN | 1027 | pdn.tcl:978 | ERROR |- || PDN | 1028 | pdn.tcl:982 | ERROR |- || PDN | 1029 | pdn.tcl:991 | ERROR |- || PDN | 1030 | pdn.tcl:1035 | ERROR |- || PDN | 1032 | pdn.tcl:1103 | ERROR |- || PDN | 1033 | pdn.tcl:1150 | ERROR |- || PDN | 1034 | pdn.tcl:1163 | ERROR |- || PDN | 1035 | pdn.tcl:1182 | ERROR |- || PDN | 1036 | pdn.tcl:1206 | ERROR |- || PDN | 1037 | pdn.tcl:49 | ERROR |- || PDN | 1038 | pdn.tcl:56 | ERROR |- || PDN | 1039 | pdn.tcl:63 | ERROR |- || PDN | 1040 | pdn.tcl:1499 | ERROR |- || PDN | 1041 | pdn.tcl:1502 | ERROR |- || PDN | 1042 | pdn.tcl:162 | WARN |- || PDN | 1043 | pdn.tcl:873 | ERROR |- || PDN | 1044 | pdn.tcl:994 | ERROR |- || PDN | 1045 | pdn.tcl:902 | ERROR |- || PDN | 1046 | pdn.tcl:226 | ERROR |- || PDN | 1047 | pdn.tcl:1189 | ERROR |- || PDN | 1048 | pdn.tcl:898 | ERROR |- || PDN | 1049 | pdn.tcl:906 | ERROR |- || PDN | 1183 | pdn.tcl:222 | ERROR |- || PDN | 1184 | pdn.tcl:231 | ERROR |- || PDN | 1186 | pdn.tcl:242 | ERROR |- || PDN | 1187 | pdn.tcl:248 | ERROR |- || PDN | 1188 | pdn.tcl:254 | ERROR |- || PDN | 1190 | pdn.tcl:780 | ERROR |- || PDN | 1191 | pdn.tcl:770 | ERROR |- || PDN | 1192 | pdn.tcl:773 | ERROR |- || PDN | 9002 | PdnGen.tcl:3146 | WARN |- || PDN | 9003 | PdnGen.tcl:3150 | WARN |- || PDN | 9004 | PdnGen.tcl:3160 | WARN |- || PDN | 9006 | PdnGen.tcl:5364 | WARN |- || PDN | 9008 | PdnGen.tcl:4932 | INFO |- || PDN | 9009 | PdnGen.tcl:4979 | INFO |- || PDN | 9010 | PdnGen.tcl:6787 | INFO |- || PDN | 9011 | PdnGen.tcl:6823 | INFO |- || PDN | 9012 | PdnGen.tcl:6833 | INFO |- || PDN | 9013 | PdnGen.tcl:6837 | INFO |- || PDN | 9014 | PdnGen.tcl:6839 | INFO |- || PDN | 9015 |

PdnGen.tcl:6868 | INFO |- || PDN | 9016 | PdnGen.tcl:6888 | INFO |- || PDN | 9017 | PdnGen.tcl:4234 | ERROR |- || PDN | 9018 | PdnGen.tcl:6820 | WARN |- || PDN | 9019 | PdnGen.tcl:1472 | ERROR |- || PDN | 9020 | PdnGen.tcl:1644 | ERROR |- || PDN | 9021 | PdnGen.tcl:1709 | ERROR |- || PDN | 9022 | PdnGen.tcl:2922 | ERROR |- || PDN | 9023 | PdnGen.tcl:2923 | ERROR |- || PDN | 9024 | PdnGen.tcl:2930 | ERROR |- || PDN | 9025 | PdnGen.tcl:3316 | ERROR |- || PDN | 9026 | PdnGen.tcl:3462 | ERROR |- || PDN | 9027 | PdnGen.tcl:4742 | ERROR |- || PDN | 9028 | PdnGen.tcl:6898 | ERROR |- || PDN | 9029 | PdnGen.tcl:4885 | ERROR |- || PDN | 9030 | PdnGen.tcl:5024 | ERROR |- || PDN | 9032 | PdnGen.tcl:5644 | INFO |- || PDN | 9033 | PdnGen.tcl:1380 | ERROR |- || PDN | 9034 | PdnGen.tcl:6790 | INFO |- || PDN | 9035 | PdnGen.tcl:5724 | WARN |- || PDN | 9036 | PdnGen.tcl:2756 | WARN |- || PDN | 9037 | PdnGen.tcl:4786 | ERROR |- || PDN | 9038 | PdnGen.tcl:2729 | WARN |- || PDN | 9039 | PdnGen.tcl:2750 | WARN |- || PDN | 9040 | PdnGen.tcl:3179 | WARN |- || PDN | 9041 | PdnGen.tcl:3185 | WARN |- || PDN | 9042 | PdnGen.tcl:3193 | WARN |- || PDN | 9043 | PdnGen.tcl:3199 | WARN |- || PDN | 9044 | PdnGen.tcl:3080 | ERROR |- || PDN | 9045 | PdnGen.tcl:3101 | ERROR |- || PDN | 9048 | PdnGen.tcl:3983 | ERROR |- || PDN | 9051 | PdnGen.tcl:5970 | ERROR |- || PDN | 9052 | PdnGen.tcl:3042 | ERROR |- || PDN | 9055 | PdnGen.tcl:5089 | WARN |- || PDN | 9056 | PdnGen.tcl:5093 | WARN |- || PDN | 9062 | PdnGen.tcl:6894 | ERROR |- || PDN | 9063 | PdnGen.tcl:2909 | WARN |- || PDN | 9064 | PdnGen.tcl:4043 | WARN |- || PDN | 9065 | PdnGen.tcl:4046 | WARN |- || PDN | 9066 | PdnGen.tcl:4049 | WARN |- || PDN | 9067 | PdnGen.tcl:4052 | WARN |- || PDN | 9068 | PdnGen.tcl:4055 | ERROR |- || PDN | 9069 | PdnGen.tcl:4603 | ERROR |- || PDN | 9070 | PdnGen.tcl:4648 | ERROR |- || PDN | 9071 | PdnGen.tcl:4654 | ERROR |- || PDN | 9072 | PdnGen.tcl:87 | ERROR |- || PDN | 9075 | PdnGen.tcl:116 | ERROR |- || PDN | 9076 | PdnGen.tcl:119 | ERROR |- || PDN | 9079 | PdnGen.tcl:151 | ERROR |- || PDN | 9081 | PdnGen.tcl:158 | ERROR |- || PDN | 9083 | PdnGen.tcl:177 | ERROR |- || PDN | 9084 | PdnGen.tcl:184 | ERROR |- || PDN | 9085 | PdnGen.tcl:198 | ERROR |- || PDN | 9086 | PdnGen.tcl:201 | ERROR |- || PDN | 9087 | PdnGen.tcl:210 | ERROR |- || PDN | 9088 | PdnGen.tcl:549 | ERROR |- || PDN | 9090 | PdnGen.tcl:1195 | ERROR |- || PDN | 9095 | PdnGen.tcl:277 | ERROR |- || PDN | 9109 | PdnGen.tcl:233 | ERROR |- || PDN | 9110 | PdnGen.tcl:288 | ERROR |- || PDN | 9111 | PdnGen.tcl:300 | ERROR |- || PDN | 9112 | PdnGen.tcl:310 | WARN |- || PDN | 9114 | PdnGen.tcl:706 | ERROR |- || PDN | 9115 | PdnGen.tcl:911 | ERROR |- || PDN | 9116 | PdnGen.tcl:924 | ERROR |- || PDN | 9117 | PdnGen.tcl:937 | ERROR |- || PDN | 9118 | PdnGen.tcl:950 | ERROR |- || PDN | 9119 | PdnGen.tcl:977 | ERROR |- || PDN | 9121 | PdnGen.tcl:241 | ERROR |- || PDN | 9124 | PdnGen.tcl:740 | ERROR |- || PDN | 9125 | PdnGen.tcl:963 | ERROR |- || PDN | 9126 | PdnGen.tcl:1008 | ERROR |- || PDN | 9127 | PdnGen.tcl:321 | ERROR |- || PDN | 9128 | PdnGen.tcl:362 | ERROR |- || PDN | 9129 | PdnGen.tcl:399 | ERROR |- || PDN | 9130 | PdnGen.tcl:446 | ERROR |- || PDN | 9138 | PdnGen.tcl:456 | ERROR |- || PDN | 9139 | PdnGen.tcl:261 | ERROR |- || PDN | 9140 | PdnGen.tcl:267 | ERROR |- || PDN | 9141 | PdnGen.tcl:269 | ERROR |- || PDN | 9146 | PdnGen.tcl:257 | ERROR |- || PDN | 9147 | PdnGen.tcl:1143 | ERROR |- || PDN | 9148 | PdnGen.tcl:1146 | ERROR |- || PDN | 9149 | PdnGen.tcl:835 | ERROR |- || PDN | 9150 | PdnGen.tcl:849 | WARN |- || PDN | 9151 | PdnGen.tcl:868 | ERROR |- || PDN | 9152 | PdnGen.tcl:882 | WARN |- || PDN | 9153 | PdnGen.tcl:1155 | ERROR |- || PDN | 9154 | PdnGen.tcl:1158 | ERROR |- || PDN | 9155 | PdnGen.tcl:1168 | ERROR |- || PDN | 9156 | PdnGen.tcl:1171 | ERROR |- || PDN | 9158 | PdnGen.tcl:757 | ERROR |- || PDN | 9159 | PdnGen.tcl:768 | ERROR |- || PDN | 9160 | PdnGen.tcl:5691 | ERROR |- || PDN | 9164 | PdnGen.tcl:500 | ERROR |- || PDN | 9165 | PdnGen.tcl:1097 | ERROR |- || PDN | 9166 | PdnGen.tcl:1281 | ERROR |- || PDN | 9168 | PdnGen.tcl:2998 | ERROR |- || PDN | 9169 | PdnGen.tcl:6136 | WARN |- || PDN | 9170 | PdnGen.tcl:6156 | WARN |- || PDN | 9171 | PdnGen.tcl:6164 | WARN |- || PDN | 9172 | PdnGen.tcl:6173 | WARN |- || PDN | 9176 | PdnGen.tcl:381 | ERROR |- || PDN | 9177 | PdnGen.tcl:4792 | WARN |- || PDN | 9178 | PdnGen.tcl:490 | ERROR |- || PDN | 9179 | PdnGen.tcl:480 | ERROR |- || PDN | 9180 | PdnGen.tcl:346 | ERROR |- || PDN | 9181 | PdnGen.tcl:330 | WARN |- || PDN | 9190 | PdnGen.tcl:421 | ERROR |- || PDN | 9191 | PdnGen.tcl:3808 | ERROR |- || PDN | 9192 | PdnGen.tcl:3813 | ERROR |- || PDN | 9193 | PdnGen.tcl:3826 | ERROR |- || PDN | 9194 | PdnGen.tcl:509 | ERROR |- || PDN | 9195 | PdnGen.tcl:521 | ERROR |- || PDN | 9196 | PdnGen.tcl:3863 | ERROR |- || PDN | 9197 | PdnGen.tcl:3854 | ERROR |- || PDN | 9248 | PdnGen.tcl:5658 | ERROR |- || PPL | 0001 | IOPlacer.cpp:1380 | INFO |- || PPL | 0002 | IOPlacer.cpp:1385 | INFO |- || PPL | 0003 | IOPlacer.cpp:1387 | INFO |- || PPL | 0004 | IOPlacer.cpp:1391 | INFO |- || PPL | 0005 | IOPlacer.cpp:1393 | INFO |- || PPL | 0006 | IOPlacer.cpp:1394 | INFO |- || PPL | 0007 | IOPlacer.cpp:2073 | INFO |- || PPL | 0008 | IOPlacer.cpp:1327 | INFO |- || PPL | 0009 | IOPlacer.cpp:1330 | INFO |- || PPL | 0010 | IOPlacer.cpp:1405 | INFO |- || PPL | 0011 | IOPlacer.cpp:949 | ERROR |- || PPL | 0012 | IOPlacer.cpp:2276 | INFO |- || PPL | 0013 | IOPlacer.cpp:1318 | ERROR |- || PPL | 0015 | IOPlacer.tcl:480 | WARN |- || PPL | 0016 | IOPlacer.tcl:167 | ERROR |- || PPL | 0017 | IOPlacer.tcl:498 | ERROR |- || PPL | 0018 | IOPlacer.tcl:504 | ERROR |- || PPL | 0019 | IOPlacer.tcl:533 | ERROR |- || PPL | 0020 | IOPlacer.cpp:1472 | ERROR |- || PPL | 0021 | IOPlacer.tcl:541 | ERROR |- || PPL | 0023 | IOPlacer.tcl:559 | ERROR |- || PPL | 0024 | IOPlacer.cpp:937 | ERROR |- || PPL | 0025 | IOPlacer.tcl:599 | ERROR |- || PPL | 0027 | IOPlacer.tcl:642 | ERROR |- || PPL | 0028 | IOPlacer.tcl:655 | ERROR |- || PPL | 0029 | IOPlacer.tcl:668 | ERROR |- || PPL | 0030 | IOPlacer.tcl:676

| ERROR | | PPL | 0031 | IOPlacer.tcl:465 | ERROR | | PPL | 0032 | IOPlacer.tcl:470 | ERROR | | PPL | 0033 | HungarianMatching.cpp:124 | WARN | | PPL | 0034 | IOPlacer.cpp:2329 | ERROR | | PPL | 0035 | IOPlacer.cpp:699 | ERROR | | PPL | 0036 | IOPlacer.cpp:1412 | WARN | | PPL | 0037 | IOPlacer.cpp:1421 | WARN | | PPL | 0038 | IOPlacer.cpp:2752 | WARN | | PPL | 0039 | IOPlacer.cpp:2140 | ERROR | | PPL | 0040 | IOPlacer.cpp:981 | ERROR | | PPL | 0041 | IOPlacer.tcl:611 | INFO | | PPL | 0042 | IOPlacer.cpp:1263 | WARN | | PPL | 0043 | IOPlacer.tcl:618 | WARN | | PPL | 0044 | IOPlacer.cpp:1992 | INFO | | PPL | 0045 | IOPlacer.tcl:545 | ERROR | | PPL | 0046 | IOPlacer.tcl:563 | ERROR | | PPL | 0047 | IOPlacer.tcl:225 | WARN | | PPL | 0048 | IOPlacer.cpp:1644 | INFO | | PPL | 0050 | IOPlacer.tcl:693 | ERROR | | PPL | 0051 | IOPlacer.tcl:698 | ERROR | | PPL | 0052 | IOPlacer.tcl:55 | ERROR | | PPL | 0053 | IOPlacer.tcl:58 | ERROR | | PPL | 0054 | IOPlacer.tcl:65 | ERROR | | PPL | 0055 | IOPlacer.tcl:89 | ERROR | | PPL | 0056 | IOPlacer.tcl:95 | ERROR | | PPL | 0057 | IOPlacer.tcl:101 | ERROR | | PPL | 0058 | IOPlacer.tcl:214 | ERROR | | PPL | 0059 | IOPlacer.tcl:198 | ERROR | | PPL | 0061 | IOPlacer.tcl:734 | ERROR | | PPL | 0062 | IOPlacer.cpp:1382 | INFO | | PPL | 0063 | IOPlacer.tcl:85 | ERROR | | PPL | 0064 | IOPlacer.tcl:386 | ERROR | | PPL | 0065 | IOPlacer.tcl:392 | ERROR | | PPL | 0066 | IOPlacer.tcl:398 | ERROR | | PPL | 0068 | IOPlacer.tcl:402 | ERROR | | PPL | 0069 | IOPlacer.tcl:415 | ERROR | | PPL | 0070 | IOPlacer.cpp:2412 | INFO | | PPL | 0071 | IOPlacer.tcl:423 | ERROR | | PPL | 0072 | IOPlacer.cpp:237 | ERROR | | PPL | 0073 | IOPlacer.tcl:206 | WARN | | PPL | 0075 | IOPlacer.cpp:1760 | WARN | | PPL | 0076 | IOPlacer.cpp:1829 | ERROR | | PPL | 0077 | IOPlacer.cpp:1480 | ERROR | | PPL | 0078 | IOPlacer.cpp:1248 | WARN | | PPL | 0079 | IOPlacer.cpp:1551 | ERROR | | PPL | 0081 | IOPlacer.tcl:240 | ERROR | | PPL | 0082 | HungarianMatching.cpp:173 | ERROR | | PPL | 0083 | IOPlacer.tcl:137 | ERROR | | PPL | 0084 | IOPlacer.cpp:1744 | WARN | | PPL | 0085 | IOPlacer.cpp:316 | ERROR | | PPL | 0086 | HungarianMatching.cpp:326 | ERROR | | PPL | 0087 | IOPlacer.tcl:141 | ERROR | | PPL | 0088 | IOPlacer.cpp:2106 | ERROR | | PPL | 0089 | HungarianMatching.cpp:266 | ERROR | | PPL | 0090 | IOPlacer.cpp:358 | ERROR | | PPL | 0091 | IOPlacer.cpp:452 | ERROR | | PPL | 0092 | IOPlacer.cpp:2082 | WARN | | PPL | 0093 | IOPlacer.cpp:384 | ERROR | | PPL | 0094 | IOPlacer.cpp:2808 | ERROR | | PPL | 0095 | IOPlacer.tcl:234 | ERROR | | PPL | 0096 | IOPlacer.cpp:229 | WARN | | PPL | 0097 | IOPlacer.cpp:530 | WARN | | PPL | 0098 | IOPlacer.cpp:1893 | ERROR | | PPL | 0100 | IOPlacer.cpp:566 | INFO | | PPL | 0101 | IOPlacer.cpp:477 | ERROR | | PPL | 0104 | IOPlacer.cpp:1922 | ERROR | | PPL | 0106 | IOPlacer.cpp:2252 | WARN | | PPL | 0107 | IOPlacer.cpp:2268 | ERROR | | PPL | 0108 | IOPlacer.tcl:365 | ERROR | | PPL | 0109 | IOPlacer.cpp:409 | ERROR | | PPL | 0110 | IOPlacer.cpp:1813 | WARN | | PPL | 0111 | IOPlacer.cpp:1845 | ERROR | | PPL | 0112 | SimulatedAnnealing.cpp:854 | ERROR | | PSM | 0001 | pdnsim.cpp:89 | INFO | | PSM | 0004 | ir\_solver.cpp:1915 | INFO | | PSM | 0008 | ir\_solver.cpp:167 | WARN | | PSM | 0010 | ir\_solver.cpp:198 | ERROR | | PSM | 0012 | ir\_solver.cpp:209 | ERROR | | PSM | 0014 | ir\_solver.cpp:390 | ERROR | | PSM | 0015 | ir\_solver.cpp:444 | INFO | | PSM | 0016 | ir\_solver.cpp:479 | WARN | | PSM | 0017 | ir\_solver.cpp:494 | WARN | | PSM | 0018 | ir\_solver.cpp:502 | WARN | | PSM | 0022 | ir\_solver.cpp:421 | INFO | | PSM | 0024 | ir\_solver.cpp:757 | WARN | | PSM | 0028 | pdnsim.tcl:205 | ERROR | | PSM | 0030 | ir\_solver.cpp:1300 | WARN | | PSM | 0031 | ir\_solver.cpp:1404 | INFO | | PSM | 0032 | ir\_solver.cpp:1177 | WARN | | PSM | 0033 | ir\_solver.cpp:1188 | WARN | | PSM | 0035 | ir\_solver.cpp:1157 | ERROR | | PSM | 0036 | ir\_solver.cpp:1210 | ERROR | | PSM | 0037 | ir\_solver.cpp:1231 | ERROR | | PSM | 0038 | ir\_solver.cpp:1478 | WARN | | PSM | 0039 | ir\_solver.cpp:1488 | WARN | | PSM | 0040 | ir\_solver.cpp:1510 | INFO | | PSM | 0041 | ir\_solver.cpp:1829 | ERROR | | PSM | 0042 | ir\_solver.cpp:738 | ERROR | | PSM | 0045 | gmat.cpp:191 | ERROR | | PSM | 0046 | gmat.cpp:204 | ERROR | | PSM | 0047 | gmat.cpp:206 | ERROR | | PSM | 0048 | gmat.cpp:289 | INFO | | PSM | 0049 | gmat.cpp:341 | ERROR | | PSM | 0050 | gmat.cpp:395 | WARN | | PSM | 0051 | gmat.cpp:570 | ERROR | | PSM | 0052 | gmat.cpp:596 | ERROR | | PSM | 0054 | pdnsim.tcl:61 | ERROR | | PSM | 0055 | pdnsim.tcl:100 | ERROR | | PSM | 0057 | pdnsim.tcl:121 | ERROR | | PSM | 0058 | pdnsim.tcl:133 | ERROR | | PSM | 0059 | pdnsim.tcl:154 | ERROR | | PSM | 0060 | pdnsim.tcl:163 | ERROR | | PSM | 0063 | ir\_solver.cpp:512 | WARN | | PSM | 0064 | ir\_solver.cpp:392 | INFO | | PSM | 0065 | ir\_solver.cpp:535 | WARN | | PSM | 0066 | ir\_solver.cpp:1254 | ERROR | | PSM | 0067 | ir\_solver.cpp:1320 | WARN | | PSM | 0068 | pdnsim.cpp:255 | ERROR | | PSM | 0069 | pdnsim.tcl:129 | ERROR | | PSM | 0070 | ir\_solver.cpp:1392 | WARN | | PSM | 0071 | ir\_solver.cpp:720 | WARN | | PSM | 0073 | ir\_solver.cpp:1350 | INFO | | PSM | 0075 | ir\_solver.cpp:469 | ERROR | | PSM | 0076 | ir\_solver.cpp:1371 | INFO | | PSM | 0078 | pdnsim.cpp:167 | ERROR | | PSM | 0079 | pdnsim.cpp:286 | ERROR | | PSM | 0080 | gmat.cpp:111 | WARN | | PSM | 0081 | ir\_solver.cpp:906 | ERROR | | PSM | 0082 | ir\_solver.cpp:1365 | ERROR | | PSM | 0084 | pdnsim.cpp:101 | ERROR | | PSM | 0085 | pdnsim.tcl:158 | ERROR | | PSM | 0086 | ir\_solver.cpp:139 | ERROR | | PSM | 0087 | ir\_solver.cpp:129 | ERROR | | PSM | 0088 | ir\_solver.cpp:126 | ERROR | | PSM | 0089 | ir\_solver.cpp:441 | ERROR | | PSM | 0090 | ir\_solver.cpp:300 | ERROR | | PSM | 0091 | ir\_solver.cpp:335 | ERROR | | PSM | 0092 | ir\_solver.cpp:1743 | ERROR | | PSM | 0093 | ir\_solver.cpp:412 | ERROR | | PSM | 0094 | ir\_solver.cpp:1503 | WARN | | RCX | 0001 | ext.cpp:323 | INFO | | RCX

| 0002 | ext.cpp:331 | ERROR | || RCX | 0003 | netRC.cpp:2263 | WARN | || RCX | 0004 | netRC.cpp:2259 | WARN  
| - || RCX | 0005 | netRC.cpp:2275 | WARN | - || RCX | 0007 | extBench.cpp:486 | INFO | - || RCX | 0008 | ext.cpp:237 |  
INFO | - || RCX | 0015 | ext.cpp:254 | INFO | - || RCX | 0016 | ext.cpp:292 | INFO | - || RCX | 0017 | ext.cpp:317 | INFO | -  
|| RCX | 0019 | ext.cpp:381 | INFO | - || RCX | 0021 | ext.cpp:434 | INFO | - || RCX | 0029 | ext.cpp:190 | INFO | - || RCX  
| 0030 | ext.cpp:201 | ERROR | - || RCX | 0031 | ext.cpp:210 | INFO | - || RCX | 0040 | netRC.cpp:1815 | INFO | - || RCX  
| 0042 | extSpec.cpp:1585 | INFO | - || RCX | 0043 | extFlow.cpp:1236 | INFO | - || RCX | 0044 | extSpecIn.cpp:2682  
| WARN | - || RCX | 0045 | netRC.cpp:1920 | INFO | - || RCX | 0047 | extSpec.cpp:1624 | INFO | - || RCX | 0048 |  
extSpecIn.cpp:2673 | WARN | - || RCX | 0049 | extSpecIn.cpp:2676 | WARN | - || RCX | 0050 | extSpecIn.cpp:2679  
| WARN | - || RCX | 0052 | extSpecIn.cpp:2686 | ERROR | - || RCX | 0055 | extBench.cpp:295 | INFO | - || RCX |  
0057 | extBench.cpp:355 | INFO | - || RCX | 0058 | extBench.cpp:417 | INFO | - || RCX | 0060 | extSpecIn.cpp:2629  
| INFO | - || RCX | 0065 | extmain.cpp:657 | INFO | - || RCX | 0069 | extRCmodel.cpp:3448 | INFO | - || RCX | 0072  
| extRCmodel.cpp:3566 | INFO | - || RCX | 0074 | extmeasure.cpp:81 | WARN | - || RCX | 0076 | extSpecIn.cpp:587  
| WARN | - || RCX | 0077 | extSpecIn.cpp:758 | WARN | - || RCX | 0078 | extSpecIn.cpp:2254 | WARN | - || RCX | 0079  
extmeasure.cpp:1858 | INFO | - || RCX | 0081 | extFlow.cpp:312 | ERROR | - || RCX | 0082 | extFlow.cpp:354 | ERROR  
| - || RCX | 0107 | netRC.cpp:1928 | WARN | - || RCX | 0110 | netRC.cpp:577 | INFO | - || RCX | 0111 | netRC.cpp:625  
| WARN | - || RCX | 0112 | netRC.cpp:723 | ERROR | - || RCX | 0113 | netRC.cpp:728 | ERROR | - || RCX | 0114 |  
netRC.cpp:736 | WARN | - || RCX | 0115 | netRC.cpp:743 | ERROR | - || RCX | 0120 | netRC.cpp:1157 | WARN | -  
|| RCX | 0121 | netRC.cpp:1303 | INFO | - || RCX | 0122 | netRC.cpp:1319 | INFO | - || RCX | 0127 | netRC.cpp:1727  
| WARN | - || RCX | 0128 | netRC.cpp:1749 | INFO | - || RCX | 0129 | netRC.cpp:1753 | WARN | - || RCX | 0134 |  
netRC.cpp:2157 | INFO | - || RCX | 0135 | netRC.cpp:2082 | WARN | - || RCX | 0136 | netRC.cpp:2106 | INFO | - ||  
RCX | 0137 | netRC.cpp:2176 | INFO | - || RCX | 0138 | extmain.cpp:335 | WARN | - || RCX | 0139 | extmain.cpp:327  
| WARN | - || RCX | 0140 | extmain.cpp:550 | INFO | - || RCX | 0141 | extmain.cpp:635 | INFO | - || RCX | 0142 |  
extmain.cpp:647 | INFO | - || RCX | 0143 | extmain.cpp:659 | INFO | - || RCX | 0147 | ext.cpp:175 | ERROR | - || RCX  
| 0148 | ext.cpp:229 | WARN | - || RCX | 0149 | OpenRCX.tcl:330 | WARN | - || RCX | 0152 | extprocess.cpp:294  
| WARN | - || RCX | 0153 | extprocess.cpp:325 | WARN | - || RCX | 0154 | extprocess.cpp:530 | WARN | - || RCX | 0158  
| extprocess.cpp:269 | WARN | - || RCX | 0159 | extprocess.cpp:547 | ERROR | - || RCX | 0171 | extSpec.cpp:193  
| ERROR | - || RCX | 0172 | extSpec.cpp:198 | ERROR | - || RCX | 0175 | extSpec.cpp:1142 | WARN | - || RCX | 0176  
| extSpec.cpp:1420 | INFO | - || RCX | 0178 | extSpecIn.cpp:2337 | INFO | - || RCX | 0208 | extRCmodel.cpp:149 | INFO  
| - || RCX | 0216 | extRCmodel.cpp:3578 | INFO | - || RCX | 0217 | extRCmodel.cpp:3584 | INFO | - || RCX | 0218 |  
extRCmodel.cpp:3633 | INFO | - || RCX | 0219 | extRCmodel.cpp:3646 | INFO | - || RCX | 0220 | extRCmodel.cpp:3669  
| INFO | - || RCX | 0221 | extRCmodel.cpp:3682 | INFO | - || RCX | 0222 | extRCmodel.cpp:3928 | WARN | - || RCX |  
0223 | extRCmodel.cpp:3952 | WARN | - || RCX | 0239 | extFlow.cpp:1386 | WARN | - || RCX | 0240 | extFlow.cpp:1397  
| WARN | - || RCX | 0252 | extmain.cpp:63 | ERROR | - || RCX | 0258 | extSpecIn.cpp:156 | WARN | - || RCX | 0259  
| extSpecIn.cpp:188 | ERROR | - || RCX | 0260 | extSpecIn.cpp:464 | ERROR | - || RCX | 0261 | extSpecIn.cpp:641  
| WARN | - || RCX | 0262 | extSpecIn.cpp:558 | ERROR | - || RCX | 0263 | extSpecIn.cpp:614 | ERROR | - || RCX | 0264  
| extSpecIn.cpp:902 | WARN | - || RCX | 0265 | extSpecIn.cpp:1095 | INFO | - || RCX | 0266 | extSpecIn.cpp:1148 |  
INFO | - || RCX | 0267 | extSpecIn.cpp:1349 | INFO | - || RCX | 0269 | extSpecIn.cpp:1504 | WARN | - || RCX | 0270  
| extSpecIn.cpp:1545 | WARN | - || RCX | 0271 | extSpecIn.cpp:1622 | WARN | - || RCX | 0272 | extSpecIn.cpp:1639  
| WARN | - || RCX | 0273 | extSpecIn.cpp:1684 | ERROR | - || RCX | 0274 | extSpecIn.cpp:1691 | WARN | - || RCX | 0275  
| extSpecIn.cpp:1699 | WARN | - || RCX | 0276 | extSpecIn.cpp:1701 | WARN | - || RCX | 0277 | extSpecIn.cpp:1745  
| WARN | - || RCX | 0278 | extSpecIn.cpp:1772 | WARN | - || RCX | 0279 | extSpecIn.cpp:1799 | WARN | - || RCX | 0280  
| extSpecIn.cpp:1857 | WARN | - || RCX | 0281 | extSpecIn.cpp:1913 | WARN | - || RCX | 0282 | extSpecIn.cpp:1998  
| WARN | - || RCX | 0283 | extSpecIn.cpp:2243 | INFO | - || RCX | 0284 | extSpecIn.cpp:2251 | WARN | - || RCX | 0285  
| extSpecIn.cpp:2585 | WARN | - || RCX | 0286 | extSpecIn.cpp:2382 | INFO | - || RCX | 0287 | extSpecIn.cpp:2402  
| INFO | - || RCX | 0288 | extSpecIn.cpp:2409 | INFO | - || RCX | 0289 | extSpecIn.cpp:2423 | INFO | - || RCX | 0290  
| extSpecIn.cpp:2433 | INFO | - || RCX | 0291 | extSpecIn.cpp:2473 | INFO | - || RCX | 0292 | extSpecIn.cpp:2582 |  
WARN | - || RCX | 0293 | extSpecIn.cpp:2700 | INFO | - || RCX | 0294 | extSpecIn.cpp:2718 | INFO | - || RCX | 0295  
| extSpecIn.cpp:2822 | WARN | - || RCX | 0296 | extSpecIn.cpp:2852 | WARN | - || RCX | 0297 | extSpecIn.cpp:2857  
| WARN | - || RCX | 0298 | extSpecIn.cpp:2859 | WARN | - || RCX | 0357 | OpenRCX.tcl:232 | ERROR | - || RCX | 0358  
| extRCmodel.cpp:3572 | INFO | - || RCX | 0374 | extSpecIn.cpp:1607 | WARN | - || RCX | 0376 | netRC.cpp:2325 |  
INFO | - || RCX | 0378 | ext.cpp:179 | ERROR | - || RCX | 0380 | ext.cpp:378 | ERROR | - || RCX | 0381 | ext.cpp:429  
| ERROR | - || RCX | 0404 | extSpecIn.cpp:2393 | INFO | - || RCX | 0405 | extSpecIn.cpp:1791 | WARN | - || RCX | 0406  
| extSpecIn.cpp:1738 | WARN | - || RCX | 0407 | extSpecIn.cpp:1780 | WARN | - || RCX | 0410 | extRCmodel.cpp:3620 |  
INFO | - || RCX | 0411 | extRCmodel.cpp:2773 | INFO | - || RCX | 0414 | extRCmodel.cpp:2767 | INFO | - || RCX | 0416

extRCmodel.cpp:2749 | INFO |- || RCX | 0417 | extRCmodel.cpp:2731 | INFO |- || RCX | 0418 | extRCmodel.cpp:2707  
 | WARN |- || RCX | 0431 | netRC.cpp:1260 | INFO |- || RCX | 0433 | netRC.cpp:1236 | INFO |- || RCX | 0434 |  
 netRC.cpp:1266 | INFO |- || RCX | 0435 | netRC.cpp:1605 | INFO |- || RCX | 0436 | netRC.cpp:1787 | INFO |- || RCX  
 | 0437 | netRC.cpp:100 | INFO |- || RCX | 0438 | netRC.cpp:89 | INFO |- || RCX | 0439 | netRC.cpp:1819 | INFO |- ||  
 RCX | 0440 | netRC.cpp:1830 | INFO |- || RCX | 0442 | extFlow.cpp:1356 | INFO |- || RCX | 0443 | extSperf.cpp:1591  
 | INFO |- || RCX | 0444 | extSperfIn.cpp:2264 | INFO |- || RCX | 0445 | extSperfIn.cpp:2555 | INFO |- || RCX | 0447  
 | extSperfIn.cpp:2661 | WARN |- || RCX | 0448 | extSperfIn.cpp:2649 | WARN |- || RCX | 0449 | extSperfIn.cpp:2707  
 | INFO |- || RCX | 0451 | extSperfIn.cpp:2710 | INFO |- || RCX | 0452 | extSperfIn.cpp:82 | WARN |- || RCX | 0456  
 | extmeasure.cpp:962 | INFO |- || RCX | 0458 | extmeasure.cpp:1031 | INFO |- || RCX | 0459 | extmeasure.cpp:641  
 | INFO |- || RCX | 0460 | extmeasure.cpp:91 | WARN |- || RCX | 0463 | extSperfIn.cpp:2619 | INFO |- || RCX | 0464 |  
 extSperfIn.cpp:2632 | INFO |- || RCX | 0465 | extSperf.cpp:1621 | INFO |- || RCX | 0468 | netRC.cpp:1610 | ERROR |- ||  
 | RCX | 0472 | netRC.cpp:1286 | INFO |- || RCX | 0474 | netRC.cpp:2044 | INFO |- || RCX | 0475 | netRC.cpp:2141 |  
 INFO |- || RCX | 0476 | extmain.cpp:649 | INFO |- || RCX | 0480 | netRC.cpp:2343 | INFO |- || RCX | 0485 | extRC-  
 model.cpp:2643 | INFO |- || RCX | 0487 | netRC.cpp:1632 | ERROR |- || RCX | 0489 | extRCmodel.cpp:3155 | ERROR  
 |- || RCX | 0490 | extRCmodel.cpp:3450 | ERROR |- || RCX | 0491 | extRCmodel.cpp:3459 | ERROR |- || RCX | 0497  
 | extmain.cpp:370 | ERROR |- || RMP | 0001 | blif.cpp:105 | ERROR |- || RMP | 0002 | blif.cpp:360 | INFO |- || RMP |  
 0003 | blif.cpp:384 | ERROR |- || RMP | 0004 | blif.cpp:407 | ERROR |- || RMP | 0005 | blif.cpp:429 | INFO |- || RMP |  
 0006 | blif.cpp:433 | INFO |- || RMP | 0007 | blif.cpp:458 | INFO |- || RMP | 0008 | blif.cpp:477 | INFO |- || RMP | 0009  
 | blif.cpp:521 | INFO |- || RMP | 0010 | blif.cpp:574 | INFO |- || RMP | 0012 | rmp.tcl:96 | ERROR |- || RMP | 0016 |  
 Restructure.cpp:620 | ERROR |- || RMP | 0020 | Restructure.cpp:485 | ERROR |- || RMP | 0021 | Restructure.cpp:292 |  
 INFO |- || RMP | 0025 | Restructure.cpp:642 | WARN |- || RMP | 0026 | Restructure.cpp:225 | ERROR |- || RMP | 0032  
 | rmp.tcl:112 | WARN |- || RMP | 0033 | rmp.tcl:128 | WARN |- || RMP | 0034 | blif.cpp:421 | ERROR |- || RMP | 0035  
 | Restructure.cpp:453 | WARN |- || RMP | 0036 | Restructure.cpp:594 | WARN |- || RMP | 0037 | Restructure.cpp:299 |  
 ERROR |- || RMP | 0076 | blif.cpp:541 | ERROR |- || RMP | 0146 | blif.cpp:595 | INFO |- || RSZ | 0001 | Resizer.tcl:145  
 | ERROR |- || RSZ | 0002 | Resizer.tcl:150 | ERROR |- || RSZ | 0003 | Resizer.tcl:231 | ERROR |- || RSZ | 0004 |  
 Resizer.tcl:591 | ERROR |- || RSZ | 0005 | Resizer.tcl:228 | ERROR |- || RSZ | 0010 | Resizer.tcl:192 | WARN |- || RSZ  
| 0011 | Resizer.tcl:195 | WARN |- || RSZ | 0020 | Resizer.tcl:507 | WARN |- || RSZ | 0021 | Resizer.tcl:558 | WARN |- ||  
RSZ | 0022 | Resizer.cc:471 | ERROR |- || RSZ | 0023 | Resizer.cc:2915 | ERROR |- || RSZ | 0025 | RepairSetup.cc:294 |  
ERROR |- || RSZ | 0026 | Resizer.cc:278 | INFO |- || RSZ | 0027 | Resizer.cc:522 | INFO |- || RSZ | 0028 | Resizer.cc:652  
| INFO |- || RSZ | 0030 | RepairSetup.cc:318 | INFO |- || RSZ | 0031 | RepairSetup.cc:321 | INFO |- || RSZ | 0032 |  
RepairHold.cc:307 | INFO |- || RSZ | 0033 | RepairHold.cc:318 | INFO |- || RSZ | 0034 | RepairDesign.cc:125 | INFO  
|- || RSZ | 0035 | RepairDesign.cc:128 | INFO |- || RSZ | 0036 | RepairDesign.cc:131 | INFO |- || RSZ | 0037 | RepairD-  
esign.cc:134 | INFO |- || RSZ | 0038 | RepairDesign.cc:137 | INFO |- || RSZ | 0039 | RepairDesign.cc:142 | INFO |- ||  
RSZ | 0040 | RepairSetup.cc:273 | INFO |- || RSZ | 0041 | RepairSetup.cc:281 | INFO |- || RSZ | 0042 | Resizer.cc:1870  
| INFO |- || RSZ | 0043 | RepairSetup.cc:284 | INFO |- || RSZ | 0044 | RepairSetup.cc:324 | INFO |- || RSZ | 0045  
| RepairSetup.cc:276 | INFO |- || RSZ | 0046 | RepairHold.cc:265 | INFO |- || RSZ | 0047 | RepairDesign.cc:271 |  
INFO |- || RSZ | 0048 | RepairDesign.cc:274 | INFO |- || RSZ | 0049 | RepairSetup.cc:287 | INFO |- || RSZ | 0050 |  
RepairHold.cc:314 | ERROR |- || RSZ | 0051 | RepairDesign.cc:321 | INFO |- || RSZ | 0052 | RepairDesign.cc:324 |  
INFO |- || RSZ | 0053 | RepairDesign.cc:327 | INFO |- || RSZ | 0054 | RepairDesign.cc:330 | INFO |- || RSZ | 0055  
| RepairDesign.cc:333 | INFO |- || RSZ | 0056 | RepairDesign.cc:339 | INFO |- || RSZ | 0057 | RepairDesign.cc:342  
| INFO |- || RSZ | 0058 | Resizer.tcl:632 | INFO |- || RSZ | 0060 | RepairHold.cc:311 | ERROR |- || RSZ | 0062 |  
RepairSetup.cc:291 | WARN |- || RSZ | 0064 | RepairHold.cc:303 | WARN |- || RSZ | 0065 | Resizer.tcl:627 | WARN |- ||  
RSZ | 0066 | RepairHold.cc:301 | WARN |- || RSZ | 0067 | Resizer.tcl:569 | WARN |- || RSZ | 0068 | Resizer.cc:1602  
| ERROR |- || RSZ | 0069 | SteinerTree.cc:91 | WARN |- || RSZ | 0070 | Resizer.cc:2370 | ERROR |- || RSZ | 0071 |  
Rebuffer.cc:297 | CRITICAL |- || RSZ | 0072 | RepairDesign.cc:745 | CRITICAL |- || RSZ | 0073 | BufferedNet.cc:670  
| WARN |- || RSZ | 0074 | BufferedNet.cc:674 | WARN |- || RSZ | 0075 | Rebuffer.cc:132 | WARN |- || RSZ | 0076 |  
Resizer.tcl:420 | WARN |- || RSZ | 0077 | Resizer.cc:3128 | WARN |- || RSZ | 0078 | BufferedNet.cc:83 | CRITICAL  
|- || RSZ | 0079 | BufferedNet.cc:118 | CRITICAL |- || RSZ | 0080 | BufferedNet.cc:146 | CRITICAL |- || RSZ | 0081  
| BufferedNet.cc:176 | CRITICAL |- || RSZ | 0082 | BufferedNet.cc:346 | CRITICAL |- || RSZ | 0083 | RepairDe-  
sign.cc:1146 | CRITICAL |- || RSZ | 0084 | Resizer.cc:670 | WARN |- || RSZ | 0085 | Resizer.cc:573 | WARN |- || RSZ |  
0086 | Resizer.cc:1477 | ERROR |- || RSZ | 0088 | Resizer.cc:2327 | WARN |- || RSZ | 0089 | Resizer.cc:2342 | ERROR  
|- || RSZ | 0090 | PreChecks.cc:81 | ERROR |- || RSZ | 0091 | RepairSetup.cc:924 | ERROR |- || RSZ | 0092 | Stein-  
erTree.cc:394 | ERROR |- || RSZ | 0093 | SteinerTree.cc:323 | ERROR |- || RSZ | 0094 | RepairSetup.cc:142 | INFO |- ||  
RSZ | 0095 | Resizer.tcl:515 | WARN |- || RSZ | 0096 | Resizer.cc:973 | WARN |- || RSZ | 0125 | RecoverPower.cc:201

```
| ERROR | || RSZ | 0141 | RecoverPower.cc:198 | INFO | || RSZ | 0142 | RecoverPower.cc:176 | INFO | || RSZ | 3111  
| RecoverPower.cc:222 | INFO | || STA | 1000 | dbSta.cc:712 | ERROR | || STT | 0001 | SteinerTreeBuilder.tcl:52 |  
ERROR | || STT | 0004 | SteinerTreeBuilder.cpp:248 | ERROR | || STT | 0005 | SteinerTreeBuilder.cpp:267 | ERROR  
| || STT | 0006 | SteinerTreeBuilder.tcl:91 | ERROR | || STT | 0007 | SteinerTreeBuilder.cpp:304 | ERROR | || TAP  
| 0003 | tapcell.cpp:541 | INFO | || TAP | 0004 | tapcell.cpp:544 | INFO | || TAP | 0005 | tapcell.cpp:168 | INFO | ||  
TAP | 0010 | tapcell.tcl:170 | ERROR | || TAP | 0011 | tapcell.tcl:180 | ERROR | || TAP | 0014 | tapcell.tcl:74 | WARN  
| || TAP | 0015 | tapcell.tcl:143 | WARN | || TAP | 0016 | tapcell.tcl:147 | WARN | || TAP | 0020 | tapcell.cpp:1218  
| ERROR | || TAP | 0032 | tapcell.cpp:344 | WARN | || TAP | 0033 | tapcell.cpp:379 | ERROR | || TAP | 0034 |  
tapcell.tcl:218 | ERROR | || TAP | 0035 | tapcell.i:62 | ERROR | || TAP | 0100 | tapcell.tcl:251 | INFO | || TAP | 0101  
| tapcell.tcl:253 | INFO | || TAP | 0102 | tapcell.tcl:386 | ERROR | || TAP | 0103 | tapcell.tcl:413 | ERROR | || TAP |  
0104 | tapcell.cpp:1419 | ERROR | || UPF | 0001 | upf.cpp:51 | WARN | || UPF | 0002 | upf.cpp:67 | WARN | || UPF |  
0003 | upf.cpp:84 | WARN | || UPF | 0004 | upf.cpp:97 | WARN | || UPF | 0005 | upf.cpp:108 | WARN | || UPF |  
0006 | upf.cpp:125 | WARN | || UPF | 0007 | upf.cpp:169 | WARN | || UPF | 0008 | upf.cpp:189 | WARN | || UPF |  
0009 | upf.cpp:209 | WARN | || UPF | 0010 | upf.cpp:228 | WARN | || UPF | 0011 | upf.cpp:247 | WARN | || UPF |  
0012 | upf.cpp:271 | WARN | || UPF | 0013 | upf.cpp:282 | WARN | || UPF | 0014 | upf.cpp:327 | WARN | || UPF |  
0015 | upf.cpp:338 | WARN | || UPF | 0016 | upf.cpp:358 | WARN | || UPF | 0017 | upf.cpp:428 | WARN | || UPF |  
0018 | upf.cpp:447 | WARN | || UPF | 0019 | upf.cpp:472 | ERROR | || UPF | 0020 | upf.cpp:491 | WARN | || UPF |  
0021 | upf.cpp:501 | WARN | || UPF | 0022 | upf.cpp:509 | WARN | || UPF | 0023 | upf.cpp:528 | WARN | || UPF |  
0024 | upf.cpp:632 | WARN | || UPF | 0025 | upf.cpp:656 | WARN | || UPF | 0026 | upf.cpp:692 | WARN | || UPF |  
0027 | upf.cpp:814 | WARN | || UPF | 0028 | upf.cpp:864 | WARN | || UPF | 0029 | upf.cpp:1261 | ERROR | || UPF |  
0030 | upf.cpp:964 | WARN | || UPF | 0031 | upf.cpp:992 | WARN | || UPF | 0032 | upf.cpp:1377 | WARN | || UPF |  
0033 | upf.tcl:633 | ERROR | || UPF | 0034 | upf.tcl:639 | ERROR | || UPF | 0035 | upf.cpp:1187 | WARN | || UPF |  
0036 | upf.tcl:303 | ERROR | || UPF | 0037 | upf.tcl:311 | ERROR | || UPF | 0038 | upf.cpp:1385 | WARN | || UPF |  
0039 | upf.cpp:1471 | WARN | || UPF | 0040 | upf.tcl:367 | ERROR | || UPF | 0041 | upf.cpp:1492 | WARN | || UPF |  
0042 | upf.cpp:1513 | WARN | || UPF | 0043 | upf.i:146 | ERROR | || UPF | 0044 | upf.cpp:1394 | WARN | || UPF |  
0053 | upf.cpp:1081 | WARN | || UPF | 0054 | upf.cpp:1143 | WARN | || UPF | 0055 | upf.cpp:1163 | WARN | ||  
UPF | 0056 | upf.cpp:1222 | WARN | || UPF | 0057 | upf.tcl:506 | WARN | || UPF | 0059 | upf.cpp:1533 | WARN | ||  
UPF | 0060 | upf.cpp:1556 | WARN | || UPF | 0061 | upf.cpp:147 | WARN | || UPF | 0071 | upf.cpp:807 | WARN | ||  
UPF | 0072 | writer.cpp:46 | ERROR | || UTL | 0001 | CFileUtils.cpp:8 | ERROR | || UTL | 0002 | CFileUtils.cpp:25  
| ERROR | || UTL | 0003 | CFileUtils.cpp:35 | ERROR | || UTL | 0004 | CFileUtils.cpp:56 | ERROR | || UTL |  
0005 | ScopedTemporaryFile.cpp:12 | ERROR | || UTL | 0006 | ScopedTemporaryFile.cpp:15 | INFO | || UTL | 0007  
| ScopedTemporaryFile.cpp:19 | ERROR | || UTL | 0008 | ScopedTemporaryFile.cpp:27 | WARN | || UTL | 0009 |  
ScopedTemporaryFile.cpp:31 | WARN | ||
```

## 5.3 Getting Involved

Thank you for taking the time to read this document and to contribute. The OpenROAD project will not reach all of its objectives without help!

Possible ways to contribute to the OpenROAD application:

- Tool improvements
- New tools
- Improvements to documentation, including this document
- Star our project and repos so we can see the number of people who are interested

### 5.3.1 Licensing Contributions

As much as possible, all contributions should be licensed using the BSD3 license. You can propose another license if you must, but contributions made with BSD3 fit best with the spirit of OpenROAD's permissive open-source philosophy. We do have exceptions in the project, but over time we hope that all contributions will be BSD3, or some other permissive license such as MIT or Apache2.0.

### 5.3.2 Contributing Scripts and Code

We follow the [Google C++ style guide](#). If you find code in our project that does *not* follow this guide, then within each file that you edit, follow the style in that file.

Please pay careful attention to the [tool checklist](#) for all code. If you want to add or improve functionality in OpenROAD, please start with the top-level [app](#) repo. You can see in the [src](#) directory that submodules exist pointing to tested versions of the other relevant repos in the project. Please look at the tool workflow in the developer guide [document](#) to work with the app and its submodule repos in an efficient way.

Please run clang-format on all the C++ source files that you change, before committing. In the root directory of the OpenROAD repository there is the file [.clang-format](#) that defines all coding formatting rules.

Please pay attention to the [test directory](#) and be sure to add tests for any code changes that you make, using open-source PDK and design information. We provide the nangate45 PDK in the OpenROAD-flow-scripts repo to help with this. Pull requests with code changes are unlikely to be accepted without accompanying test cases. There are many [examples](#) tests. Each repo has a test directory as well with tests you should run and add to if you modify something in one of the submodules.

For changes that claim to improve QoR or PPA, please run many tests and ensure that the improvement is not design-specific. There are designs in the [OpenROAD-flow-scripts](#) repo which can be used unless the improvement is technology-specific.

Do not add runtime or build dependencies without serious thought. For a project like OpenROAD with many application subcomponents, the software architecture can quickly get out of control. Changes with lots of new dependencies which are not necessary are less likely to be integrated.

If you want to add Tcl code to define a new tool command, look at [pdngen](#) as an example of how to do so. Take a look at the [CMake file](#) which automatically sources the [Tcl file](#) itself.

To accept contributions, we require each commit to be made with a DCO (Developer Certificate of Origin) attached. When you commit you add the `-s` flag to your commit. For example:

```
git commit -s -m "test dco with -s"
```

This will append a statement to your commit comment that attests to the DCO. GitHub has built in the `-s` option to its command line since use of this is so pervasive. The promise is very basic, certifying that you know that you have the right to commit the code. Please read the [full statement here](#).

### 5.3.3 Questions

Please refer to our [FAQs](#).

### 5.3.4 Developer Guide

#### Tool Philosophy

OpenROAD is a tool to build a chip from synthesizable RTL (Verilog) to completed physical layout (manufacturable, tapeout-clean GDSII).

The unifying principle behind the design of OpenROAD is for all of the tools to reside in one tool, with one process, and one database. All tools in the flow should use Tcl commands exclusively to control them instead of external “configuration files”. File-based communication between tools and forking processes is strongly discouraged. This architecture streamlines the construction of a flexible tool flow and minimizes the overhead of invoking each tool in the flow.

#### Tool File Organization

Every tool follows the following file structure, grouping sources, tests and headers together.

- `src/` This folder contains the source files for individual tools.

src	Purpose
<code>CMakeLists.txt</code>	add_subdirectory for each tool
<code>tool/src</code>	sources and private headers
<code>tool/src/CMakeLists.txt</code>	tool specific CMake file
<code>tool/include/tool</code>	exported headers
<code>tool/test</code>	tool tests
<code>tool/regression</code>	tool unit tests

- OpenROAD repository: This folder contains the top-level files for overall compilation. OpenROAD uses `swig` that acts as a wrapper for C/C++ programs to be callable in higher-level languages, such as Python and Tcl.

OpenROAD	Purpose
<code>CMakeLists.txt</code>	top-level CMake file
<code>src/Main.cc</code>	main file
<code>src/OpenROAD.cc</code>	OpenROAD class functions
<code>src/OpenROAD.i</code>	top-level swig, includes, tool swig files
<code>src/OpenROAD.tcl</code>	basic read/write lef/def/db commands
<code>include/ord/OpenROAD.hh</code>	OpenROAD top-level class, has instances of tools

Some tools such as OpenSTA are submodules, which are simply subdirectories in `src/` that are pointers to the git submodule. They are intentionally not segregated into a separate module.

The use of submodules for new code integrated into OpenROAD is strongly discouraged. Submodules make changes to the underlying infrastructure (e.g., OpenSTA) difficult to propagate across the dependent submodule repositories.

Where external/third-party code that a tool depends on should be placed depends on the nature of the dependency.

- Libraries - code packaged as a linkable library. Examples are `tcl`, `boost`, `zlib`, `eigen`, `lemon`, `spdlog`.

These should be installed in the build environment and linked by OpenROAD. Document these dependencies in the top-level `README.md` file. The `Dockerfile` should be updated to illustrate where to find the library and how to install it. Adding libraries to the build environment requires coordination with system administrators, so that continuous integration hosts ensure that environments include the dependency. Advance notification should also be given to the development team so that their private build environments can be updated.

Each tool CMake file builds a library that is linked by the OpenROAD application. The tools should not define a `main()` function. If the tool is Tcl only and has no C++ code, it does not need to have a CMake file. Tool CMake files should **not** include the following:

- `cmake_minimum_required`
- `GCC_COVERAGE_COMPILE_FLAGS`
- `GCC_COVERAGE_LINK_FLAGS`
- `CMAKE_CXX_FLAGS`
- `CMAKE_EXE_LINKER_FLAGS`

None of the tools have commands to read or write LEF, DEF, Verilog or database files. For consistency, these functions are all provided by the OpenROAD framework.

Tools should package all of their state in a single class. An instance of each tool class resides in the top-level OpenROAD object. This allows multiple tools to exist at the same time. If any tool keeps state in global variables (even static), then only one tool can exist at a time. Many of the tools being integrated were not built with this goal in mind and will only work on one design at a time.

Each tool should use a unique namespace for all of its code. The same namespace should be used for Tcl functions, including those defined by a swig interface file. Internal Tcl commands stay inside the namespace, and user visible Tcl commands should be defined in the global namespace. User commands should be simple Tcl commands such as `global_placement` that do not create tool instances that must be based to the commands. Defining Tcl commands for a tool class is fine for internal commands, but not for user visible commands. Commands have an implicit argument of the current OpenROAD class object. Functions to get individual tools from the OpenROAD object can be defined.

### Initialization (C++ tools only)

The OpenROAD class has pointers to each tool, with functions to get each tool. Each tool has (at a minimum) a function to make an instance of the tool class, an initialization function that is called after all of the tools have been made, and a function to delete the tool. This small header does **not** include the class definition for the tool so that the OpenROAD framework does not have to know anything about the tool internals or include a gigantic header file.

`MakeTool.hh` defines the following:

```
Tool *makeTool();
void initTool(OpenRoad *openroad);
void deleteTool(Tool *tool);
```

The `OpenRoad::init()` function calls all of the `makeTool` functions and then all of the `initTool()` functions. The `init` functions are called from the bottom of the tool dependencies. Each `init` function grabs the state it needs out of the `OpenRoad` instance.

### Commands

Tools should provide Tcl commands to control them. Tcl object based tool interfaces are not user-friendly. Define Tcl procedures that take keyword arguments that reference the `OpenRoad` object to get tool state. OpenSTA has Tcl utilities to parse keyword arguments (`sta::parse_keyword_args`). See `OpenSTA/tcl/*.tcl` for examples. Use swig to define internal functions to C++ functionality.

Tcl files can be included by encoding them in CMake into a string that is evaluated at run time (See `Resizer::init()`).

### Errors

Tools should report errors to the user using the `ord::error` function defined in `include/openroad/Error.hh`. `ord::error` throws `ord::Exception`. The variables `ord::exit_on_error` and `ord::file_continue_on_error` control how the error is handled. If `ord::exit_on_error` is true then OpenROAD reports the error and exits. If the error is encountered while reading a file with the `source` or `read_sdc` commands and `ord::file_continue_on_error` is false then no other commands are read from the file. The default value is `false` for both variables.

### Test

Each “tool” has a `/test` directory containing a script named `regression` to run “unit” tests. With no arguments it should run default unit tests.

No database files should be in tests. Read LEF/DEF/Verilog to make a database.

The regression script should not depend on the current working directory. It should be able to be run from any directory. Use filenames relative to the script name rather the current working directory.

Regression scripts should print a concise summary of test failures. The regression script should return an exit code of 0 if there are no errors and 1 if there are errors. The script should **not** print thousands of lines of internal tool information.

Regression scripts should pass the `-no_init` option to `openroad` so that a user’s `init` file is not sourced before the tests runs.

Regression scripts should add output files or directories to `.gitignore` so that running does not leave the source repository “dirty”.

The Nangate45 open-source library data used by many tests is in `test/Nangate45`. Use the following command to add a link in the tool command:

```
cd src/<tool>/test  
ln -s ../../test/Nangate45
```

After the link is installed, the test script can read the Liberty file with the command shown below.

```
read_liberty Nangate45/Nangate45_typ.lib
```

### Building

Instructions for building are available [here](#).

### Example of Adding a Tool to OpenROAD

The patch file “`AddTool.patch`” illustrates how to add a tool to OpenROAD. Use the following commands to add a sample tool:

```
# first, update existing config files  
patch -p1 < docs/misc/AddTool.patch  
  
# next, create the additional source files of the tool using this command  
patch -p1 < docs/misc/AddToolFiles.patch  
  
# finally, create the regression tests as follows
```

(continues on next page)

(continued from previous page)

```
cd src/tool/test
ln -s ../../test/regression.tcl regression.tcl
```

This adds a directory OpenRoad/src/tool that illustrates a tool named “Tool” that uses the file structure described above and defines a command to run the tool with keyword and flag arguments as illustrated below:

```
> toolize foo
Helping 23/6
Gotta positional_argument1 foo
Gotta param1 0.000000
Gotta flag1 false

> toolize -flag1 -key1 2.0 bar
Helping 23/6
Gotta positional_argument2 bar
Gotta param1 2.000000
Gotta flag1 true

> help toolize
toolize [-key1 key1] [-flag1] positional_argument1
```

## Documentation

Tool commands should be documented in the top-level OpenROAD README.md file. Detailed documentation should be the tool/README.md file.

## Tool Flow Namespace

Tool namespaces are usually three-lettered lowercase letters.

- Verilog to DB (dbSTA)
- OpenDB: Open Database (*odb*)
- TritonPart: constraints-driven partitioner (*par*)
- Floorplan Initialization (*ifp*)
- ICeWall chip-level connections (*pad*)
- I/O Placement (*ppl*)
- PDN Generation (*pdn*)
- Tapcell and Welltie Insertion (*tap*)
- Triton Macro Placer (*mpl*)
- Hierarchical Automatic Macro Placer (*mpl2*)
- RePlAce Global Placer (*gpl*)
- Gate resizing and buffering (*rsz*)
- Detailed placement (*dpl*)
- Clock tree synthesis (*cts*)

- FastRoute Global routing (*grt*)
- Antenna check and diode insertion (*ant*)
- TritonRoute Detailed routing (*drt*)
- Metal fill insertion (*fin*)
- Design for Test (dft)
- OpenRCX Parasitic Extraction (*rce*)
- OpenSTA timing/power analyzer (*sta*)
- Graphical User Interface (*gui*)
- Static IR analyzer (*psm*)

### Tool Checklist

Tools should make every attempt to minimize external dependencies. Linking libraries other than those currently in use complicates the builds and sacrifices the portability of OpenROAD. OpenROAD should be portable to many different compiler/operating system versions and dependencies make this vastly more complicated.

1. OpenROAD submodules reference tool `openroad` branch head. No git develop, `openroad_app`, or `openroad_build` branches.
2. Submodules used by more than one tool belong in `src/`, not duplicated in each tool repo.
3. `CMakeLists.txt` does not use `add_compile_options` `include_directories` `link_directories` `link_libraries`. Use `target_` versions instead. See tips [here](#).
4. `CMakeLists.txt` does not use `glob`. Use explicit lists of source files and headers instead.
5. `CMakeLists.txt` does not define `CFLAGS` `CMAKE_CXX_FLAGS` `CMAKE_CXX_FLAGS_DEBUG` `CMAKE_CXX_FLAGS_RELEASE`. Let the top level and defaults control these.
6. No `main.cpp` or main procedure.
7. No compiler warnings for GCC or Clang with optimization enabled.
8. Does not call `flute::readLUT` (called once by `openroad`).
9. Tcl command(s) documented in top level `README.md` in flow order.
10. Command line tool documentation in tool `README`.
11. Conforms to Tcl command naming standards (no camel case).
12. Does not read configuration files. Use command arguments or support commands.
13. `.clang-format` at tool root directory to aid foreign programmers.
14. No `jenkins/`, `Jenkinsfile`, `Dockerfile` in tool directory.
15. `regression` script named `test/regression` with no arguments that runs tests. Not `tests/regression-tcl.sh`, not `test/run_tests.py` etc.
16. `regression` script should run independent of current directory. For example, `../test/regression` should work.
17. `regression` should only print test results or summary, not belch 1000s of lines of output.
18. Test scripts use OpenROAD tcl commands (not `itcl`, not internal accessors).
19. `regression` script should only write files in a directory that is in the tool's `.gitignore` so the hierarchy does not have modified files in it as a result of running the regressions.

20. Regressions report no memory errors with `valgrind` (stretch goal).
21. Regressions report no memory leaks with `valgrind` (difficult).

## Code Linting and Formatting

OpenROAD uses both `clang-tidy` and `clang-format` to perform automatic linting and formatting whenever a pull request is submitted. To run these locally, please first setup Clang Tooling using this [guide](#). Thereafter, you may run these commands:

```
cmake . -B build # generate build files
# typically only run these commands on files you changed.
clang-tidy -p ./build source_file.cpp
clang-format -i -style=file:./clang-format source_file.cpp
```

## Guidelines

1. Internally, the code should use `int` for all database units and `int64_t` for all area calculations. Refer to this link for a more detailed writeup on the reasons why this approach is preferred. The only place that the database distance units should appear in any program should be in the user interface, as microns are easier for humans than DBUs.

### 5.3.5 Coding Practices

List of coding practices.

---

**Note:** This is a compilation of many idioms in OpenROAD code that are considered undesirable.

---

#### C++

##### Practice #1

Don't comment out code, instead remove it. `git` provides a complete history of the code if you want to look backwards. Huge chunks of commented-out code make it difficult to read.

##### Practice #2

Don't use prefixes on function names or variables. That's what namespaces are for.

```
namespace fr {
    class frConstraint
    class frLeaf58CutClassConstraint
    class frShortConstraint
    class frNonSufficientMetalConstraint
    class frOffGridConstraint
    class frMinEnclosedAreaConstraint
    class frMinStepConstraint
    class frMinimumcutConstraint
```

(continues on next page)

(continued from previous page)

```
class frAreaConstraint  
class frMinWidthConstraint  
class frLef58SpacingEndOfLineWithinEndToEndConstraint  
class frLef58SpacingEndOfLineWithinParallelEdgeConstraint  
class frLef58SpacingEndOfLineWithinMaxMinLengthConstraint  
class frLef58SpacingEndOfLineWithinConstraint  
class frLef58SpacingEndOfLineConstraint  
}
```

### Practice #3

Namespaces should be all lower case and short. This is an example of a poor choice: namespace TritonCTS

### Practice #4

Don't use `extern` on function definitions. It is pointless in a world with prototypes.

```
namespace fr {  
    extern frCoord getGCELLGRIDX();  
    extern frCoord  
    getGCELLGRIDY();  
    extern frCoord getGCELLOFFSETX();  
    extern frCoord  
    getGCELLOFFSETY();  
}
```

### Practice #5

Don't use prefixes on file names. That's what directories are for.

```
frDRC.h frDRC_init.cpp frDRC_main.cpp frDRC_setup.cpp frDRC_util.cpp
```

### Practice #6

Don't name variables `theThingy`, `curThingy` or `myThingy`. It is just distracting extraneous verbiage. Just use `thingy`.

```
float currXSize;  
float currYSize;  
float currArea;  
float currWS;  
float currWL;  
float currWLnoWts;
```

**Practice #7**

Do not use global variables. All state should be inside of classes. Global variables make multi-threading next to impossible and preclude having multiple copies of a tool running in the same process. The only global variable in openroad should be the singleton that Tcl commands reference.

```
extern std::string DEF_FILE;
extern std::string GUIDE_FILE;
extern std::string OUTGUIDE_FILE;
extern std::string LEF_FILE;
extern std::string OUTTA_FILE;
extern std::string OUT_FILE;
extern std::string DBPROCESSNODE;
extern std::string OUT_MAZE_FILE;
extern std::string DRC_RPT_FILE;
extern int MAX_THREADS ;
extern int VERBOSE ;
extern int BOTTOM_ROUTING_LAYER;
extern bool ALLOW_PIN_AS_FEEDTHROUGH;
extern bool USENONPREFTRACKS;
extern bool USEMINSPACING_OBS;
extern bool RESERVE_VIA_ACCESS;
extern bool ENABLE_BOUNDARY_MAR_FIX;
```

**Practice #8**

Do not use strings (names) to refer to database or sta objects except in user interface code. DEF, SDC, and Verilog all use different names for netlist instances and nets, so the names will not always match.

**Practice #9**

Do not use continue. Wrap the body in an if instead.

```
// instead of
for(dbInst* inst : block->getInsts() ) {
    // Skip for standard cells
    if (inst->getBBox()->getDY() <= cellHeight) { continue; }
    // code
}
// use
for(dbInst* inst : block->getInsts() ){
    // Skip for standard cells
    if (inst->getBBox()->getDY() > cellHeight) {
        // code
    }
}
```

**Practice #10**

Don't put magic numbers in the code. Use a variable with a name that captures the intent. Document the units if they exist.

```
referenceHpwL_ = 446000000;
coeffV = 1.36;
coeffV = 1.2;
double nearest_dist = 9999999999;
if (dist < rowHeight * 2) {}
for(int i = 9; i > -1; i--) {}
if(design_util > 0.6 || num_fixed_nodes > 0) div = 1;
avail_region_area += (theRect->xUR - theRect->xLL - (int)theRect->xUR % 200 + (int)t ↵
heRect->xLL % 200 - 200) * (theRect->yUR - theRect->yLL - (int)theRect->yUR % 2000 + ↵
(int)theRect->yLL % 2000 - 2000);
```

**Practice #11**

Don't copy code fragments. Write functions.

```
// 10x
int x_pos = (int)floor(theCell->x_coord / wsite + 0.5);
// 15x
int y_pos = (int)floor(y_coord / rowHeight + 0.5);

// This
nets[newnetID]->netIDorg = netID;
nets[newnetID]->numPins = numPins;
nets[newnetID]->deg = pinInd;
nets[newnetID]->pinX = (short *)malloc(pinInd* sizeof(short));
nets[newnetID]->pinY = (short *)malloc(pinInd* sizeof(short));
nets[newnetID]->pinL = (short *)malloc(pinInd* sizeof(short));
nets[newnetID]->alpha = alpha;

// Should factor out the array lookup.
Net *net = nets[newnetID];
net->netIDorg = netID;
net->numPins = numPins;
net->deg = pinInd;
net->pinX = (short *)malloc(pinInd* sizeof(short));
net->pinY = (short *)malloc(pinInd* sizeof(short));
net->pinL = (short *)malloc(pinInd* sizeof(short));
net->alpha = alpha;

// Same here:
if (grid[j][k].group != UINT_MAX) {
    if (grid[j][k].isValid) {
        if (groups[grid[j][k].group].name == theGroup->name)
            area += wsite * rowHeight;
    }
}
```

**Practice #12**

Don't use logical operators to test for null pointers.

```
if (!net) {
    // code
}

// should be
if (net != nullptr) {
    // code
}
```

**Practice #13**

Don't use `malloc`. Use `new`. We are writing C++, not C.

**Practice #14**

Don't use C style arrays. There is no bounds checks for them so they invite subtle memory errors to unwitting programmers who fail to use valgrind. Use `std::vector` or `std::array`.

**Practice #15**

Break long functions into smaller ones, preferably that fit on one screen.

**Practice #16**

Don't reinvent functions like `round`, `floor`, `abs`, `min`, `max`. Use the std versions.

```
int size_x = (int)floor(theCell->width / wsite + 0.5);
```

**Practice #17**

Don't use C's `stdlib.h abs`, `fabs` or `fabsf`. They fail miserably if the wrong arg type is passed to them. Use `std::abs`.

**Practice #18**

Fold code common to multiple loops into the same loop. Each of these functions loops over every instance like this:

```
legal &= row_check(log);
legal &= site_check(log);
for(int i = 0; i < cells.size(); i++) {
    cell* theCell = &cells[i];
    legal &= power_line_check(log);
    legal &= edge_check(log);
```

(continues on next page)

(continued from previous page)

```
legal &= placed_check(log);
legal &= overlap_check(log);
}
// with this loop
for(int i = 0; i < cells.size(); i++) {
    cell* theCell = &cells[i];
}
```

Instead make one pass over the instances doing each check.

### Practice #19

Don't use == true, or == false. Boolean expressions already have a value of true or false.

```
if(found.first == true) {
    // code
}
// is simply
if(found.first) {
    // code
}
// and
if(found.first == false) {
    // code
}
// is simply
if(!found.first) {
    // code
}
```

### Practice #20

Don't nest if statements. Use && on the clauses instead.

```
if(grid[j][k].group != UINT_MAX)
    if(grid[j][k].isValid == true)
        if(groups[grid[j][k].group].name == theGroup->name)
```

is simply

```
if(grid[j][k].group != UINT_MAX
    && grid[j][k].isValid
    && groups[grid[j][k].group].name == theGroup->name)
```

### Practice #21

Don't call return at the end of a function that does not return a value.

### Practice #22

Don't use <> to include anything but system headers. Your project's headers should never be in <>.

1. GCC Include Syntax
2. StackOverflow discussion on “filename” vs <filename>

These are all wrong:

```
#include <odb/db.h>
#include <sta/liberty/Liberty.hh>
#include <odb/db.h>
#include <odb/dbTypes.h>
#include <odb/defin.h>
#include <odb/defout.h>
#include <odb/lefin.h>
```

### Practice #23

Don't make “include the kitchen sink” headers and include them in every source file. This is convenient but slows the builds down for everyone. Make each source file include just the headers it actually needs.

```
// Types.hpp
#include <sta/liberty/Liberty.hh>
#include <odb/db.h>
#include <odb/dbTypes.h>
// It should be obvious that every source file is not reading def.
#include <odb/defin.h>
// or writing it.
#include <odb/defout.h>
#include <odb/lefin.h>
#include "db_stा/dbNetwork.hh"
#include "db_stा/dbStа.hh"
```

Note this example also incorrectly uses <>'s around OpenROAD headers.

Header files should only include files to support the header. Include files necessary for code in the code file, not the header.

In the example below NONE of the system files listed are necessary for the header file.

```
#include <stdio.h>
#include <stdlib.h>
#include <math.h>
#include <limits.h>

unsigned num_nets = 1000;
unsigned num_terminals = 64;
```

(continues on next page)

(continued from previous page)

```
unsigned verbose = 0;
float alpha1 = 1;
float alpha2 = 0.45;
float alpha3 = 0;
float alpha4 = 0;
float margin = 1.1;
unsigned seed = 0;
unsigned root_idx = 0;
unsigned dist = 2;
float beta = 1.4;
bool runOneNet = false;
unsigned net_num = 0;
```

### Practice #24

Use class declarations if you are only referring to objects by pointer instead of including their complete class definition. This can vastly reduce the code the compiler has to process.

```
class Network;
// instead of
#include "Network.hh"
```

### Practice #25

Use pragma once instead of #define to protect headers from being read more than once. The #define symbol has to be unique, which is difficult to guarantee.

```
// Instead of:
#ifndef __MACRO_PLACER_HASH_UTIL__
#define __MACRO_PLACER_HASH_UTIL__
#endif
// use
#pragma once
```

### Practice #26

Don't put using namespace inside a function.

### Practice #27

Don't nest namespaces.

### Practice #28

Avoid using `namespace`. It increases the likelihood of conflicts and doesn't explicitly declare what is in the namespace is being used. Use `using namespace::symbol;` instead. And especially do not use `using namespace std`.

The following is especially confused because it is trying to "use" the symbols in code that are already in the MacroPlace namespace.

```
using namespace MacroPlace;

namespace MacroPlace { }
```

### Practice #29

Use `nullptr` instead of `NULL`. This is the C++ approved version of the ancient C `#define`.

### Practice #30

Use range iteration. C++ iterators are ugly and verbose.

```
// Instead of
odb::dbSet::iterator nIter;
for (nIter = nets.begin(); nIter != nets.end(); ++nIter) {
    odb::dbNet* currNet = *nIter;
    // code
}
// use
for (odb::dbNet* currNet : nets) {
    // code
}
```

### Practice #31

Don't use end of line comments unless they are very short.

```
for (int x = firstTile._x; x <= lastTile._x; x++) { // Setting capacities of edges.
    ↵completely inside the adjust region according the percentage of reduction
    // code
}
```

### Practice #32

Don't `std::pow` for powers of 2 or for decimal constants.

```
// This
double newCapPerSqr = (_options->getCapPerSqr() * std::pow(10.0, -12));
// Should be
double newCapPerSqr = _options->getCapPerSqr() * 1E-12;
```

(continues on next page)

(continued from previous page)

```
// This
unsigned numberOfTopologies = std::pow(2, numberNodes);
// Should be
unsigned numberOfTopologies = 1 << numberNodes;
```

## Git

### Practice #33

Don't put /'s in .gitignore directory names. test/

### Practice #34

Don't put file names in .gitignore ignored directories. test/results test/results/diffs

### Practice #35

Don't list compile artifacts in .gitignore. They all end up in the build directory so each file type does not have to appear in .gitignore.

All of the following are to be avoided:

#### Compiled Object files

\*.slo \*.lo \*.o \*.obj

#### Precompiled Headers

\*.gch \*.pch

#### Compiled Dynamic libraries

\*.so \*.dylib \*.dll

#### Fortran module files

\*.mod \*.smod

## Compiled Static libraries

\*.lai \*.la \*.a \*.lib

## CMake

### Practice #35

Don't change compile flags in cmake files. These are set at the top level and should not be overridden.

```
set(CMAKE_CXX_FLAGS "-O3")
set(CMAKE_CXX_FLAGS_DEBUG "-g -ggdb")
set(CMAKE_CXX_FLAGS_RELEASE "-O3")
```

### Practice #36

Don't put /'s in CMake directory names. CMake knows they are directories.

```
target_include_directories( ABKCommon PUBLIC ${ABKCOMMON_HOME} src/ )
```

### Practice #37

Don't use glob. Explicitly list the files in a group.

```
# Instead of
file(GLOB_RECURSE SRC_FILES ${CMAKE_CURRENT_SOURCE_DIR}/src/*.cpp)
# should be
list(REMOVE_ITEM SRC_FILES ${CMAKE_CURRENT_SOURCE_DIR}/src/Main.cpp)
list(REMOVE_ITEM SRC_FILES ${CMAKE_CURRENT_SOURCE_DIR}/src/Parameters.h)
list(REMOVE_ITEM SRC_FILES ${CMAKE_CURRENT_SOURCE_DIR}/src/Parameters.cpp)
```

## 5.3.6 Using the Logging Infrastructure

OpenROAD uses `spdlog` as part of logging infrastructure in order to ensure a clear, consistent messaging and complete messaging interface. A wrapper formats the prefix in the recommended messaging style and limit. A message format is as follows:

```
<tool id>-<message id> <Message body>.
```

For example,

```
[INFO ODB-0127] Reading DEF file: ./results/asap7/aes/base/4_cts.def
```

All output from OpenROAD tools should be directed through the logging API to ensure that redirection, file logging and execution control flow are handled consistently. This also includes messages from any third-party tool. Use the 'ord' message ID for third-party tools.

The logging infrastructure also supports generating a `JSON` file containing design metrics (e.g., area or slack). This output is directed to a user-specified file. The OpenROAD application has a `-metrics` command line argument to specify the file.

## Handling Messages

OpenROAD supports multiple levels of severity for message outputs: critical, error, warning, information and debug. These are supported by automatic calls to the logger which will then prefix the appropriate severity type to the message.

## C++20 Requirements

In C++20 the logger messages are checked during compile time which introduces restrictions around runtime format strings. See [docs](#).

OpenROAD uses `spdlog` which uses `fmt_lib` under the hood. Below is an example of what is no longer allowed.

In order to make use of runtime format strings, we have introduced a `FMT_RUNTIME` macro in `Logger.h`. You should use this macro any time you pass a dynamic string as the format string

```
logger_->info("{} {}", a, b); // OK

void blah(std::string template& a) {
    logger_->info(a, c); // Illegal
    logger_->info(FMT_RUNTIME(a), c); // Ok
}
```

## Messaging Guidelines

In addition to the proper use of message types, follow the guidelines below to compose messages for clarity, consistency and other guidelines:

### Grammar

Start with a capital letter and end with a period, besides well-known exceptions. Use capital letters for file formats and tool proper names, e.g., LEF, DEF, SPICE, FLUTE.

After the first word's capitalization, do not use capital letters (aside from obvious exceptions, such as RSMT, hCut, etc.).

Do not use exclamations. Severity must be communicated by message severity and clear implied or explicit action.

Avoid long, verbose messages. Use commas to list and separate clauses in messages.

Spellcheck all messages using American English spellings.

Use ellipsis ... only to indicate a pause, as when some tool is running or being initialized.

### Abbreviations and Shortcuts

Use single-word versions when well-accepted / well-understood by users and developers. Examples: `stdcell`, `cutline`, `wirelength`, `flipchip`, `padring`, `bondpad`, `wirebond`, `libcell`, `viarule`.

Do not abbreviate or truncate English words; expand for the sake of clarity.

Incorrect: Num, #; Tot.
-------------------------

Correct: Number; Total
------------------------

Use acceptable, well-understood abbreviations for brevity. Examples: db, tech, lib, inst, term, params, etc.

Avoid contractions of action words:

Incorrect: Can't, Can not; Don't
----------------------------------

Correct: Cannot; Do not
-------------------------

## Actionability

Messages should communicate a clear, implied or explicit action that is necessary for flow continuation or improved quality of results.

Example:
----------

A value for core_area must be specified in the footprint specification, or in the environment variable CORE_AREA.
-------------------------------------------------------------------------------------------------------------------

## Clarity

Messages must be clear and complete, so as to communicate necessary and sufficient information and actions. Elaborate specific variables, options, and/or parameters to avoid any ambiguity.

Example:
----------

Unrecognized argument \$arg, should be one of -pitch, -bump_pin_name, -spacing_to_edge, -cell_name, -bumps_per_tile, -rdl_layer, -rdl_width, -rdl_spacing.
------------------------------------------------------------------------------------------------------------------------------------------------------------

Specify objects clearly in the local context:

Example:
----------

cutWithin is smaller than cutSpacing for ADJACENTCUTS on layer {}. Please check your rule definition.
-------------------------------------------------------------------------------------------------------

Incomplete:
-------------

Warning: {} does not have viaDef aligned with layer.
------------------------------------------------------

Make any assumptions or use of default values explicit:

Example:
----------

No net slacks found.
----------------------

Timing-driven mode disabled.
------------------------------

Incomplete, missing default:
------------------------------

Utilization exceeds 100%.
---------------------------

Use simple language, and avoid repetitions:

Example:
----------

Missing orientation for cell \$cell_ref.
------------------------------------------

Incorrect:
------------

No orientation available for orientation of \$cell_ref.
---------------------------------------------------------

### Message Types

OpenROAD supports the following levels of severity through the logger: report, debug, information, warning, error and critical.

#### Report

Report messages are output by the tool in the form of a report to the user. Examples include timing paths or power analysis results.

Example report message:

```
Path startpoint: $startpoint
```

#### Debug

Debug messages are only of use to tool developers and not to end users. These messages are not shown unless explicitly enabled.

#### Information

Information messages may be used to report metrics, quality of results, or program status to the user. Any message which indicates runtime problems, such as potential faulty input or other internal program issues, should be issued at a higher status level.

Example information messages:

```
Number of input ports: 47  
Running optimization iteration 2  
Current cell site utilization: 57.1567%
```

#### Warning

Warnings should be used to indicate atypical runtime conditions that may affect quality, but not correctness, of the output. Any conditions that affect correctness should be issued at a higher status level.

Example warning messages:

```
Core area utilization is greater than 90%. The generated cell placement may not be  
↳ routable.  
  
14 outputs are not constrained for max capacitance.  
  
Pin 'A[0]' on instance 'mem01' does not contain antenna information and will not be  
↳ checked for antenna violations.
```

## Error

Error messages should be used to indicate correctness problems. Problems with command arguments are a good example of where error messages are appropriate. Errors exit the current command by throwing an exception that is converted to an error in Tcl. Errors that occur while reading a command file stop execution of the script commands.

Example error messages:

```
Invalid selection: net 'test0' does not exist in the design.

Cell placement cannot be run before floorplanning.

Argument 'max_routing_layer' expects an integer value from 1 to 10.
```

## Critical

Critical messages should be used to indicate correctness problems that the program is not able to work around or ignore, and that require immediate exiting of the program (abort).

Example critical messages:

```
Database 'chip' has been corrupted and is not recoverable.

Unable to allocate heap memory for array 'vertexIndices'. The required memory size may ↵
exceed host machine limits.

Assertion failed: 'nodeVisited == false' on line 122 of example.cpp. Please file a ↵
Github issue and attach a testcase.
```

## Coding

Each status message requires:

- The three letter tool ID
- The message ID
- The message string
- Optionally, additional arguments to fill in placeholders in the message string

Reporting is simply printing and does not require a tool or message ID. The tool ID comes from a fixed enumeration of all the tools in the system. This enumeration is in `Logger.h`. New abbreviations should be added after discussion with the OpenROAD system architects. The abbreviation matches the C++ namespace for the tool.

Message IDs are integers. They are expected to be unique for each tool. This has the benefit that a message can be mapped to the source code unambiguously even if the text is not unique. Maintaining this invariant is the tool owner's responsibility. To ensure that the IDs are unique, each tool should maintain a file named '`messages.txt`' in the top-level tool directory, listing the message IDs along with the format string. When code that uses a message ID is removed, the ID should be retired by removing it from '`messages.txt`'. See the utility `etc/find_messages.py` to scan a tool directory and write a `messages.txt` file.

Spdlog comes with the `fmt` library which supports message formatting in a python or C++20 like style.

The message string should not include the tool ID or message ID which will automatically be prepended. A trailing newline will automatically be added, and hence messages should not end with one. Messages should be written as complete sentences and end in a period. Multi-line messages may contain embedded new lines.

Some examples:

```
logger->report("Path startpoint: {}", startpoint);

logger->error(ODB, 25, "Unable to open LEF file {}.", file_name);

logger->info(DRT, 42, "Routed {} nets in {:.2f}s.", net_count, elapsed_time);
```

Tcl functions for reporting messages are defined in the OpenROAD swig file `OpenRoad.i`. The message is simply a Tcl string (no C++20 formatting).

```
utl::report "Path startpoint: $startpoint"

utl::error ODB 25 "Unable to open LEF file $file_name."

utl::info DRT 42 "Routed $net_count nets in [format %.2f $elapsed_time]."
```

`utl::report` should be used instead of ‘puts’ so that all output is logged.

Calls to the Tcl functions `utl::warn` and `utl::error` with a single message argument report with tool ID `UKN` and message ID `0000`.

Tools use `#include utl/Logger.h` that defines the logger API. The Logger instance is owned by the OpenROAD instance. Each tool should retrieve the logger instance in the tool init function called after the tool make function by the OpenROAD application.

Every tool swig file must include `src/Exception.i` so that errors thrown by `utl::error` are caught at the Tcl command level. Use the following swig command before `%inline`.

```
%include "../../Exception.i"
```

The logger functions are shown below.

```
Logger::report(const std::string& message,
               const Args&... args)
Logger::info(ToolId tool,
            int id,
            const std::string& message,
            const Args&... args)
Logger::warn(ToolId tool,
            int id,
            const std::string& message,
            const Args&... args)
Logger::error(ToolId tool,
             int id,
             const std::string& message,
             const Args&... args)
Logger::critical(ToolId tool,
                 int id,
                 const std::string& message,
                 const Args&... args)
```

The corresponding Tcl functions are shown below.

```
utl::report message
utl::info tool id message
```

(continues on next page)

(continued from previous page)

```
utl::warn tool id message
utl::error tool id message
utl::critical tool id message
```

Although there is a `utl::critical` function, it is really difficult to imagine any circumstances that would justify aborting execution of the application in a tcl function.

## Debug Messages

Debug messages have a different programming model. As they are most often *not* issued the concern is to avoid slowing down normal execution. For this reason such messages are issued by using the `debugPrint` macro. This macro will avoid evaluating its arguments if they are not going to be printed. The API is:

```
debugPrint(logger, tool, group, level, message, ...);
```

The `debug()` method of the `Logger` class should not be called directly. No message id is used as these messages are not intended for end users. The level is printed as the message id in the output.

The argument types are as for the `info/warn/error/critical` messages. The one additional argument is `group` which is a `const char*`. Its purpose is to allow the enabling of subsets of messages within one tool.

Debug messages are enabled with the tcl command: `set_debug_level <tool> <group> <level>`

## Metrics

The metrics logging uses a more restricted API since JSON only supports specific types. There are a set of overloaded methods of the form:

```
metric(ToolId tool,
      const std::string_view metric,
      <type> value)
```

where `<type>` can be `int`, `double`, `string`, or `bool`. This will result in the generated JSON:

```
"<tool>-<metric>" : value
```

String values will be enclosed in double-quotes automatically.

## Converting to Logger

The error functions in `include/openroad/Error.hh` should no longer be included or used. Use the corresponding logger functions.

All uses of the tcl functions `ord::error` and `ord::warn` should be updated call the `utl::error/warn` with a tool ID and message ID. For compatibility these are defaulted to `UKN` and `0000` until they are updated.

Regression tests should not have any `UKN-0000` messages in their `ok` files. A simple grep should indicate that you still have pending calls to pre-logger error/warn functions.

The `CMakeLists.txt` file for the tool must also be updated to include `spdlog` in the link libraries so it can find the header files if they are not in the normal system directories.

**Tip:** At UCSD, dfm.ucsd.edu is an example of this problem; it has an ancient version of spdlog in '/usr/include/spdlog'. Use module to install spdlog 1.8.1 on dfm.ucsd.edu and check your build there.

```
target_link_libraries(<library_target>
    PUBLIC
        utl
)
```

### Useful Information

As tool developers, we can also choose to include useful information to the end user - be it in the form of debugging tips, or solutions to fix the errors/warnings. We compile a list of such errors in this [table](#). The good thing about this page is the ability to encode rich formatting using Markdown, enabling you to convey more information than what can be said from the limited messages in code.

To format the information, refer to this sample GRT information file. In addition, make sure you create the corresponding docs/messages folder under the tool folder, before creating your Markdown file with the corresponding NUM.

```
cd src/<tool> && mkdir -p doc/messages
cd doc/messages && touch <NUM>.md
```

### OpenROAD Tool List

A full list of tool namespaces can be found [here](#).

#### 5.3.7 CI Guide

This document describes the pipelines available to the developers and code maintainers in the [Jenkins server](#). Note that pipelines with the suffix \*-Private are only available to code maintainers and The OpenROAD Project members as they can contain confidential information. Thus, to access Private pipelines one needs to have authorization to access confidential data and be logged in the Jenkins website.

Below there is a list of the available features. Instructions on how to navigate Jenkins to access these features are available [here](#).

- Find your build through Jenkins website or from GitHub.
- See test status: Pass/Fail.
- Log files for each test.
- Build artifacts to reproduce failures.
- HTML reports about code coverage and metrics.

## OpenROAD App

- OpenROAD-Coverage-Public
  - Description: run dynamic code coverage tool lconv.
  - Target: master branch.
  - Report link [here](#).
- OpenROAD-Coverity-Public
  - Description: compile and submit builds to Coverity static code analysis tool.
  - Target: master branch.
  - Report link [here](#).
- OpenROAD-Nightly-Public
  - Description: openroad unit tests, docker builds, ISPD 2018 and 2019 benchmarks for DRT and large unit tests of GPL.
  - Target: master branch.
- OpenROAD-Public
  - Description: openroad unit tests and docker builds.
  - Target: all branches and open PRs.
- OpenROAD-Special-Private
  - Description: for developer testing, runs ISPD 2018 and 2019 benchmarks for DRT and large unit tests of GPL.
  - Target branches: TR\_\*, secure-TR\_\*, TR-\*, secure-TR-\*.
- OpenROAD-Private
  - Description: openroad unit tests and docker builds.
  - Target: all branches. Note that PRs will be run on public side after “Ready to Sync Public” workflow.

## OpenROAD Flow

- Information about OpenROAD Flow CI jobs can be found [here](#)

## OpenLane

- OpenLane-MPW-CI-Public
  - Description: test projects to older MPW shuttles with newer OpenLane versions.
  - [Repo link](#).
- OpenLane-Public
  - Description: test OpenLane with latest commit from OpenROAD.
  - [Repo link](#).

## **5.4 Contributor Covenant Code of Conduct**

### **5.4.1 Our Pledge**

We as members, contributors, and leaders pledge to make participation in our community a harassment-free experience for everyone, regardless of age, body size, visible or invisible disability, ethnicity, sex characteristics, gender identity and expression, level of experience, education, socio-economic status, nationality, personal appearance, race, religion, or sexual identity and orientation.

We pledge to act and interact in ways that contribute to an open, welcoming, diverse, inclusive, and healthy community.

### **5.4.2 Our Standards**

Examples of behavior that contributes to a positive environment for our community include:

- Demonstrating empathy and kindness toward other people
- Being respectful of differing opinions, viewpoints, and experiences
- Giving and gracefully accepting constructive feedback
- Accepting responsibility and apologizing to those affected by our mistakes, and learning from the experience
- Focusing on what is best not just for us as individuals, but for the overall community

Examples of unacceptable behavior include:

- The use of sexualized language or imagery, and sexual attention or advances of any kind
- Trolling, insulting or derogatory comments, and personal or political attacks
- Public or private harassment
- Publishing others' private information, such as a physical or email address, without their explicit permission
- Other conduct which could reasonably be considered inappropriate in a professional setting

### **5.4.3 Enforcement Responsibilities**

Community leaders are responsible for clarifying and enforcing our standards of acceptable behavior and will take appropriate and fair corrective action in response to any behavior that they deem inappropriate, threatening, offensive, or harmful.

Community leaders have the right and responsibility to remove, edit, or reject comments, commits, code, wiki edits, issues, and other contributions that are not aligned to this Code of Conduct, and will communicate reasons for moderation decisions when appropriate.

### **5.4.4 Scope**

This Code of Conduct applies within all community spaces, and also applies when an individual is officially representing the community in public spaces. Examples of representing our community include using an official e-mail address, posting via an official social media account, or acting as an appointed representative at an online or offline event.

## 5.4.5 Enforcement

Instances of abusive, harassing, or otherwise unacceptable behavior may be reported to the community leaders responsible for enforcement at [complaints@openroad.tools](mailto:complaints@openroad.tools). All complaints will be reviewed and investigated promptly and fairly.

All community leaders are obligated to respect the privacy and security of the reporter of any incident.

## 5.4.6 Enforcement Guidelines

Community leaders will follow these Community Impact Guidelines in determining the consequences for any action they deem in violation of this Code of Conduct:

### 1. Correction

**Community Impact:** Use of inappropriate language or other behavior deemed unprofessional or unwelcome in the community.

**Consequence:** A private, written warning from community leaders, providing clarity around the nature of the violation and an explanation of why the behavior was inappropriate. A public apology may be requested.

### 2. Warning

**Community Impact:** A violation through a single incident or series of actions.

**Consequence:** A warning with consequences for continued behavior. No interaction with the people involved, including unsolicited interaction with those enforcing the Code of Conduct, for a specified period of time. This includes avoiding interactions in community spaces as well as external channels like social media. Violating these terms may lead to a temporary or permanent ban.

### 3. Temporary Ban

**Community Impact:** A serious violation of community standards, including sustained inappropriate behavior.

**Consequence:** A temporary ban from any sort of interaction or public communication with the community for a specified period of time. No public or private interaction with the people involved, including unsolicited interaction with those enforcing the Code of Conduct, is allowed during this period. Violating these terms may lead to a permanent ban.

### 4. Permanent Ban

**Community Impact:** Demonstrating a pattern of violation of community standards, including sustained inappropriate behavior, harassment of an individual, or aggression toward or disparagement of classes of individuals.

**Consequence:** A permanent ban from any sort of public interaction within the community.

### **5.4.7 Attribution**

This Code of Conduct is adapted from the [Contributor Covenant](https://www.contributor-covenant.org/version/2/0/code_of_conduct.html), version 2.0, available at [https://www.contributor-covenant.org/version/2/0/code\\_of\\_conduct.html](https://www.contributor-covenant.org/version/2/0/code_of_conduct.html).

Community Impact Guidelines were inspired by [Mozilla's code of conduct enforcement ladder](#).

For answers to common questions about this code of conduct, see the FAQ at <https://www.contributor-covenant.org/faq>. Translations are available at <https://www.contributor-covenant.org/translations>.

## **5.5 FAQs**

If you cannot find your question/answer here, please file a GitHub issue to the appropriate repository or start a discussion.

- Issues and bugs:
  - OpenROAD: <https://github.com/The-OpenROAD-Project/OpenROAD/issues>
- Discussions:
  - OpenROAD: <https://github.com/The-OpenROAD-Project/OpenROAD/discussions>

### **5.5.1 How can I contribute?**

Thank you for your willingness to contribute. Please see the [\*Getting Involved\*](#) guide.